

Establish Your Debug Session

Establish Your Debug Session

TRACE32 Online Help

TRACE32 Directory

TRACE32 Index

TRACE32 Debugger Getting Started	
Establish Your Debug Session	1
History	4
Establish your Debug Session	5
Key TRACE32 Setup Commands	5
The PER.view/PER.Set Command	5
The Data.LOAD Command	7
Debug Scenarios	9
Establish the Debug Communication	11
Debug Scenario 1	17
Onchip/NOR Flash Programming	18
The Flash Programming File	18
On-chip Flash Programming	19
Off-chip NOR Flash Programming	24
Configure the TRACE32 OS Awareness	35
Debug Scenario 2	36
Typical Boot Sequence	36
Flash Programming (NAND/Serial/eMMC)	41
The Flash Programming File and the Debug Symbol File	41
NAND Flash Programming (non-generic NAND Flash Controller)	42
eMMC Flash Programming	54
Establish the Communication	55
Load the Debug Symbols	55
Debug Scenario 3	56
Run the Boot Loader	57
Load Application (and/or OS) Code and Debug Symbols	58
Load Debug Symbols only	58
Configure the TRACE32 OS Awareness	58
Complete Setup Example	58
Debug Scenario 4	59
Write a Script to Configure the Target	60
Load Application (and/or OS) Code and Debug Symbols	60
Configure the TRACE32 OS Awareness	60

Start-Up Scripts	61
Write a Start-Up Script	61
Run a Start-up Script	62
Automated Start-up Scripts	62

History

16-Oct-2014 Initial version of the manual.

23-Jan-2020 Full revision of the manual.

Establish your Debug Session

Before you can start debugging, you need to set up the debug environment. The necessary configurations depend significantly on the specific debug scenario.

Key TRACE32 Setup Commands

The PER.view/PER.Set Command

A debug setup requires configuring various core/chip-related registers. The main commands to perform these configurations are:

PER.Set.simple <address>|<range> [%<format>] <string>

Modify configuration register/on-chip peripheral

Data.Set <address>|<range> [%<format>] <string>

Modify memory-mapped configuration register/on-chip peripheral


The main command to inspect the configurations is:

PER.view <file> [<tree_search_item>] /SpotLight


Display the configuration registers/on-chip peripherals, highlight changes

Example: Disable Watchdog

```
; Display "Watchdog Timer" configuration registers, highlight changes
; a comma is used instead of the <file>
PER.view , "Watchdog Timer" /SpotLight
```



```
; Disable Watchdog timer by configuring Watchdog Timer Control Register
; (WTCN)
PER.Set.simple 0x53000000 %Long 0x0
```



Setting up a debug environment involves loading the code to be debugged and the associated debug symbols. TRACE32 PowerView supports a wide range of compilers and compiler output formats. You can find a list of supported compilers on the Lauterbach website.

The most important commands for loading the code to be debugged and the associated debug symbols are:

Data.LOAD.<sub_cmd> <file> /<option>	Load code and debug symbols
Data.LOAD.Binary <file> /<option>	Load only code
Data.LOAD.<sub_cmd> <file> /NoCODE /<option>	Load only debug symbols

Examples:

```
Data.LOAD.Elf demo-flash.elf          ; Load code and debug symbols from
                                         ; ELF file

Data.LOAD.AIF demo.axf                ; Load code and debug symbols from
                                         ; AIF file

Data.LOAD.Elf *                      ; Load code and debug symbols from
                                         ; ELF file
                                         ; open file browser to select file

Data.LOAD.Elf demo.elf /NoCODE        ; Load debug symbols from ELF file

Data.LOAD.Binary my_app.bin          ; Load code from binary file
```

A in-depth introduction to the **Data.LOAD** command is given in the chapter "["Load the Application Program"](#) (training_hll.pdf).


The TASK.CONFIG Command

Today most applications use an operating system. TRACE32 PowerView includes a configurable target-OS debugger to provide symbolic debugging of operating systems.


Lauterbach provides ready-to-run configuration files for most common available OSes.

To get the appropriate information on your OS, proceed as follows:

1. Open the online help and deactivate the help filter.




2. Open the TRACE32 **OS Awareness Manual** for your operating system.



Debug Scenarios

The necessary setup for your debug session depends crucially on the debug scenario. The graphic below shows you that there are mainly four debug scenarios.



After the communication between the debugger and the core(s) is established, there are four debug scenarios. Each debug scenario requires a different setup.

- **Debug Scenario 1**

The boot loader or the application (and/or the operating system) under debug is running out of Onchip/NOR flash.

- **Debug Scenario 2**

The boot loader under debug is running out of a flash e.g. a NAND or serial flash.


- **Debug Scenario 3**

The application (and/or the operating system) under debug are running out of RAM and a ready-to-run boot loader configures the target system and especially the RAM for this debug scenario.


- **Debug Scenario 4**

The application (and/or the operating system) under debug are running out of RAM. The target configuration, especially the RAM configuration has to be done by TRACE32 commands, because there is no ready-to-run boot loader.

Establish the Debug Communication



1. Select the target core/chip



Inform the debugger about the core/chip on your target, if an automatic detection of the core/chip is not possible. Wild card symbols * or ? are allowed.

SYStem.DETECT CPU

Auto detection of CPU

SYStem.CPU <cpu>

Select the CPU/chip


```
SYStem.CPU CortexR5
```

```
SYStem.CPU CortexR5*
```

2. Adjust the JTAG clock

The debugger uses a default JTAG clock of 10 MHz. Adjusting the JTAG clock might be necessary:

- if a fixed relation between the core clock and the JTAG clock is specified.



SYStem.JtagClock <frequency>


Select the JTAG clock

```
SYStem.JtagClock 1.MHz
```


```
SYStem.JtagClock 100.kHz
```

3. Set the required options for your core/chip

Some cores/chips require additional settings before the communication can be established.




For details refer to the **Processor Architecture Manual**.



4. Establish the communication

The most common way to establish the communication between the debugger and the core(s) is **Up**.




If **Up** is selected, the following steps are performed:

- Reset of the core/chip
- Initialization of the communication between the debugger and the core(s)
- Stop of the core(s) at the reset vector

SYStem.Up

Establish the communication between the debugger and the core(s)

A second useful way to establish the communication between the debugger and the core/chip is **Attach**. **Attach** allows to connect the debugger to an already running core/chip.



If **Attach** is selected, the following step is performed:

1. Initialization of the communication between the debugger and the core(s).

SYStem.Mode Attach


Establish the communication between the debugger and the target core(s) (without reset)

SYStem.Mode Attach

Break ; stop the program execution

Debug Scenario 1

The boot loader or the application (and/or the operating system) under debug is running out of the on-chip flash or out of a NOR flash device.



*Considering the circumstance that a process has to be started manually e.g. via a TERMINAL window

Onchip/NOR Flash Programming

The debugger supports the programming of on-chip flash and off-chip NOR flash devices.

NOTE: Flash programming requires that data cache is disabled for the address range covered by the FLASH.

The Flash Programming File

On-chip flash and off-chip NOR flash programming allows to load any output file generated by your compiler.

Videos about the on-chip flash programming can be found here:

support.lauterbach.com/kb/articles/flash-programming



Ready-to-run scripts for most on-chip flashes can be found in `~/demo/<architecture>/flash/<cpu>.cmm`

e.g. `~/demo/arm/flash/mk20.cmm`


e.g. `~/demo/powerpc/flash/mpc5xxx.cmm`

To program the software to the on-chip flash of your processor/chip proceed as follows:


1. Start the script appropriate for your processor/chip.




2. TRACE32 PowerView informs you when all preparations are done. Please confirm that you are ready to choose the boot loader or the application to be programmed.



3. Please select the boot loader or application to be programmed.



TRACE32 PowerView informs you, that the programming is done.



If the boot loader/application is compiled with debug symbols they are automatically loaded into TRACE32 PowerView with the flash programming.

For details on the on-chip flash programming open the flash programming script.

```
; ~~ represents the TRACE32 installation directory
PEDIT ~~/demo/powerpc/flash/mpc5xxxx.cmm
```



If you create your own start-up script for your target hardware, please call the flash programming script from there.

If you leave the flash programming script unchanged, you can always replace it with its most current version.

The following parameters can be used, when the flash programming script is called:

CPU=<cpu>	If a FLASH programming script supports a CPU family, you can provide your target CPU as parameter.
PREPAREONLY	Advise the FLASH programming script to prepare the FLASH programming by declaring the FLASH sectors and by linking the appropriate programming binary. The FLASH programming commands are bypassed.
DUALPORT=0 1	Disable/enable DualPort FLASH programming. For all processors/cores that allow to write to physical memory while the CPU is running a higher FLASH programming performance can be achieved by the use of DualPort FLASH Programming

Not every script supports all parameters. The parameters relevant for your script are described in the meta data section of the script.

```
; -----  
; @Title: Generic script for Freescale MK20, MK21 and MK22 internal flash  
;  
; @Description:  
;  
; Example for flash declaration of Freescale MK20, MK21 and MK22 internal  
; flash.  
  
; Script arguments:  
;  
; DO mk20 [PREPAREONLY] [CPU=<cpu>] [DUALPORT=0|1] [MASSEREASE]  
;  
; PREPAREONLY only declares flash but does not execute flash programming  
;  
; CPU=<cpu> selects CPU derivative <cpu>. <cpu> can be CPU name out of the  
; table listed below. For these derivatives the flash declaration  
; is done by the script.  
;  
; DUALPORT default value is 0 (disabled). If DualPort mode is enabled  
; flash algorithm stays running until flash programming is  
; finished. Data is transferred via dual port memory access.  
;  
; MASSEREASE forces mass erase of device before establishing debug connection  
;  
; For example:  
;  
; DO --/demo/arm/flash/mk20 CPU=MK20DN512VLK10 DUALPORT=1 PREPAREONLY  
  
; List of MK20/MK21/MK22 derivatives and their configuration:  
;  
; CPU-Type      Flash    ProgFlash   FlexNVM    EEPROM    RamSize  
;   type        [Byte]   [Byte]      [Byte]     [Byte]    [Byte]  
; -----  
; MK20DN32VEX5    0      32KB       -         -       8KB  
; MK20DN32VFM5    0      32KB       -         -       8KB  
; MK20DN32VFT5    0      32KB       -         -       8KB
```

The following framework can be used to call the flash programming script from your start-up script.

```
...
DO <flash_script> [CPU=<cpu>] PREPAREONLY [DUALPORT=0|1]

; program file to on-chip FLASH
FLASH.ReProgram ALL /Erase
Data.LOAD.Elf <file>
FLASH.ReProgram off

; reset processor/chip
; might be necessary to reset all target settings made by the flash
; programming script
SYStem.Up

; continue with start-up script
;...
```

More details on the on-chip flash programming can be found in [“Onchip/NOR FLASH Programming User’s Guide”](#) (norflash.pdf).

TRACE32 PowerView provides two methods to program off-chip NOR flash:

1. Tool-based programming

Tool-based programming means that the flash programming algorithm is part of the TRACE32 software. Tool-based programming is easy to configure but slow.

2. Target-controlled programming

Target-controlled flash programming means that the underlying flash programming algorithm is detached from the TRACE32 software. Target-controlled flash programming works as follows:


1. The flash algorithm is downloaded to the target RAM.
2. The programming data are downloaded to the target RAM.
3. The flash algorithm running in the target RAM programs the data to the flash devices.

Target-controlled flash programming minimizes the communication between the host and the debugger hardware. This makes target-controlled flash programming fast.

NOTE:

It is recommended to start with tool-based flash programming. If this works properly you can switch to target-controlled flash programming.


Programming off-chip NOR flash requires the following steps (see next page):




1. Disable Internal and External Watchdog

Example

```
; Display "Watchdog Timer" configuration registers, highlight changes  
PER.view , "Watchdog Timer" /SpotLight
```



```
; Disable Watchdog timer by configuring Watchdog Timer Control Register  
; (WTCON)  
PER.Set.simple 0x53000000 %Long 0x0
```




2. Disable Data Cache


The data cache has to be disabled for the address ranges of all flash devices to enable TRACE32 PowerView to read the flash status information.

Example

```
; Display the memory management configuration registers
; highlight changes
PER.view , "Core Registers,Memory Management Unit" /SpotLight
```



```
; Disable Data Cache by configuring the control register SCLTR
PER.Set.simple C15:0x1 %Long 0x550078
```



3. Make sure that the core has write access to the flash

NOR flash programming requires that the core has write access to the flash device(s).

The following settings in the **bus configuration** have to be done for each NOR flash device:

- Definition of the base address of the NOR flash device
- Definition of the size of the NOR flash device
- Definition of the bus size that is used to access the NOR flash device
- The write access has to be enabled for the NOR flash device
- Definition of the timing (number of wait states for the write access to the NOR flash device)

Use the **PER.view** command to check the settings in the bus configuration registers.

Example for ColdFire

Bus configuration after reset:



In order to have write access to the used off-chip NOR flash device the **Address Region 0** has to be configured for the following characteristics:


- Base address 0xa0000000
- Size 16 MByte
- Bus size 16 bit

PER.Set <address> %<format> <value>

Data.Set <address> %<format> <value>

```
PER.view , /SpotLight ; Highlight all changed
; configuration registers
PER.Set 0xf0000080 %Long 0xA0000031 ; ADDSEL0
PER.Set 0xf00000c0 %Long 0x00508637 ; BUSCON0
```

Correct bus configuration for NOR flash programming.



FLASH.RESet	Reset the FLASH declaration table
FLASH.CFI < <i>start_address</i> > < <i>data_bus_width</i> >	Generate a FLASH declaration by evaluating the Common Flash Interface description inside the FLASH device. The command FLASH.CFI requires the definition of <ul style="list-style-type: none">• the <<i>start_address</i>> of the FLASH device• the <<i>data_bus_width</i>> that is used by the core to access the FLASH device
FLASH.List	List the FLASH declaration table
FLASH.UNLOCK ALL	Unlock the FLASH sectors
FLASH.ReProgram ALL OFF	Enable/disable the FLASH programming
Data.LOAD.<sub_cmd> <file> /<option>	Load code and debug symbols

More details on the concepts of the TRACE32 NOR flash programming can be found in “[Onchip/NOR FLASH Programming User’s Guide](#)” (norflash.pdf).

If your FLASH device doesn’t provide CFI please refer to “[Onchip/NOR FLASH Programming User’s Guide](#)” (norflash.pdf) for details on the FLASH programming procedure.

Example

```
FLASH.RESet ; Reset the FLASH declaration table

FLASH.CFI 0xa0000000 Word ; Generate a FLASH declaration via
; CFI

FLASH.List ; Display the FLASH declaration
; table

FLASH.UNLOCK ALL ; Unlock the FLASH device if
; required
; e.g. some FLASH devices are
; locked after power on

FLASH.ReProgram ALL ; Enable the FLASH for programming

Data.LOAD.Elf demo.elf ; Specify the file that contains
; the code and the debug symbols

FLASH.ReProgram off ; Program FLASH and disable
; the FLASH programming afterwards

Data.LOAD.Elf demo.elf /DIFF ; Verify the FLASH programming

IF FOUND()
    PRINT "Verify error after FLASH programming"
ELSE
    PRINT "FLASH programming completed successfully"
```

FLASH.RESet

Reset the FLASH declaration table

FLASH.CFI <*start_address*> <*bus_width*> /**TARGET** <*code_range*> <*data_range*>

Generate a FLASH declaration by evaluating the Common Flash Interface description inside the FLASH device.

The command **FLASH.CFI** requires the definition of

- the <*start_address*> of the FLASH device
- the <*data_bus_width*> that is used by the core to access the FLASH device
- the target RAM location <*code_range*> for the flash programming algorithm
- the target RAM location <*data_range*> for the flash programming data

FLASH.List

List the FLASH declaration table

FLASH.UNLOCK ALL

Unlock the FLASH sectors

FLASH.ReProgram ALL | OFF

Enable/disable the FLASH programming

Data.LOAD.<sub_cmd> <file> /<option>

Load code and debug symbols

Details on `<code_range>`

Required size for the code is `size_of(file) + 32 byte`

Flash programming algorithm	Memory mapping for the <code><code_range></code>
32 byte	

Details on `<data_range>`

The parameter `<data_range>` specifies the RAM location for the data, especially

- the `<data_buffer_size>` for the programming data. Recommended buffer size is 4 KByte, smaller buffer sizes are also possible. The max. buffer size is 16 KByte
- the argument buffer for the communication between TRACE32 PowerView and the programming algorithm
- the stack

```
<data_buffer_size> =  
size_of(<data_range>) - 64 byte argument buffer - 256 byte stack
```

64 byte argument buffer	Memory mapping for the <code><data_range></code>
Data buffer for data transfer between TRACE32 and flash programming algorithm <code><buffer_size></code> calculated as described above	
256 byte stack	

4. Enable RAM Access

Target-controlled Flash Programming requires, that the core has access to the RAM locations specified for *<code_range>* and *<data_range>*.

If this is not the case the following settings in the **bus configuration** have to be done for an off-chip RAM:

- Definition of the base address of the RAM
- Definition of the size of the RAM
- Definition of the bus size that is used to access the RAM
- Definition of the timing (number of wait states for the RAM access)

Example

```
; reset the FLASH declaration table
FLASH.RESet

; set up the FLASH declaration for target-controlled programming
; target RAM at address 0x20000000
FLASH.CFI 0x0 Word /TARGET 0x20000000++0xffff 0x20001000++0xffff

; display FLASH declaration table
FLASH.List

; unlock the FLASH device if required for a power-up locked device
; FLASH.UNLOCK ALL

; enable the programming for all declared FLASH devices
FLASH.ReProgram ALL

; specify the file that contains the code and the debug symbols
Data.LOAD.Elf demo.elf

; program the file and disable the FLASH programming afterwards
FLASH.ReProgram off

; verify the FLASH contents
Data.LOAD.Elf demo.elf /DIFF

IF FOUND()
    PRINT "Verify error after FLASH programming"
ELSE
    PRINT "FLASH programming completed successfully"
...
```

Configure the TRACE32 OS Awareness

Refer to “[The **TASK.CONFIG** Command](#)”, page 8 for details.

Debug Scenario 2

The boot loader under debug is running out of a flash e.g. a NAND flash.

In contrast to NOR flash, code can not be executed out of NAND or serial flash. The code has always to be copied to RAM before it can be executed.


Typical Boot Sequence

Before the setup for debug scenario 2 is described, it might be useful to have a look at a typical boot sequence. If the boot loader is running out of flash the system start-up might include the following steps:

1. Reset


At RESET the boot loader is copied from the flash to an on-chip SRAM, which is mapped to the reset vector. The boot loader starts afterwards.

Please be aware, that some core(s) require a correct ECC for this copy procedure.




2. Boot loader is running


The main task of the boot loader is to initialize the SDRAM and to copy the second stage boot loader to SDRAM. When this is done the control is passed to the second stage boot loader.



3. Second stage boot loader is running

The main task of the second stage boot loader is to copy the kernel image to SDRAM. When this is done the control is passed to the kernel.





NOTE: Flash programming requires that data cache and MMU are disabled.

The Flash Programming File and the Debug Symbol File

Flash programming can only program binary files. Therefore two output files have to be generated by the compiler:

- A binary file (e.g. boot.bin)
- A file containing the debug symbols (e.g. boot.elf)


NAND Flash Programming (non-generic NAND Flash Controller)

Ready-to-run flash programming scripts for most processors/chips can be found in the directory
~~/demo/<architecture>/flash

Folder and file name convention:

~~/demo/<architecture>/flash/<cpu_name>-<prefix_of_nand_flash_code>.cmm


Get <cpu_name> from the CPU column of the list of “**Supported NAND/Serial Flash Controller**” on the Lauterbach home page (www.lauterbach.com) if the CONTROLLER column does not indicate generic.



CPU	CONTROLLER	COMMENT	STATE
IMX21	imx	NAND	
IMX23	gpmimx23	NAND	
IMX25	imx25	NAND	
IMX25	ecspi	SPI(eCSPI)	
IMX27	imx	NAND	
IMX27	imx	SPI(CSPI)	
IMX28	gpmimx28	NAND	
IMX31	imx	NAND	
IMX31	imx	SPI(CSPI)	
IMX35	imx25	NAND	
IMX35	ecspi	SPI(eCSPI)	
IMX51	imx51	NAND	
IMX51	ecspi	SPI(eCSPI)	
IMX51	imx51	eMMC/SD/MMC	
IMX53	imx51	NAND	
IMX6	ecspi	SPI(eCSPI)	
IMX6	nnmimx6	NAND	

If the **CONTROLLER** column indicates **generic** refer to “[NAND Flash Programming \(generic NAND Flash Controller\)](#)”, page 45.

Get the prefix of the <nand_flash_code> from the CODE column of the list of “**Supported Flash Devices**” on the Lauterbach home page (www.lauterbach.com).




The screenshot shows a Firefox browser window with the Lauterbach website open. The URL is www.lauterbach.com/frames.html?home.html. The page title is "TRACE32® Supported FLASH Devices". On the left, a sidebar menu is open under "Tool Chain", with "Supported Flash Devices" selected. The main content area is titled "Hynix semiconductor" and contains a table with the following data:

TYPE	COMPANY	CODE	COMMENT
H27U518S	HYNIX	NAND1208	
H8KDSOUN0MER	HYNIX	NAND2G16	NAND Flash
HY27SS08561A	HYNIX	NAND5608L	NAND Flash
HY27SS16561A	HYNIX	NAND5616L	NAND Flash
HY27UF082G2A	HYNIX	NAND2G08	NAND-Flash
HY27UF082G2M	HYNIX	NAND2G08L	NAND-Flash
HY27UF162G2A	HYNIX	NAND2G16	NAND-Flash
HY27UF162G2B	HYNIX	NAND2G16	NAND-Flash
HY27UF162G2M	HYNIX	NAND2G16L	NAND-Flash
HY27UG082G2B	HYNIX	NAND2G08	NAND-Flash
HY27US08561A	HYNIX	NAND5608L	NAND Flash
HY27US16561A	HYNIX	NAND5616L	NAND Flash
HY29DL162	HYNIX	AM29LV100	16-bit mode
		AM29LV100B	8-bit mode
HY29DL163	HYNIX	AM29LV100	16-bit mode
		AM29LV100B	8-bit mode
HY29DS162	HYNIX	AM29LV100	16-bit mode


Name of flash programming script here `~/demo/arm/flash/imx31-nand2g08.cmm`

To program the code to flash proceed as follows:


1. Start the script appropriate for your processor/chip and appropriate for your flash device.



2. TRACE32 PowerView informs you when all preparations are done. Please confirm that you are ready to choose the boot loader binary to be programmed.




3. Please select the boot loader to be programmed.



Detail on NAND flash programming can be found in [“NAND FLASH Programming User’s Guide”](#) (handflash.pdf).


NAND Flash Programming (generic NAND Flash Controller)

The **CONTROLLER** column of the list of “**Supported NAND/Serial Flash Controller**” on the Lauterbach home page (www.lauterbach.com) indicates “generic”, if a processor/chip has a generic NAND flash controller.



CPU	CONTROLLER	COMMENT	STATE
SH7264	sh7264	NAND	
SH7264	sh7264	SPI	
Samsung Semiconductor			
S3C24XX	generic	NAND	
S3C6410	s3c6410	OneNAND	
S3C6410	s3c6410	eMMC/SD/MMC	
S3C64XX	generic	NAND	

Programming script for generic NAND flash controller have to be written by the user.



1. Prepare the NAND FLASH Controller and the NAND FLASH for Programming

Programming a flash device requires a proper initialization of the flash controller and the bus interface. The following settings might be necessary:

- Power up the flash clock domain.
- Enable the flash controller or bus.
- Configure the communication signals (clock, timing, etc.).
- Inform the flash controller about the flash device (large/small page, ECC, spare, etc.).
- Configure the flash pins if they are muxed with other functions of the processor/chip.
- Disable the write protection for the flash.

Use the **PER.Set/PER.view** commands for this setup.

Example for s3c2410X (ARM920T):

```
PER.view , "NAND Flash Controller" /SpotLight
```

B:PER.view , "NAND Flash Controller" /SpotLight								
NAND Flash Controller								
NFCONF	00004800	ENABLE	Disabled	INI_ECC	Not initialized	NFM_CEN	Inactive	TACLS 0
				TWRPH0	0			
NFCMD	00000000	COMMAND	00					
NFADDR	00000000	ADDRESS	00					
NFDATA	00000000	DATA	00					
NFSTAT	00008301	RNB	Ready					
NFECC	00559595	ECC2	55	ECC1	95	ECC0	95	

```
; enable and configure NAND flash controller  
PER.Set 0x4E000000 %Long 0xE030
```

B:PER.view , "NAND Flash Controller" /SpotLight								
NAND Flash Controller								
NFCONF	0000E030	ENABLE	Enabled	INI_ECC	Not initialized	NFM_CEN	Active	TACLS 0
				TWRPH0	3			
NFCMD	00000000	COMMAND	00					
NFADDR	00000000	ADDRESS	00					
NFDATA	00000004	DATA	04					
NFSTAT	00008301	RNB	Ready					
NFECC	00C0C00C	ECC2	C0	ECC1	C0	ECC0	0C	

2. Enable RAM Access

TRACE32 PowerView runs the flash programming algorithm in target RAM. It requires at least 16 KByte of RAM for this purpose.

This requires that the core has access to target RAM.

If the core has no access to target RAM, the access to target RAM has to be set up.

Correct settings in the bus configuration registers are key for the RAM access. The following settings in the bus configuration have to be done:

- Definition of the RAM base address
- Definition of the RAM size
- Definition of the bus size that is used to access the RAM
- The write access has to be enabled for the RAM
- Definition of the timing (number of wait states for the write access to the RAM)

Use the **PER.Set/PER.view** commands for this setup.

Example SDRAM configuration on an s3c2410X (ARM920T):

Bus configuration after reset:

B:PER.view, /SpotLight							
ARM Core Registers							
Memory Controller							
BWSCON 00000000							
ST7	No UB/LB	WS7	Disabled	DW7	8-bit		
ST6	No UB/LB	WS6	Disabled	DW6	8-bit		
ST5	No UB/LB	WS5	Disabled	DW5	8-bit		
ST4	No UB/LB	WS4	Disabled	DW4	8-bit		
ST3	No UB/LB	WS3	Disabled	DW3	8-bit		
ST2	No UB/LB	WS2	Disabled	DW2	8-bit		
ST1	No UB/LB	WS1	Disabled	DW1	8-bit		
DW0	Reserved						
BANK CONTROL REGISTER(BANKCONN:nGCS0-nGCS5)							
BANKCON0 00000700							
TACS	0 clock	TCOS	0 clock	TACC	14 clocks		
TCOH	1 clock	TCAH	0 clock	TACP	2 clocks		
PMC	1 data						
BANKCON1 00000700							
TACS	0 clock	TCOS	0 clock	TACC	14 clocks		
TCOH	0 clock	TCAH	0 clock	TACP	2 clocks		
PMC	1 data						
BANKCON2 00000700							
TACS	0 clock	TCOS	0 clock	TACC	14 clocks		
TCOH	0 clock	TCAH	0 clock	TACP	2 clocks		
PMC	1 data						
BANKCON3 00000700							
TACS	0 clock	TCOS	0 clock	TACC	14 clocks		
TCOH	0 clock	TCAH	0 clock	TACP	2 clocks		
PMC	1 data						
BANKCON4 00000700							
TACS	0 clock	TCOS	0 clock	TACC	14 clocks		
TCOH	0 clock	TCAH	0 clock	TACP	2 clocks		
PMC	1 data						
BANKCON5 00000700							
TACS	0 clock	TCOS	0 clock	TACC	14 clocks		
TCOH	0 clock	TCAH	0 clock	TACP	2 clocks		
PMC	1 data						
BANKCON6 00018008							
MT	Sync DRAM	TRCD	4 clocks	SCAN	8-bit		
BANKCON7 00018008							
MT	Sync DRAM	TRCD	4 clocks	SCAN	8-bit		
REFRESH CONTROL REGISTER							
REFRESH 00AC0000	REFEN	Enabled	TREFMD	Auto		TRP	4 clocks
TSRC	7 clocks		REFCNT	0000			
BANKSIZE REGISTER							
BANKSIZE 00000002	BURST_EN	Disabled	SCKE_EN	Disabled		SCLK_EN	Disabled
BK76MAP	128MB/128MB						
SDRAM MODE REGISTER SET REGISTER							
MRSRB6 00000030	WBL	Burst	TM	Test mode		CL	3 clocks
	BT	Sequential	BL	1			
MRSRB7 00000030	WBL	Burst	TM	Test mode		CL	3 clocks
	BT	Sequential	BL	1			

```

PER.Set 0x48000000 %Long 0x2222D222
PER.Set 0x48000004 %Long 0x00000700
PER.Set 0x48000008 %Long 0x00007fff
PER.Set 0x4800000C %Long 0x00000700
PER.Set 0x48000010 %Long 0x00001F4C
PER.Set 0x48000014 %Long 0x00000700
PER.Set 0x48000018 %Long 0x00000700
PER.Set 0x4800001C %Long 0x00018005
PER.Set 0x48000020 %Long 0x00018005
PER.Set 0x48000024 %Long 0x008e0459
PER.Set 0x48000028 %Long 0x00000032
PER.Set 0x4800002C %Long 0x00000030
PER.Set 0x48000030 %Long 0x00000030
PER.Set 0x53000030 %Long 0x00000000

```


Correct bus configuration for SDRAM usage:

ARM Core Registers							
Memory Controller							
BWSCON	2222D220	ST7	No UB/LB	WS7	Disabled	DW7	32-bit
		ST6	No UB/LB	WS6	Disabled	DW6	32-bit
		ST5	No UB/LB	WS5	Disabled	DW5	32-bit
		ST4	No UB/LB	WS4	Disabled	DW4	32-bit
		ST3	UB/LB	WS3	Enabled	DW3	16-bit
		ST2	No UB/LB	WS2	Disabled	DW2	32-bit
		ST1	No UB/LB	WS1	Disabled	DW1	32-bit
		DW0	Reserved				
BANK CONTROL REGISTER (BANKCONN: nGCS0-nGCS5)							
BANKCON0	00000700	TACS	0 clock	TCOS	0 clock	TACC	14 clocks
		TCOH	0 clock	TCAH	0 clock	TACP	2 clocks
		PMC	1 data				
BANKCON1	00007FF0	TACS	4 clocks	TCOS	4 clocks	TACC	14 clocks
		TCOH	4 clocks	TCAH	4 clocks	TACP	2 clocks
		PMC	1 data				
BANKCON2	00000700	TACS	0 clock	TCOS	0 clock	TACC	14 clocks
		TCOH	0 clock	TCAH	0 clock	TACP	2 clocks
		PMC	1 data				
BANKCON3	00001F4C	TACS	0 clock	TCOS	4 clocks	TACC	14 clocks
		TCOH	1 clock	TCAH	0 clock	TACP	6 clocks
		PMC					
BANKCON4	00000700	TACS	0 clock	TCOS	0 clock	TACC	14 clocks
		TCOH	0 clock	TCAH	0 clock	TACP	2 clocks
		PMC	1 data				
BANKCON5	00000700	TACS	0 clock	TCOS	0 clock	TACC	14 clocks
		TCOH	0 clock	TCAH	0 clock	TACP	2 clocks
		PMC	1 data				
BANKCON6	00018005	MT	Sync DRAM	TRCD	3 clocks	SCAN	8-bit
BANKCON7	00018005	MT	Sync DRAM	TRCD	3 clocks	SCAN	8-bit
REFRESH CONTROL REGISTER							
REFRESH	008E0459	REFEN	Enabled	TREFMD	Auto	TRP	2 clocks
		TSRC	7 clocks	REFCNT	0459		
BANKSIZE REGISTER							
BANKSIZE	00000032	BURST_EN	Disabled	SCKE_EN	Enabled	SCLK_EN	Enabled
		BK76MAP	128MB/128MB				
SDRAM MODE REGISTER SET REGISTER							
MRSRB6	00000030	WBL	Burst	TM	Test mode	CL	3 clocks
		BT	Sequential	BL	1		
MRSRB7	00000030	WBL	Burst	TM	Test mode	CL	3 clocks
		BT	Sequential	BL	1		


3. Disable internal and external watchdog

Example (ARM920T):

```
; Display "Watchdog Timer" configuration registers, highlight changes  
PER.view , "Watchdog Timer" /SpotLight
```



```
; Disable Watchdog timer by configuring Watchdog Timer Control Register  
; (WTCN)  
PER.Set.simple 0x53000000 %Long 0x0
```




The following commands are useful, if a generic NAND flash controller is used to program a flash. For details refer to “**NAND FLASH Programming User’s Guide**” (nandflash.pdf).

FLASHFILE.RESet	Reset NAND flash programming to default.
FLASHFILE.CONFIG <cmd_reg> <addr_reg> <io_reg>	Inform TRACE32 PowerView on the NAND flash registers
FLASHFILE.TARGET <code_range> <data_range> <file>	Inform TRACE32 PowerView on all details about flash programming algorithm.
FLASHFILE.Erase <range>	Erase NAND flash.
FLASHFILE.LOAD <file> <address>	Program binary file to NAND flash.

More details on the **FLASHFILE.TARGET** command:

The name of the flash programming algorithm depends on the NAND flash to be programmed (e.g. nand5608.bin for the K9F5608 NAND flash from Samsung).



K8P6415	SAMSUNG	AM29LV100	
K8Q2815	SAMSUNG	AM29LV100	
K8S2815	SAMSUNG	AM29LV100	
K8S3215	SAMSUNG	AM29LV100	
K8S6115	SAMSUNG	AM29LV100	
K8S6415	SAMSUNG	AM29LV100	
K9F1208	SAMSUNG	NAND1208	NAND Flash
K9F1G08	SAMSUNG	NAND1G08	NAND Flash
K9F2G08	SAMSUNG	NAND2G08	NAND Flash
K9F4G08	SAMSUNG	NAND2G08	NAND Flash
K9F5608	SAMSUNG	NAND5608	NAND Flash
K9F5616	SAMSUNG	NAND5616	NAND Flash
K9F8G08	SAMSUNG	NAND8G08	NAND Flash, 4KB Page
K9G8G08	SAMSUNG	NAND2G08	NAND Flash, 2KB Page
K9GA08U0D	SAMSUNG	NANDLG08XS	NAND Flash, 4K/218B
K9HBG08U	SAMSUNG	NANDLG08	NAND Flash
K9HC08U0	SAMSUNG	NANDLG08	NAND Flash
K9HC08U1M	SAMSUNG	NANDLG08XS	NAND Flash, 4K/218B
K9K1208X0C	SAMSUNG	NAND1208L	NAND Flash

Its location in the TRACE32 demo folder is defined by the number of data I/O pins between the NAND flash controller and the flash device. E.g. is there are 8 data I/O pins between the NAND flash controller and the flash device the algorithm can be found in:

~~/demo/<architecture>/flash/byte/<nand_flash_code>.bin

This flash programming algorithm is downloaded to a target RAM when flash programming is performed. Therefore TRACE32 PowerView needs to be informed about an appropriate RAM location by the `<code_range>` parameter of the **FLASH.TARGET** program

required size for the code is `size_of(file) + 32 byte`

FLASH algorithm	Memory mapping for the <code><code_range></code>
32 byte	

The parameter `<data_range>` specifies the RAM location for the data, especially

- the `<data_buffer_size>` for the programming data. Recommended buffer size is 4 KByte, smaller buffer sizes are also possible. The max. buffer size is 16 KByte
- the argument buffer for the communication between TRACE32 PowerView and the programming algorithm
- the stack

```
<data_buffer_size> =  
size_of(<data_range>) - 64 byte argument buffer - 256 byte stack
```

64 byte argument buffer	Memory mapping for the <code><data_range></code>
Data buffer for data transfer between TRACE32 and NAND FLASH algorithm <code><buffer_size></code> calculated as described above	
256 byte stack	

Example


```
FLASHFILE.RESET  
FLASHFILE.CONFIG 0x4E000004 0x4E000008 0x4E00000C  
FLASHFILE.TARGET 0x30000000++0x1FFF 0x30002000++0x3FFF  
~~/demo/arm/flash/byte/nand5608.bin  
FLASHFILE.Erase 0x0--0x1FFF  
FLASHFILE.LOAD boot.bin 0x0
```

eMMC Flash Programming

Folder and file name convention:

~~/demo/<architecture>/flash/<cpu_name>-emmc.cmm

Get <cpu_name> from the CPU column of the list of “**Supported NAND/Serial Flash Controller**” on the Lauterbach home page (www.lauterbach.com).



The screenshot shows a Firefox browser window with the Lauterbach website loaded. The URL in the address bar is <http://www.lauterbach.com/frames.html?home.html>. The page title is "TRACE32® Supported NAND/SERIAL FL...". The left sidebar has navigation links for Site Search, Chip Search, Products, Features, Tool Chain (with "Supported NAND/Serial Flash Controller" checked), Support, and a link to the list of supported controllers. The main content area is titled "Marvell, Inc." and contains a table with columns: CPU, CONTROLLER, and COMMENT. The table lists various controllers, with the row for "PXA920" highlighted in red. The table data is as follows:

CPU	CONTROLLER	COMMENT
88F5082	generic	NAND
88F5181	generic	NAND
88F5281	generic	NAND
88F6192	generic	NAND
88F6192	marvell	SPI
88F6281	generic	NAND
88F6281	marvell	SPI
MV76100	generic	NAND
MV76100	marvell	SPI
MV78100	generic	NAND
MV78100	marvell	SPI
MV78200	generic	NAND
MV78200	marvell	SPI
PXA3XX	pxa	NAND
PXA920	pxa	eMMC
PXA978	pxa	eMMC/SD/MMC
PXA978	pxa	eMMC/SD/MMC

Name of flash programming script here

~~/demo/arm/flash/**pxa920-emmc.cmm**

Detail on eMMC flash programming can be found in “**eMMC FLASH Programming User’s Guide**” (emmcflash.pdf).

Establish the Communication

It is required to establish the communication between the debugger and the core by **SYStem.Up**. This advise the processor/chip to reset before the communication is established (details can be found on “[Establish your Debug Session](#)”, page 5).

Load the Debug Symbols


```
; load debug symbols for boot loader and second stage boot loader
; address of boot loader:           0x0--0x3fff
; address of second stage boot loader: 0x33f80000++0x3ffff
; symbol mapping has to be accordingly
Data.LOAD.Elf boot.elf /NoCODE
```

If you want to debug only the second stage boot loader you can set an on-chip breakpoint to its start address:

```
Break.Set start_boot2 /Onchip
```

Debug Scenario 3

The application (and/or the operating system) under debug are running out of RAM and a ready-to-run boot loader configures the target system and especially the RAM for this debug scenario.



*Considering the circumstance that a process has to be started manually e.g. via a TERMINAL window

Run the Boot Loader

The most important command to run the boot loader are:

Go	Start program execution
Break	Stop program execution
WAIT <time>	Wait the defined time (for scripts only)
Go <address>	Run the program until the specified address is reached
Break.Set <address>	Set a breakpoint to the specified address

Example 1

```
Go ; start the program execution
Break ; stop the program execution after
; the target initialization is done
```

Example 2

```
; ...
; script example
Go ; start the program execution
WAIT 0.5s ; wait 500. ms
Break ; stop the program execution
; ...
; continue with other setups
```

Example 3

```
Go 0xc0001000 ; run the program until the
; complete setup is done
```

Example 4

```
Break.Set 0xc0001000 ; set a breakpoint to the end
; of the boot loader
Go ; start the program execution
WAIT !STATE.RUN() ; wait until the program stops
; at the end of the boot loader
; ...
; continue with other setups
```

Load Application (and/or OS) Code and Debug Symbols

If the boot loader does not load the application (and/or OS) you can perform the loading by the following command:

```
Data.LOAD.Elf my_app.elf
```

Load Debug Symbols only

If the boot loader loads the application (and/or OS) code to RAM you need only to load the debug symbols.

```
Data.LOAD.Elf my_app.elf /NoCODE
```

Configure the TRACE32 OS Awareness

Refer to [“The TASK.CONFIG Command”](#), page 8 for details.


Complete Setup Example

Example for a boot loader that loads the application to RAM.

```
SYStem.CPU
SYStem.Up
Go                      ; start the program execution
WAIT 0.5s                ; wait 500. ms
Break                   ; stop the program execution
Data.LOAD.Elf my_app /NoCODE
```

Debug Scenario 4

The application (and the operating system) under debug are running out of RAM. The target configuration, especially the RAM configuration has to be done by TRACE32 commands, because there is no ready-to-run boot loader.



*Considering the circumstance that a process has to be started manually e.g. via a TERMINAL window

Write a Script to Configure the Target

A minimum target configuration has to configure all used memories and the serial interface.

Use the **PER.Set/PER.view** commands for this setup.

Load Application (and/or OS) Code and Debug Symbols

```
Data.LOAD.Elf my_app.elf
```

Configure the TRACE32 OS Awareness

Refer to “[The TASK.CONFIG Command](#)”, page 8 for details.

Start-Up Scripts

It is strongly recommended to summarize the commands used to set up the debug environment in a start-up script. For this purpose, the script language PRACTICE is provided.

The standard extension for a script file is .cmm.

Write a Start-Up Script

The debugger provides an PRACTICE script editor, that allows to write, to run and to debug a start-up script. The editor window provides syntax highlighting, configurable auto-indentation as well as multiple undo and redo.

PEDIT <file>

Open <file> with the script editor

```
PEDIT my_startup.cmm
```

The debugger provides two commands, that allow you to convert debugger configuration information to a script.

STOre <file> [<item>]

Generate a script that allows to reproduce the current settings

ClipSTOre [<item>]

Generate a command list in the clip-text that allows to reproduce the current settings

```
STOre system_settings.cmm SYSTEM
```

; Generate a script that allows you
; to reproduce the settings of the
; SYSTEM window at any time

```
PEDIT system_settings.cmm
```

; Open the file system_settings.cmm

```
ClipSTOre SYSTEM
```

; Generate a command list that
; allows you to reproduce the
; settings of the SYSTEM window
; at any time
; The generated command list can be
; pasted in any editor

Run a Start-up Script

You can run a PRACTICE script from the TRACE32 PowerView interface by selecting the menu “**File**” > “**Run Script...**”. This action corresponds to using the TRACE32 command **DO** with the script name as parameter.

DO <file>	run PRACTICE script
------------------------	---------------------

Example:

```
DO my_startup.cmm
```

Alternatively, you can select the “**File**” > “**ChangeDir and Run Script...**”. The difference here is that TRACE32 PowerView will change the current working directory to the directory of the selected file before running the script.

ChDir.DO <file>	Change directory and run script
------------------------------	---------------------------------

Example:

```
ChDir.DO C:\my_scripts\my_startup.cmm
```

Automated Start-up Scripts

When a TRACE32 instance starts, the PRACTICE script **autostart.cmm** is executed, which then calls the following scripts:

- **system-settings.cmm** (from the TRACE32 system directory, usually C:\T32)
- **user-settings.cmm** (from the user settings directory: on Windows %APPDATA%\TRACE32 or ~/.trace32 otherwise)
- **work-settings.cmm** (from the current working directory)

With the command line option **-s <startup_script>** you can specify an additional PRACTICE script (*.cmm) which is automatically started afterwards.

Example:

```
C:\T32\t32arm.exe -s C:\my_scripts\start.cmm
```