

UEFI Awareness Manual TianoCore

TRACE32 Online Help

TRACE32 Directory

TRACE32 Index


TRACE32 Documents	
UEFI Awareness Manuals	
UEFI Awareness Manual TianoCore	1
History	4
Overview	4
Brief Overview of Documents for New Users	5
Supported Versions	5
Configuration	6
ARM 32-Bit	6
ARM 64-Bit	7
Hooks & Internals in TianoCore	7
Features	8
Display of UEFI Resources	8
Symbol Autoloader	9
Autoloader Configuration	9
Scan the UEFI Module Table	10
Display the Autoloader Table	11
TianoCore Specific Menu	12
Debugging UEFI Phases of TianoCore	13
Debugging from Reset Vector	13
SEC Phase	13
PEI Phase	13
DXE Phase	13
BDS Phase	14
TianoCore Commands	15
EXTension.ConfigTab	Display DXE configuration table 15
EXTension.DXEDRiVer	Display loaded DXE drivers 15
EXTension.DXEModule	Display DXE modules 16
EXTension.FV	Display firmware volumes 17
EXTension.HOB	Display HOBs 17
EXTension.Option	Set awareness options 18
EXTension.PEIModule	Display PEI modules 19
EXTension.PEISvc	Display PEI services 19

EXTension.POST	Display POST code	20
EXTension.PROTOcol	Display installed protocols	20
TianoCore PRACTICE Functions		21
EXT.DXEDRV.ENTRY()	Entry address for DXE driver	21
EXT.DXEDRV.MAGIC()	Magic of DXE driver	21
EXT.DXEDRV.PATH()	Build path for DXE driver	21
EXT.DXEFILE.PATH()	Build path for DXE module	22
EXT.PEIM.ENTRY()	Entry address for PEI module	22
EXT.PEIM.MAGIC()	Magic of PEI module	22
EXT.PEIM.PATH()	Build path for PEI module	22

History

28-Aug-18 The title of the manual was changed from “UEFI <x> Debugger” to “UEFI Awareness Manual <x>”.

Overview



The UEFI Awareness for TianoCore contains special extensions to the TRACE32 Debugger. This chapter describes the additional features, such as additional commands and debugging approaches.

Brief Overview of Documents for New Users

Architecture-independent information:

- **“Training Basic Debugging”** (training_debugger.pdf): Get familiar with the basic features of a TRACE32 debugger.
- **“T32Start”** (app_t32start.pdf): T32Start assists you in starting TRACE32 PowerView instances for different configurations of the debugger. T32Start is only available for Windows.
- **“General Commands”** (general_ref_<x>.pdf): Alphabetic list of debug commands.

Architecture-specific information:

- **“Processor Architecture Manuals”**: These manuals describe commands that are specific for the processor architecture supported by your Debug Cable. To access the manual for your processor architecture, proceed as follows:
 - Choose **Help** menu > **Processor Architecture Manual**.
- **“OS Awareness Manuals”** (rtos_<os>.pdf): TRACE32 PowerView can be extended for operating system-aware debugging. The appropriate OS Awareness manual informs you how to enable the OS-aware debugging.
- **“UEFI Awareness Manuals”** (uefi_<x>.pdf): TRACE32 PowerView can be extended for UEFI-aware debugging. The appropriate UEFI manual informs you how to enable the UEFI-aware debugging.

Supported Versions

Currently TianoCore is supported for the following versions:

- TianoCore on ARM32 and ARM64 architectures

Configuration

The UEFI Awareness for TianoCore is configured by loading an extension definition file called “tiano.t32” from the demo directory with the **EXTension.CONFIG** command. The command takes two parameters that specify the memory base address and size of the UEFI package. See the file `<board>Pkg/<board>Pkg.dsc` of your UEFI implementation. “PcdSystemMemoryBase” resp. “PcdSystemMemorySize” are the needed values.

Additionally, load the “tiano.men” menu file (see [“TianoCore specific Menu”](#)) and configure the [Symbol Autoloader](#).

ARM 32-Bit

A full configuration for ARM **32-bit** can look like this (the path prefix `~~` expands to the system directory of TRACE32.):

```
; Specify the memory base address and size,
; see <board>Pkg/<board>Pkg.dsc:
; PcdSystemMemoryBase = 0x80000000
; PcdSystemMemorySize = 0x08000000

; Load the TianoCore Awareness:
EXTension.CONFIG ~~<code>/demo/arm/bootloader/uefi/tiano/tiano.t32 \
    0x80000000 0x08000000

; In a TrustZone/Hypervisor environment, you may need to
; specify the access class where the UEFI BIOS runs.
; E.g. if TianoCore runs in hypervisor zone:
EXTension.ACCESS H:

; Load the additional menu:
MENU.ReProgram ~~<code>/demo/arm/bootloader/uefi/tiano/tiano.men

; Configure symbol autoloader:
sYmbol.AutoLOAD.CHECKUEFI "do ~~<code>/demo/arm/bootloader/uefi/tiano/autoload "
```

See also the example scripts in `~~<code>/demo/arm/bootloader/uefi/tiano`

A full configuration for ARM **64-bit** can look like this (the path prefix `~~` expands to the system directory of TRACE32.):

```
; Specify the memory base address and size,
; see <board>Pkg/<board>Pkg.dsc:
; PcdSystemMemoryBase = 0x80000000
; PcdSystemMemorySize = 0x08000000

; Load the TianoCore Awareness:
EXTension.CONFIG ~~<demo>/arm/bootloader/uefi/tiano/tiano.t32 \
    0x80000000 0x08000000

; In a TrustZone/Hypervisor environment, you may need to
; specify the access class where the UEFI BIOS runs.
; E.g. if TianoCore runs in hypervisor zone:
EXTension.ACCESS H:

; Load the additional menu:
MENU.ReProgram ~~<demo>/arm/bootloader/uefi/tiano/tiano.men

; Configure symbol autoloader:
sYmbol.AutoLOAD.CHECKUEFI "do ~~<demo>/arm/bootloader/uefi/tiano/autoload "
```

See also the example scripts in `~~<demo>/arm/bootloader/uefi/tiano`

Hooks & Internals in TianoCore

IMPORTANT:

When using GCC on ARM:

The ELF->COFF converter (GenFw) may spoil the debug information when using several text/data sections (check with `"-v"`). The linker must combine all sections into one text section and one data section. The `edk2/BaseTools/Scripts` directory contains a suitable linker script (`GccBase.lds` or previously `gcc4.4-ld-script`). Please ensure that this script is used when linking a module, e.g. by adding it to the linker flags in the `edk2/BaseTools/Conf/tools_def.template`:

```
--script=$(EDK_TOOLS_PATH)/Scripts/GccBase.lds
```

Features

The UEFI Awareness for TianoCore supports the following features.

Display of UEFI Resources

The extension defines new commands to display various UEFI resources. Information on the following UEFI components can be displayed:

PEI phase:

EXTension.FV PEI	PEI firmware volumes
EXTension.PEIModule	PEI modules in FVs
EXTension.HOB PEI	PEI HOBs

DXE phase:

EXTension.FV DXE	DXE firmware volumes
EXTension.DXEModule	DXE modules in FVs
EXTension.DXEDRiVer	Loaded DXE drivers
EXTension.HOB DXE	DXE HOBs
EXTension.PROTOcol DXE	Installed DXE protocols
EXTension.ConfigTab	DXE configuration table

For a description of the commands, refer to chapter “**TianoCore Commands**”.

If you want to display the UEFI objects “On The Fly” while the target is running, you need to have access to memory while the target is running. Enable **SYStem.MemAccess** or **SYStem.CpuAccess** (CPU dependent), but be aware of the limitations (no cache reading, real-time intrusion).

Symbol Autoloader

The UEFI code is provided by the boot FLASH, but debugging becomes more comfortable when debug symbols are available.

TRACE32 contains an “Autoloader”, which can be set up for automatic loading of symbol files. The Autoloader maintains a list of address ranges, corresponding UEFI components and the appropriate load command. Whenever the user accesses an address within an address range known to the Autoloader, the debugger invokes the load associated command. The command is usually a call to a PRACTICE script, that handles loading the symbol file.

The TRACE32 Autoloader has to be set up. This includes the following steps:

1. Autoloader configuration.
2. Scan of the UEFI module table to the Autoloader table.
3. Display of the Autoloader table.

Autoloader Configuration

The command **sYmbol.AutoLOAD.CHECKUEFI** *<load_command>* specifies the command that is automatically used by the Autoloader to load the symbol information. Typically the script `autoload.cmm` provided by Lauterbach is called.

The command **sYmbol.AutoLOAD.CHECKUEFI** implicitly also defines the parameters that TRACE32 uses internally for the Autoloader.

The script is provided in the TRACE32 demo directory:

- 32-bit: `~/demo/arm/bootloader/uefi/tiano/autoload.cmm`.
- 64-bit: `~/demo/arm/bootloader/uefi/tiano/autoload.cmm`.

Example:

```
; Configure symbol Autoloader for 32-bit TianoCore
sYmbol.AutoLOAD.CHECKUEFI "DO ~/demo/arm/bootloader/uefi/tiano/autoload.cmm"
```

Scan the UEFI Module Table

When the Autoloader is configured, the command **sYmbol.AutoLOAD.CHECK** can be used to scan the UEFI module table into the Autoloader table and to activate the Autoloader.

Since the UEFI module table is updated by UEFI a re-scan might be necessary.

The point of time at which the UEFI module table is re-scanned can be set very flexibly:

sYmbol.AutoLOAD.CHECK [ON | OFF | ONGO]

The default setting is **sYmbol.AutoLOAD CHECK OFF**. With this setting TRACE32 re-scans the UEFI module table only on request by using the **sYmbol.AutoLOAD.CHECK** command.

With **sYmbol.AutoLOAD.CHECK ON**, TRACE32 re-scans the UEFI module table after every single step and whenever the program execution is stopped. This significantly slows down the speed of TRACE32.

With **sYmbol.AutoLOAD.CHECK ONGO**, TRACE32 re-scans the UEFI module table whenever the program execution is stopped.


NOTE:

The Autoloader can load the symbol information for the SecCore, the PeiCore, all PEI modules and the DXE core as soon as the memory mode (e.g. 32-bit protected mode) used by UEFI is activated.


The Autoloader can only load symbol information for DXE modules that are already loaded.

Display the Autoloader Table

The command “**sSymbol.AutoLOAD.List**” shows a list of all known address ranges/components and their symbol load commands.



Module address range Module name Module status
dyn: (no meaning)
load: symbols for module are loaded



Load command Parameters for load command

Autoload context menu	
Touch	Advise TRACE32 to load the symbols for the selected module now.
Set	Mark selected module as loaded.
Clear	Delete symbols for the selected module in TRACE32.

TianoCore Specific Menu

The menu file “tiano.men” contains a menu with TianoCore specific menu items. Load this menu with the **MENU.ReProgram** command.

You will find a new menu called **TianoCore**.

- Use the **PEI** submenu to launch windows displaying PEI specific resources.
- Use the **DXE** submenu to launch windows displaying DXE specific resources.
- Use the **Symbol Autoloader** submenu to configure the symbol autoloader. See also chapter “**Symbol Autoloader**”.
 - **List Components** opens a **sYmbol.AutoLOAD.List** window showing all components currently active in the autoloader.
 - **Check Now!** performs a **sYmbol.AutoLOAD.CHECK** and reloads the autoloader list.
 - **Set Loader Script** allows you to specify the script that is called when a symbol file load is required. You may also set the automatic autoloader check.

Debugging UEFI Phases of TianoCore

UEFI runs in several “phases”. It starts with the “Security” (SEC) phase which immediately switches to the “Pre-EFI Initialization Environment” (PEI) phase. After this phase ended, control is given to the “Driver Execution Environment” (DXE) phase. Shortly, before the OS is booted, the “Boot Device Selection” (BDS) phase is running.

Each of this phases needs a different debugging environment. See below for a detailed description of each phase.

Debugging from Reset Vector

TRACE32 is a JTAG-based debugging tool and, as such, allows the user to start debugging their system right from the reset vector. It is possible to walk through the very first steps of the start-up to detect FLASH problems or faulty reset behavior.

Shortly after reset, the system switches into the SEC phase.

SEC Phase

TianoCore itself does not provide an SEC phase. It is up to the developer to implement a custom SEC phase, and as such out of the scope of this document

PEI Phase

If you want to debug the PEI phase right from the start, halt the system at the reset vector. Then load the symbols of your PEI core module with the symbol autoloader, and go until the desired entry point, e.g:

```
sYmbol.AutoLOAD.CHECK  
sYmbol.AutoLOAD.Touch "ArmPlatformPrePiUniCore"  
Go PrePiMain
```

Inspect the PEI resources with the menu items in the “PEI” submenu.

DXE Phase

After PEI phase completed, it hands off control to the DXE core. To debug the DxeCore from start, load the symbols of “DxeCore” just before PEI jumps into the DxeCore and set a breakpoint at “DxeMain”. DxeMain then starts the DXE dispatcher.

For debugging a DXE driver from its entry point, a special script “go_dxedrv” is available in the ~/demo directory. Call this script with the name of the DXE module *before* the module is started. E.g. to debug the DXE driver “Metronome”:

```
DO go_dxedrv Metronome
```

This script sets a breakpoint in the DXE core code and waits until the specified DXE module is loaded. Then it sets a breakpoint onto the module entry point and halts there. You can then start debugging the module from scratch.

BDS Phase


TianoCore implements the BDS phase as DXE driver. To debug the BDS phase, debug the “ArmPlatformBds” module like shown in “[DXE Phase](#)”.

EXTension.ConfigTab

Display DXE configuration table

Format:EXTension.ConfigTab

Displays the DXE configuration table.




EXTension.DXEDRiVer

Display loaded DXE drivers

Format:EXTension.DXEDRiVer

Displays a table with all DXE drivers that DxeCore already loaded into the system.




You can sort the window to the entries of a column by clicking on the column header.

“magic” is a unique ID, used by the UEFI Awareness to identify a specific driver.

Format: EXTension.DXEModule

Displays a table with all DXE modules found in the system (firmware volumes or HOBs).



magic	name	baseaddr	entry	build	path
3FA65078	DxeCore	3FA65094	3FA652F4	e:\bldk\Build\CrownBayPlat	
3FA7C198	PcdDxe	3FA7C1BC	3FA7C41C	e:\bldk\Build\CrownBayPlat	
3FA81820	CpuIoDxe	3FA81854	3FA81AB4	e:\bldk\Build\CrownBayPlat	
3FA83478	CpuIo2Dxe	3FA834AC	3FA8370C	e:\bldk\Build\CrownBayPlat	
3FA84C10	ReportStatusCodeRoute	3FA84C44	3FA84EA4	e:\bldk\Build\CrownBayPlat	
3FA86F98	StatusCodeHandlerRunt	3FA86FDC	3FA8723C	e:\bldk\Build\CrownBayPlat	
3FA8E1C8	SectionExtractionDxe	3FA8E20C	3FA8E46C	e:\bldk\Build\CrownBayPlat	
3FA905E8	SecurityStubDxe	3FA9061C	3FA9087C	e:\bldk\Build\CrownBayPlat	
3FA92090	CpuArchDxe	3FA920C4	3FA92324	c:\src\Build\CrownBayPlatf	
3FA96590	CpuMpDxe	3FA96630	3FA96890	c:\src\Build\CrownBayPlatf	
3FAA2EB8	Metronome	3FAA2EEC	3FAA314C	e:\bldk\Build\CrownBayPlat	
3FAA41D0	BdsDxe	3FAA4238	3FAA4498	c:\src\Build\CrownBayPlatf	
3FAB1138	WatchdogTimer	3FAB117C	3FAB13DC	e:\bldk\Build\CrownBayPlat	
3FAB2488	RuntimeDxe	3FAB24BC	3FAB271C	e:\bldk\Build\CrownBayPlat	

You can sort the window to the entries of a column by clicking on the column header.


“magic” is a unique ID, used by the UEFI Awareness to identify a specific module.

The “magic” fields are mouse sensitive. Right-click on them to get a local menu. Double-clicking on them opens appropriate windows.

Format: **EXTension.FV** [PEI | DXE [<fv_address>]]

Displays a table with the firmware volumes of the PEI or DXE phase.

If an address of a firmware volume is specified, the command displays the contents of this FV.



“magic” is a unique ID used by the UEFI Debugger to identify a specific firmware volume or file.

The “magic” fields are mouse sensitive, double clicking on them opens appropriate windows. Right-clicking on them will show a context menu.


The debugger tries to detect the address of the boot firmware volume automatically. If this fails, specify the address of the boot FV manually with the **EXTension.Option BOOTFV** command.

EXTension.HOB

Display HOBs

Format: **EXTension.HOB** [PEI | DXE]

Displays a table with the hand off blocks of the PEI or DXE phase.



The “address” fields are mouse sensitive, double-clicking them opens appropriate windows. Right-clicking on them will show a context menu.

EXTension.Option

Set awareness options

Format:

EXTension.Option <option>

<option>:

BOOTFV <address>

PEIHOBS <address>

SYSTABLE <address>

UCODE <address>

Sets various options to the awareness.

- BOOTFV

Set the base address of the boot firmware volume.
- PEIHOBS

Set the base address of the HOB list in PEI phase.
- SYSTABLE


Set the base address of the EFI System Table
- UCODE

Set the base address of the microcode table.

Format:

EXTension.PEIModule

Displays a table with all PEI modules found in the system.



magic	name	type	baseaddr	entry	build_path
FFFC0088	PeiCore	boot	FFF8FF44	FFFC01A4	e:\bldk\Build\CrownBayP1
FFFC6A88	PcdPeim	boot	FFFC691C	FFFC6B7C	e:\bldk\Build\CrownBayP1
FFFC8DC0	StatusCodePei	boot	FFFC8C64	FFFC8EC4	e:\bldk\Build\CrownBayP1
FFFCADF0	PeiVariable	boot	FFFCAC9C	FFFCAEFC	e:\bldk\Build\CrownBayP1
FFFC2C8	CpuPei	boot	FFFC164	FFFC3C4	c:\src\Build\CrownBayPla
FFFC688	CapsulePei	boot	FFFC544	FFFC7A4	c:\src\Build\CrownBayPla
FFFD0790	MemoryInitPei	boot	FFFD0634	FFFD0894	c:\src\Build\CrownBayPla
FFFD13E0	SmnAccessPei	boot	FFFD129C	FFFD14FC	c:\src\Build\CrownBayPla
FFFD2668	PlatformPeim	boot	FFFD2538	FFFD2798	c:\src\Build\CrownBayPla
FFFD8688	DxeIpl	boot	FFFD8558	FFFD87B8	e:\bldk\Build\CrownBayP1
FFFD6B8	SecCore	boot	FFFD548	FFFD8BC8	c:\src\Build\CrownBayPla

You can sort the window to the entries of a column by clicking on the column header.


“magic” is a unique ID, used by the UEFI Awareness to identify a specific module.

The “magic” fields are mouse sensitive. Right-click on them to get a local menu. Double-clicking on them opens appropriate windows.

Format:

EXTension.PEISvc

Displays a table with all available PEI services.




service	address	label
install ppi	FFF40D06	PeiInstallPpi
reinstall ppi	FFF40D91	PeiReInstallPpi
locate ppi	FFF40C06	PeiLocatePpi
notify ppi	FFF40DF7	PeiNotifyPpi
get boot mode	FFF40B43	PeiGetBootMode
set boot mode	FFF40B63	PeiSetBootMode
get hob list	FFF40A2F	PeiGetHobList
create hob	FFF40A42	PeiCreateHob
ffs find next volume	FFF409CC	PeiFvFindNextVolume
ffs find next file	FFF409B5	PeiFfsFindNextFile
ffs find section data	FFF40943	PeiFfsFindSectionData
install pei memory	FFF406E3	PeiInstallPeiMemory
allocate pages	FFF40557	PeiAllocatePages
allocate pool	FFF40610	PeiAllocatePool
copy memory	FFF41510	CopyMem
set memory	FFF40638	PeiCoreSetMem
report status code	FFF40514	PeiReportStatusCode
reset system	FFF404E2	PeiCoreResetSystem
cpu io		
pci config		

Format:

EXTension.POST

(Only available on x86/x64 targets.)


Displays the Power-On Self-Test code.



Format:

EXTension.PROTOcol

Displays the list of installed DXE protocols.



There are special definitions for TianoCore specific PRACTICE functions.

EXT.DXEDRV.ENTRY()

Entry address for DXE driver

Syntax:

EXT.DXEDRV.ENTRY(<dxedrv_magic>)

Returns the entry address for the specified DXE driver.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

EXT.DXEDRV.MAGIC()

Magic of DXE driver

Syntax:

EXT.DXEDRV.MAGIC("<dxedrv_name>")

Returns the “magic” of the specified loaded DXE driver.

Parameter Type: [String](#) (*with quotation marks*).

Return Value Type: [Hex value](#).

EXT.DXEDRV.PATH()

Build path for DXE driver

Syntax:

EXT.DXEDRV.PATH(<dxedrv_magic>)

Returns the build path for the specified DXE driver.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [String](#).

Syntax: **EXT.DXEFILE.PATH(<dxem_magic>)**

Returns the build path for the specified DXE module.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [String](#).

Syntax: **EXT.PEIM.ENTRY(<peim_magic>)**

Returns the entry address for the specified PEI module.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

Syntax: **EXT.PEIM.MAGIC("<peim_name>")**

Returns the “magic” of the specified PEI module.

Parameter Type: [String](#) (*with quotation marks*).

Return Value Type: [Hex value](#).

Syntax: **EXT.PEIM.PATH(<peim_magic>)**

Returns the build path for the specified PEI module.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [String](#).