

General Function Reference

General Function Reference

TRACE32 Online Help

TRACE32 Directory

TRACE32 Index

TRACE32 Documents	
PRACTICE Script Language	
TRACE32 Functions	
General Function Reference	1
History	24
In This Document	26
How This Document is Organized	26
Difference between Functions and Commands in TRACE32	27
Purpose of Functions	28
Example 1: Return Status of the Target	28
Example 2: Return Status of a TRACE32 Tool	28
Example 3: Return the Version Number	28
Example 4: Convert a String	28
How to Use Functions	29
Example 1: In PRACTICE Scripts	29
Example 2: As Parameters in Commands	29
Example 3: Together with the Output Commands PRINT and Data.Print	30
Example 4: Address Function and Their Access Class Specifiers	30
Which Return Values of Functions can be Printed?	31
Related Documents	31
ACCESS Functions	32
In This Section	32
ACCESS.isGUEST()	TRUE if access class belongs to guest 32
ACCESS.isHYPERVISOR()	TRUE if access class belongs to hypervisor 33
ADDRESS Functions	34
In This Section	34
ADDRESS.ACCESS()	Access class as ordinal number 34
ADDRESS.ACCESS.CMP()	Compare access classes 34
ADDRESS.ACCESS.CMPSTRICT()	Compare access classes, strict 35
ADDRESS.EXPANDACCESS()	Fully qualified access class 35
ADDRESS.INSTR.LEN()	Length of instruction 36
ADDRESS.isDATA()	Check if memory class refers to data 36
ADDRESS.isGUEST()	TRUE if address is guest address 37

ADDRESS.isHYPERVISOR()	TRUE if address is hypervisor address	37
ADDRESS.isINTERMEDIATE()	Check if intermediate address	38
ADDRESS.isNONSECURE()	TRUE if non-secure (TrustZone) access	38
ADDRESS.isNONSECUREEX()	TRUE if non-secure access	39
ADDRESS.MACHINEID()	Extract machine ID	39
ADDRESS.MAU()	Minimal addressable unit size (MAU)	40
ADDRESS.OFFSET()	Address without class	41
ADDRESS.isONCHIP()	TRUE if on-chip address area	41
ADDRESS.isPHYSICAL()	TRUE if physical address	41
ADDRESS.isPROGRAM()	TRUE if program address	42
ADDRESS.isSECURE()	TRUE if secure (TrustZone) access	42
ADDRESS.isSECUREEX()	TRUE if secure access	43
ADDRESS.RANGE.BEGIN()	Lowest address value of address range	44
ADDRESS.RANGE.END()	Highest address value of address range	44
ADDRESS.RANGE.SIZE()	Size of address range	45
ADDRESS.SEGMENT()	Segment of an address	46
ADDRESS.STRACCESS()	Access class of an address	46
Analyzer Functions		47
In This Section		48
Analyzer()	Check if Analyzer command group is available	48
Analyzer.CONFIG.<powertrace>()	Check if specified PowerTrace connected	49
Analyzer.COUNTER.EVENT()	Get value of trigger program event counter	49
Analyzer.COUNTER.TIME()	Get value of trigger program time counter	50
Analyzer.DSEL()	For internal usage only	50
Analyzer.FIRST()	Get record number of first trace record	50
Analyzer.FLOW.ERRORS()	Get number of flow errors / hard errors	50
Analyzer.FLOW.FIFOFULL()	Get number of FIFO overflows	51
Analyzer.FOCUS.EYE()	Check quality of data eye	53
Analyzer.ISCHANNELUP()	Check if serial link is established	54
Analyzer.MAXSIZE()	Get max. size of trace buffer in records	55
Analyzer.MODE()	Get Analyzer recording mode	55
Analyzer.MODE.FLOW()	Check if Analyzer operates as flowtrace	55
Analyzer.PCIE.CONFIG()	Value of register field from PCIe configuration	56
Analyzer.PCIE.ISCONFIGURED()	TRUE if prerequisites are fulfilled	57
Analyzer.PCIE.Register()	Value of 32-bit register from PCIe configuration	57
Analyzer.PROBEREVISION()	Get revision of StarCore NEXUS probe	58
Analyzer.RECORDS()	Get number of used trace records	58
Analyzer.RECORD.ADDRESS()	Get address recorded in trace record	58
Analyzer.RECORD.DATA()	Get data recorded in trace record	59
Analyzer.RECORD.OFFSET()	Get address in trace record as number	59
Analyzer.RECORD.TIME()	Get timestamp of trace record	60
Analyzer.REF()	Get record number of reference record	61
Analyzer.SIZE()	Get current trace buffer size in records	61

Analyzer.STATE()	Get state of Analyzer	61
Analyzer.THRESHOLD()	Get threshold voltage of parallel preprocessor	62
Analyzer.TraceCONNECT()	Name of trace sink of the SoC	62
Analyzer.TRACK.RECORD()	Get record number matching search	63
Analyzer.TRIGGER.TIME()	Time of trigger point in trace	63
ARM Function		65
ARMARCHVERSION()	ARM architecture version of CPU	65
Advanced Register Trace (ART) Functions		66
In This Section		66
ART.FIRST()	Get record number of first trace record	66
ART.MAXSIZE()	Get max. size of trace buffer in records	67
ART.MODE()	Get ART recording mode	67
ART.RECORD.ADDRESS()	Get address recorded in trace record	67
ART.RECORD.OFFSET()	Get address in trace record as number	68
ART.RECORD.TIME()	Get timestamp of trace record	68
ART.RECORDS()	Get number of used trace records	68
ART.REF()	Get record number of reference record	68
ART.SIZE()	Get current trace buffer size in records	69
ART.STATE()	Get state of ART trace	69
ART.TRACK.RECORD()	Get record number matching search	69
AUTOFOCUS Functions		70
In This Section		70
AUTOFOCUS()	TRUE if AutoFocus preprocessor attached	70
AUTOFOCUS.OK()	TRUE if command execution successful	70
AUTOFOCUS.FREQUENCY()	Frequency of trace-port clock	70
AVX Functions		71
In This Section		71
AVX()	Content of AVX register	71
AVX512()	Content of AVX512 register	72
Break Functions		73
In This Section		73
Break.Alpha.EXIST()	TRUE if Alpha breakpoint exists	73
Break.Beta.EXIST()	TRUE if Beta breakpoint exist	73
Break.Charly.EXIST()	TRUE if Charly breakpoint exists	74
Break.Program.EXIST()	TRUE if enabled program breakpoint exists	74
Break.ReadWrite.EXIST()	TRUE if enabled data address breakpoint exists	74
BMC Functions (Benchmark Counter)		75
In This Section		75
BMC.CLOCK()	Frequency of core clock	75
BMC.COUNTER()	Value of a benchmark counter	75
BMC.COUNTER.BYNAME()	Value of a benchmark counter	76

BMC.COUNTER.CORE()	Value of a benchmark counter	76
BMC.COUNTER.BYNAME.CORE()	Value of a benchmark counter	77
BMC.OVERFLOW()	TRUE if benchmark counter overflow	77
BMC.OVERFLOW.BYNAME()	TRUE if benchmark counter overflow	77
BMC.OVERFLOW.CORE()	TRUE if benchmark counter overflow	78
BMC.OVERFLOW.BYNAME.CORE()	TRUE if benchmark counter overflow	78
Boundary Scan Description Language (BSDL) Functions		79
In This Section		79
BSDL.CHECK.BYPASS()	Chain bypass test	79
BSDL.CHECK.FLASHCONF()	Flash configuration test	79
BSDL.CHECK.IDCODE()	Chain IDCODE test	79
BSDL.GetDRBit()	Data register bit	80
BSDL.GetPortLevel()	Port level value	80
CABLE Functions		81
In This Section		81
CABLE.GalvanicISolation()	Cable has galvanic isolation	81
CABLE.GalvanicISolation.FIRMWARE()	Adapter firmware version	81
CABLE.GalvanicISolation.SERIAL()	Serial number of adapter	81
CABLE.NAME()	Name of debug cable	82
CABLE.SERIAL()	Serial number of debug cable	82
CABLE.TWOWIRE()	TRUE if two-wire debugging supported	82
CACHE Functions		83
In This Section		83
CACHE.DC.DIRTY()	Dirty-flag of L1 Data Cache Line	83
CACHE.DC.DIRTYMASK()	Dirty-flag mask of L1 Data Cache Line	84
CACHE.DC.LRU()	LRU information of L1 Data Cache Line	84
CACHE.DC.TAG()	Address Tag of L1 Data Cache Line	84
CACHE.DC.VALID()	Valid-flag of L1 Data Cache Line	85
CACHE.DC.VALIDMASK()	Valid-flag mask of L1 Data Cache Line	85
CACHE.IC.DIRTY()	Dirty-flag of L1 Unified Cache Line	86
CACHE.IC.DIRTYMASK()	Dirty-flag mask of L1 Unified Cache Line	86
CACHE.IC.LRU()	LRU information of L1 Instruction Cache Line	86
CACHE.IC.TAG()	Address Tag of L1 Instruction Cache Line	87
CACHE.IC.VALID()	Valid-flag of L1 Instruction Cache Line	87
CACHE.IC.VALIDMASK()	Valid-flag mask of L1 Instruction Cache Line	87
CACHE.L2.DIRTY()	Dirty-flag of L2 Cache Line	88
CACHE.L2.DIRTYMASK()	Dirty-flag mask of L2 Cache Line	88
CACHE.L2.LRU()	LRU information of L2 Cache Line	88
CACHE.L2.SHARED()	Shared-flag of L2 Cache Line	89
CACHE.L2.SHAREDMASK()	Shared-flag mask of L2 Cache Line	89
CACHE.L2.TAG()	Address Tag of L2 Cache Line	89
CACHE.L2.VALID()	Valid-flag of L2 Cache Line	90

CACHE.L2.VALIDMASK()	Valid-flag mask of L2 Cache Line	90
CACHE.L3.DIRTY()	Dirty-flag of L3 Cache Line	90
CACHE.L3.DIRTYMASK()	Dirty-flag of L3 Cache Line	91
CACHE.L3.LRU()	LRU information of L3 Cache Line	91
CACHE.L3.TAG()	Address Tag of L3 Cache Line	91
CACHE.L3.VALID()	Valid-flag of L3 Cache Line	92
CACHE.L3.VALIDMASK()	Valid-flag mask of L3 Cache Line	92
CAnalyzer Functions		93
In This Section		93
CAnalyzer()	Check if CAnalyzer command group is available	94
CAnalyzer.BOTHCables()	TRUE if both debug cables are plugged	94
CAnalyzer.CableTYPE()	Type of adapter	94
CAnalyzer.DebugCable()	CombiProbe whisker cable is A or B	95
CAnalyzer.FEATURE()	Query features of CAnalyzer hardware	95
CAnalyzer.FIRST()	Get record number of first trace record	97
CAnalyzer.MAXSIZE()	Get max. size of trace buffer in records	97
CAnalyzer.PIN()	Status of trace pins	98
CAnalyzer.RECORD.ADDRESS()	Get address recorded in trace record	98
CAnalyzer.RECORD.DATA()	Get data recorded in trace record	98
CAnalyzer.RECORD.OFFSET()	Get address in trace record as number	99
CAnalyzer.RECORD.TIME()	Get timestamp of trace record	99
CAnalyzer.RECORDS()	Get number of used trace records	99
CAnalyzer.REF()	Get record number of reference record	99
CAnalyzer.SIZE()	Get current trace buffer size in records	100
CAnalyzer.STATE()	Get state of Compact Analyzer	100
CAnalyzer.TraceCLOCK()	Get trace port frequency	101
CAnalyzer.TraceCONNECT()	Name of trace sink of the SoC	102
CAnalyzer.TracePort()	CombiProbe whisker cable is A or B	102
CAnalyzer.TRACK.RECORD()	Get record number matching search	102
CERBEURS Functions		103
CERBERUS.IOINFO()	IOINFO of Cerberus module	103
CERBERUS.IOINFO.IFLCK()	TRUE if IF_LCK bit in Cerberus INONFO set	103
CHIP Functions		104
CHIP.EmulationDevice()	TRUE if emulation device	104
CHIP.STEPping()	Major silicon step of an TriCore AURIX device	104
CIProbe Functions (Analog Probe for CombiProbe or μTrace)		105
In This Section		105
CIProbe()	TRUE if Compact Analyzer hardware	105
CIProbe.ADC.ENABLE()	TRUE if channel is enabled	105
CIProbe.ADC.SHUNT()	Get shunt-resistor value	105
CIProbe.MAXSIZE()	Get max. size of trace buffer in records	106
CIProbe.RECORDS()	Get number of used trace records	106

CIProbe.SIZE()	Get current trace buffer size in records	106
CIProbe.STATE()	Get state of Compact Analyzer for CIProbe	107
CIProbe.TRACK.RECORD()	Get record number matching search	107
CMI Function		108
CMIBASE()	Base addresses of CMI modules	108
COMPONENT Functions		109
In This Section		109
COMPONENT.AVAILABLE()	TRUE if debug/trace peripherals available on CPU	109
COMPONENT.BASE()	Base address of debug/trace peripherals	110
COMPONENT.NAME()	User-defined name of debug/trace peripherals	110
COMPONENT.TYPE()	Type of debug/trace peripherals	111
COMPONENTNAME()	Name of debug/trace peripheral	111
COMPONENTNUMBER()	Number of valid debug/trace peripherals	112
CORE Functions		113
In This Section		113
CONFIGNUMBER()	Number of cores configured in TRACE32	114
CORE()	Get the selected core	114
CORE.ISACTIVE()	TRUE if this core is active	115
CORE.ISASSIGNED()	TRUE if physical core is assigned to debug session	116
CORE.LOGICALTOPHYSICAL()	This is the physical core number	117
CORE.NAMES()	Physical core names assigned to TRACE32	118
CORENAME()	Name of core within selected chip	119
CORE.NUMBER()	Number of logical cores	119
CORE.PHYSICALTOLOGICAL()	Logical core number of physical core	121
Count Functions		122
In This Section		122
Count.Frequency()	Frequency of last measurement	122
Count.LEVEL()	Level of frequency counter input	122
Count.Time()	Time of last measurement	123
Count.VALUE()	Samples of the Count.GO command	123
COVERAGE Functions		124
In This Section		124
COVERAGE.BDONE()	Byte count of all executed instructions	125
COVERAGE.IDLE()	TRUE if all trace data for code coverage are processed	125
COVERAGE.LOAD.KEY()	Key from last ACD file	126
COVERAGE.Percentage()	Percentage of code coverage	126
COVERAGE.SCOPE()	Degree of code coverage	126
COVERAGE.SourceMetric()	Active code coverage criterion	128
COVERAGE.TreeWalk()	Walk symbol tree	129
CPU Functions		130
In This Section		130

CPU.ADDRESS()	Start address of memory section	130
CPU.ADDRESS.PhysicalINDEX()	Section start address of given core	130
CPU.FEATURE()	TRUE if CPU feature exists	131
CPU.PINCOUNT()	For internal usage only	136
CPUBONDOUT()	Name of boundout processor	136
CPUCOREVERSION()	Core or architecture version of CPU	136
CPUDERIVATE()	Main part of processor name	137
CPUFAMILY()	Family name of processor	137
CPUHELP()	For internal usage only	137
CPUIS()	TRUE if search string matches processor name	138
CPUIS64BIT()	TRUE if 64-bit architecture	138
DAP Functions		139
In This Section		139
DAP.Available()	TRUE if debugging via DAP is supported	139
DAP.USER<x>()	Status of the DAP user pin	139
Data Functions		140
In This Section		140
Data.<value_width>()	Memory contents in default endianness	140
Data.<value_width>.<endianness>()	Mem. contents in specified byte order	143
Data.<value_width>.<access_width>()	Mem. contents in specified width	145
Data.AL.ERRORS()	Get number of errors detected by Data.AllocList	146
Data.Float()	Get floating point number	146
Data.STRing()	Get zero-terminated string	147
Data.STRingN()	Get zero-terminated string with a maximum length	148
Data.SUM()	Get checksum	148
Data.SWAP.<value_width>.<swap_width>()	Swap byte groups in word	149
Data.WSTRING()	Get zero-terminated wide string	150
Data.WSTRING.BigEndian()	Get big-endian wide string	150
Data.WSTRING.LittleEndian()	Get little-endian wide string	151
DEBUGGER Function		152
DEBUGGER.FEATURE()	Check debugger feature	152
DEBUGMODE Function		153
DEBUGMODE()	Current debug mode	153
DISASSEMBLE Function		154
DISASSEMBLE.ADDRESS()	Disassembled instruction at address	154
DONGLEID Function		155
DONGLEID()	Serial number of USB WibuKey	155
ELA Function (ARM Coresight Embedded Logic Analyzer)		156
ELABASE()	ELA base address	156
DPP Function (C166/ST10 only)		156
DPP()	Content of DPP register	156

EPOC Functions	157
In This Section	157
EPOC.DATAADDRESS()	Start address of data area (EPOC debugger) 157
EPOC.ENTRYPOINT()	Entry address of debug task 157
EPOC.TEXTADDRESS()	Start address of code area (EPOC debugger) 157
ERROR Functions (target-dependent)	158
ERROR.ADDRESS()	Address of last occurred memory access error 158
ETM Functions	159
In This Section	159
ETM()	TRUE if ETM trace is available 159
ETM.ADDRCOMP()	For internal usage only 160
ETM.ADDRCOMPTOTAL()	Number of ETM address comparator pair 160
ETM.COUNTERS()	Number of ETM counters 160
ETM.DATACOMP()	Number of ETM data comparators 160
ETM.EXTIN()	Number of internal ETM inputs 161
ETM.EXTOUT()	Number of external ETM outputs 161
ETM.FIFOFULL()	ETM fifofull logic 161
ETM.MAP()	Number of ETM memory map decoders 161
ETM.PROTOCOL()	Version of ETM protocol 162
ETM.SEQUENCER()	Number of ETM sequencers 162
ETM.TraceCore()	TRUE if the core is traced 162
EXTENDED Function (Z80 only)	163
EXTENDED()	TRUE if register CBAR > 0 163
FDX Function	164
FDX.INSTRING()	Content at FDX memory address 164
FDX.TargetSTALLS()	Monitor FDX communication stalls on the target 164
FLAG Functions	165
In This Section	165
FLAG()	TRUE if hardware flag system available 165
FLAG.READ()	FLAG memory bytes with read access bit 165
FLAG.WRITE()	FLAG memory bytes with write access bit 165
FLASH Functions	166
In This Section	166
FLASH.CFI.SIZE()	Size of FLASH devices 167
FLASH.CFI.WIDTH()	Data bus width of FLASH devices 167
FLASH.CLock.Frequency()	FLASH clock value 167
FLASH.ID()	FLASH manufacturer and device ID 168
FLASH.List.STATE.PENDING()	Number of pending sectors 169
FLASH.List.TYPE()	FLASH family code of FLASH list entry 169
FLASH.ProgramMODE()	FLASH programming modes 170
FLASH.ProgramMODE.OPTION()	FLASH programming options 171

FLASH.SECTOR.BEGIN()	Start address	172
FLASH.SECTOR.END()	End address	172
FLASH.SECTOR.EXIST()	TRUE if sector exists	172
FLASH.SECTOR.EXTRAvalue()	Extra value of FLASH.Create	173
FLASH.SECTOR.NEXT()	Address of next sector	174
FLASH.SECTOR.OTP()	TRUE if OTP sector	174
FLASH.SECTOR.OPTION()	Options of a FLASH sector	175
FLASH.SECTOR.RANGE()	Address range of a FLASH sector	176
FLASH.SECTOR.SIZE()	Size in bytes	176
FLASH.SECTOR.STATE()	FLASH programming state	176
FLASH.SECTOR.TYPE()	FLASH family code of sector	177
FLASH.SECTOR.WIDTH()	Width of FLASH sector	178
FLASH.TARGET.BUILD()	Build number of FLASH algorithm file	178
FLASH.TARGET.CODERANGE()	Code range of FLASH algorithm	179
FLASH.TARGET.DATARANGE()	Data range of FLASH algorithm	179
FLASH.TARGET.FILE()	Name of FLASH algorithm file	179
FLASH.UNIT()	Unit number of FLASH sector	180
FLASH.UNIT.BEGIN()	Unit start address	180
FLASH.UNIT.END()	Unit end address	180
FLASH.UNIT.EXIST()	TRUE if unit exists	181
FLASH.UNIT.NEXT()	Number of next unit	181
FLASHFILE Functions		182
In This Section		182
FLASHFILE.GETBADBLOCK.COUNT()	Number of bad blocks	182
FLASHFILE.GETBADBLOCK.NEXT()	Address of bad block	182
FLASHFILE.SPAREADDRESS()	Address of spare area	183
FPU Functions (Floating Point Unit)		184
In This Section		184
FPU()	FPU register contents	184
FPUCR()	FPU control register contents	184
FPU.RAW()	FPU register raw contents	184
FXU Function		185
FXU()	Content of FXU register	185
GROUP Function		185
GROUP.EXIST()	TRUE if group exists	185
Hardware Functions		186
In This Section		186
hardware.COMBIPROBE()	TRUE if CombiProbe	186
hardware.ESI()	TRUE if EPROM Simulator	186
hardware.ICD()	TRUE if TRACE32 debug hardware	187
hardware.POWERDEBUG()	TRUE if TRACE32 PowerDebug hardware	187
hardware.POWERINTEGRATOR()	TRUE if a PowerIntergrator	187

hardware.POWERINTEGRATOR2()	TRUE if a PowerIntegrator II	187
hardware.POWERNEXUS()	TRUE is a NEXUS Adapter	188
hardware.POWERPROBE()	TRUE is a PowerProbe	188
hardware.POWERTRACE()	TRUE if a PowerTrace Module	188
hardware.POWERTRACE2()	TRUE if a PowerTrace II	188
hardware.POWERTRACE2LITE()	TRUE if a PowerTrace II LITE	189
hardware.POWERTRACE3()	TRUE if a PowerTrace III	189
hardware.POWERTRACEPX()	TRUE if a PowerTrace PX	189
hardware.POWERTRACESERIAL()	TRUE if a PowerTrace Serial	189
hardware.POWERTRACESERIAL2()	TRUE if a PowerTrace Serial II	190
hardware.QUADPROBE()	TRUE if QuadProbe	190
hardware.UTRACE()	TRUE if μ Trace	190
HVX Function		191
HVX()	Content of HVX register	191
I2C Functions		192
In This Section		192
I2C.DATA()	Data read by I2C.TRANSFER	192
I2C.PIN()	Pin status	192
ID Functions		193
In This Section		193
ID.CABLE()	Hardware ID of debug cable	193
ID.POWERTRACEAUXPORT()	Hardware ID of device at PT aux port	193
ID.PREPROcessor()	Hardware ID of preprocessor	194
ID.SERialPort1()	Type-ID of Adapter or Preprocessor at PowerTrace Serial	195
ID.WHISKER()	ID of whisker cable	196
IDCODE()	ID code of TAP in JTAG chain	199
IDCODENUMBER()	Number of detected TAPs	199
Integrator Functions		200
In This Section		200
Integrator()	TRUE if PowerIntegrator	200
Integrator.FIRST()	Get record number of first trace record	200
Integrator.ADC.ENABLE()	Bitmask of enabled analog channels	201
Integrator.ADC.SHUNT()	Shunt-resistor value	201
Integrator.ANALOG()		201
Integrator.COUNTER.EVENT()	Get value of trigger program event counter	201
Integrator.COUNTER.EXTERN()	Value of trigger program external counter	202
Integrator.COUNTER.TIME()	Get value of trigger program time counter	202
Integrator.DIALOGDSEL()	For internal usage only	202
Integrator.DIALOGDSELGET()	For internal usage only	202
Integrator.DSEL()	For internal usage only	203
Integrator.FIND.PI_CHANNEL()	For internal usage only	203
Integrator.FIND.PI_WORD()	TRUE if signal word is defined	203

Integrator.FLAG()	Check state of trigger program FLAG	203
Integrator.GET()	Value of channel	204
Integrator.MAXSIZE()	Get max. size of trace buffer in records	204
Integrator.PROBE()	For internal usage only	204
Integrator.PROGRAMFILENAME()	File name of trigger program	204
Integrator.RECORD.DATA()	Get data recorded in trace record	205
Integrator.RECORD.TIME()	Get timestamp of trace record	205
Integrator.RECORDS()	Get number of used trace records	205
Integrator.REF()	Get record number of reference record	205
Integrator.SIZE()	Get current trace buffer size in records	206
Integrator.STATE()	Get state of the Integrator	206
Integrator.TRACK.RECORD()	Get record number matching search	206
Integrator.USB()	For internal usage only	207
INTERFACE Functions		208
In This Section		208
INTERFACE.CADI()	TRUE if connection to target is via CADI interface	208
INTERFACE.GDB()	TRUE if connection to target is via GDB interface	209
INTERFACE.GDI()	TRUE if connection to target via GDI interface	209
INTERFACE.HOST()	TRUE if application is debugged on host	209
interface.HOSTMCI()	TRUE if TRACE32 debug driver runs on host	209
INTERFACE.IRIS()	TRUE if connection to target is via IRIS interface	210
INTERFACE.MCD()	TRUE if connection to target via MCD interface	210
INTERFACE.NAME()	Name of debugger	210
INTERFACE.QNX()	TRUE if PBI=QNX	210
INTERFACE.SIM()	TRUE if simulator	211
IOBASE Functions		212
In This Section		212
IOBASE()	Base address of internal I/O's	212
IOBASE.ADDRESS()	Base address of internal I/O's with access class	212
IOBASE2()	Second base address of internal I/O's	212
IProbe Functions		213
In This Section		214
IProbe()	TRUE if IPROBE	214
IProbe.ADC.ENABLE()	TRUE if channel is enabled	214
IProbe.ADC.SHUNT()	Shunt resistor value of channel	215
IProbe.ANALOG()	TRUE if Analog Probe is plugged	216
IProbe.FIRST()	Get record number of first trace record	216
IProbe.GET()	Value of channel	216
IProbe.MAXSIZE()	Get max. size of trace buffer in records	217
IProbe.PROBE()		217
IProbe.RECORD.DATA()	Get data recorded in trace record	218
IProbe.RECORD.TIME()	Get timestamp of trace record	218

IProbe.RECORDS()	Get number of used trace records	219
IProbe.REF()	Get record number of reference record	220
IProbe.SIZE()	Get current trace buffer size in records	220
IProbe.STATE()	Get state of IProbe	221
IProbe.TRACK.RECORD()	Get record number matching search	221
JTAG Functions		222
In This Section		222
JTAG.MIPI34()	Query special MIPI34 pins	222
JTAG.PIN()	Level of JTAG signal	223
JTAG.SEquence.RESULT()	Get result of JTAG sequence	223
JTAG.SEquence.EXIST()	Check if a JTAG sequence exists	223
JTAG.SEquence.LOCKED()	Check if a JTAG sequence is locked	224
JTAG.SHIFT()	TDO output of JTAG shift	224
JTAG.X7EFUSE.RESULT()	Result of JTAG.X7EFUSE command	225
JTAG.X7EFUSE.CNTL()	CNTL flags read by JTAG.X7EFUSE command	226
JTAG.X7EFUSE.DNA()	DNA value read by JTAG.X7EFUSE command	226
JTAG.X7EFUSE.KEY()	AES key read by JTAG.X7EFUSE command	227
JTAG.X7EFUSE.USER()	User code read by JTAG.X7EFUSE command	227
JTAG.XUSEFUSE.RESULT()	Result of JTAG.XUSEFUSE command	228
JTAG.XUSEFUSE.CNTL()	CNTL value read by JTAG.XUSEFUSE command	228
JTAG.XUSEFUSE.DNA()	DNA value read by JTAG.XUSEFUSE command	229
JTAG.XUSEFUSE.KEY()	AES key read by JTAG.XUSEFUSE command	229
JTAG.XUSEFUSE.RSA()	RSA hash read by JTAG.XUSEFUSE command	230
JTAG.XUSEFUSE.SEC()	SEC value read by JTAG.XUSEFUSE command	230
JTAG.XUSEFUSE.USER()	User code read by JTAG.XUSEFUSE command	231
JTAG.XUSEFUSE.USER128()	128 bit User code read by JTAG.XUSEFUSE	231
LOGGER Functions		232
In This Section		232
LOGGER.FIRST()	Get record number of first trace record	232
LOGGER.RECORD.ADDRESS()	Get address recorded in trace record	233
LOGGER.RECORD.DATA()	Get data recorded in trace record	233
LOGGER.RECORD.OFFSET()	Get address in trace record as number	233
LOGGER.RECORD.TIME()	Get timestamp of trace record	234
LOGGER.RECORDS()	Get number of used trace records	234
LOGGER.REF()	Get record number of reference record	234
LOGGER.SIZE()	Get current trace buffer size in records	234
LOGGER.STATE()	Get state of Logger trace	235
MachO Format Function (Apple)		236
MACHO.LASTUUID()	Universally unique identifier of MachO file	236
MAP Functions		237
In This Section		237
MAP.ROMSIZE()	Size of the defined ROM	237

MCDS Functions	238
In This Section	238
MCDS.MODULE.NAME()	Name of MCDS module 239
MCDS.MODULE.NUMBER()	Number-part of MCDS module ID 239
MCDS.MODULE.REVision()	Revision-part of MCDS module ID 239
MCDS.MODULE.TYPE()	Type-part of MCDS module ID 240
MCDS.STATE()	MCDS module is switched on/off 240
MCDS.TraceBuffer.LowerGAP()	Trace buffer lower gap 241
MCDS.TraceBuffer.SIZE()	Trace buffer size 242
MCDS.TraceBuffer.UpperGAP()	Trace buffer upper gap 242
MMU Functions (Memory Management Unit)	243
In This Section	243
MMU()	Value of MMU register 243
MMU.DEFAULTPT()	Base address of default page table 244
MMU.DEFAULTTRANS.<range>()	Query MMU setup 245
MMU.FORMAT()	Currently selected MMU format 247
MMU.FORMAT.DETECTED()	Auto-detection of page table format 248
MMU.FORMAT.DETECTED.ZONE()	Auto-detection of page table format 249
MMX Function (MultiMedia eXtension)	250
MMX()	Value of MMX register 250
MONITOR Function	250
MONITOR()	TRUE if debugger is running as monitor 250
NEXUS Functions	251
In This Section	251
NEXUS()	TRUE if Nexus trace is supported 251
NEXUS.RTTBUILD()	RTT build register 251
NEXUS.PortMode()	Current PortMode setting 252
NEXUS.PortSize()	Current PortSize setting 252
Onchip Functions	253
In This Section	253
Onchip()	TRUE if the onchip trace is available 253
Onchip.FIRST()	Get record number of first trace record 253
Onchip.FLOW.ERRORS()	Get number of flow errors / hard errors 253
Onchip.FLOW.FIFOFULL()	Get number of FIFO overflows 254
Onchip.MAXSIZE()	Get max. size of trace buffer in records 255
Onchip.RECORD.ADDRESS()	Get address recorded in trace record 255
Onchip.RECORD.DATA()	Get data recorded in trace record 255
Onchip.RECORD.OFFSET()	Get address in trace record as number 255
Onchip.RECORD.TIME()	Get timestamp of trace record 256
Onchip.RECORDS()	Get number of used trace records 256
Onchip.REF()	Get record number of reference record 256
Onchip.SIZE()	Get current trace buffer size in records 256

Onchip.STATE()	Get state of Onchip trace	257
Onchip.TraceCONNECT()	Name of trace sink of the SoC	257
Onchip.TRACK.RECORD()	Get record number matching search	258
PBI Function		259
PBI()	Name of used debug back-end	259
PCI Functions		260
In This Section		260
PCI.Read.B()	Byte from PCI register	260
PCI.Read.L()	Long from PCI register	260
PCI.Read.W()	Word from PCI register	260
PER Functions		261
In This Section		261
PER.<width>()	Memory contents in default endianness	261
PER.<width>.<endianness>()	Memory contents in specified endianness	262
PER.ADDRESS()	Address of register(field)	263
PER.ADDRESS.<sub_cmd>()	Check access security in PER file	264
PER.ARG()	Argument of PER.view command	264
PER.ARG.ADDRESS()	Address argument of PER.view command	265
PER.BASE()	Last BASE address	265
PER.Buffer.<width>()	Value from buffer	266
PER.EVAL()	Value of expression in PER file	267
PER.FILENAME()	PER file name	267
PER.SAVEINDEX()	Value from indexed register	268
PER.VALUE()	Value of register(field)	268
PER.VALUE.STRING()	Value of BITFLD as string	269
PERF Functions (Performance)		270
In This Section		270
PERF.MEMORY.HITS()	Number of memory samples	270
PERF.MEMORY.SnoopAddress()	Snoop memory address	271
PERF.MEMORY.SnoopSize()	Snoop size	271
PERF.METHOD()	Recording method	271
PERF.MODE()	Get Performance Analyzer recording mode	272
PERF.PC.HITS()	Number of PC samples	272
PERF.RATE()	Number of snoops per second	272
PERF.RunTime()	Retained time for program run	273
PERF.SNOOPFAILS()	Number of snoop fails	273
PERF.STATE()	Get state of Performance Analyzer	273
PERF.TASK.HITS()	Number of task samples	274
Port Analyzer Functions		275
In This Section		275
PORT.GET()	Value of channel	275
PORT.MAXSIZE()	Get max. size of trace buffer in records	275

PORT.RECORDS()	Get number of used trace records	275
PORT.REF()	Get record number of reference record	276
PORT.SIZE()	Get current trace buffer size in records	276
PORT.STATE()	Get state of Port Analyzer	276
PORT.TRACK.RECORD()	Get record number matching search	276
PORTANALYZER()		277
PORTSHARING Function		277
PORTSHARING()	Current setting of PortSHaRing	277
POWER Functions		278
In This Section		278
PowerProbe Functions		279
In This Section		279
PROBE.COUNTER.EVENT()	Get value of trigger program event counter	279
PROBE.COUNTER.EXTERN()	Get value of trigger program external counter	279
PROBE.COUNTER.TIME()	Get value of trigger program time counter	279
Probe.FIRST()	Get record number of first trace record	280
PROBE.FLAG()	Check state of trigger program FLAG	280
PROBE.GET()	Value of channel	280
PROBE.MAXSIZE()	Get max. size of trace buffer in records	280
PROBE.RECORD.DATA()	Get data recorded in trace record	281
PROBE.RECORD.TIME()	Get timestamp of trace record	281
PROBE.RECORDS()	Get number of used trace records	281
PROBE.REF()	Get record number of reference record	281
PROBE.SIZE()	Get current trace buffer size in records	282
PROBE.STATE()	Get state of PowerProbe	282
PROBE.TRACK.RECORD()	Get record number matching search	283
Program Pointer Function		284
PP()	Address of program pointer (access class, space ID, program counter)	284
Register Functions		285
Register()	Content of register	285
Register.LIST()	First / next register name	286
Register.Valid()	Valid register value	287
RTS Functions		288
In This Section		288
RTS.ERROR()	Check for flowerrors during RTS processing	288
RTS.NOCODE()	Check for RTS NOCODE error	288
RTS.FIFOFULL()	Check for FIFO full error in RTS	289
RTS.RECORD()	Find record causing an error in RTS	289
RTS.RECORDS()	Get number of trace records transferred to RTS	289
RTS.BUSY()	Check if RTS is busy	289
RunTime Functions		290

In This Section		290
RunTime.ACCURACY()	Accuracy of run-time counter	290
RunTime.ACTUAL()		290
RunTime.LAST()		290
RunTime.LASTRUN()		291
RunTime.REFA()		291
RunTime.REFB()		291
SMMU Functions		292
SMMU.BaseADDRESS()	Base address of SMMU	292
SMMU.StreamID2SMRG()	Find match for stream ID	292
SNOOPer Functions		294
In This Section		294
SNOOPer.FIRST()	Get record number of first trace record	294
SNOOPer.MAXSIZE()	Get max. size of trace buffer in records	295
SNOOPer.RECORD.ADDRESS()	Get address recorded in trace record	295
SNOOPer.RECORD.DATA()	Get data recorded in trace record	295
SNOOPer.RECORD.OFFSET()	Get address in trace record as number	295
SNOOPer.RECORD.TIME()	Get timestamp of trace record	296
SNOOPer.RECORDS()	Get number of used trace records	296
SNOOPer.REF()	Get record number of reference record	296
SNOOPer.SIZE()	Get current trace buffer size in records	296
SNOOPer.STATE()	Get state of SNOOPer trace	297
STATE Functions (Target State)		298
In This Section		298
STATE.HALT()		298
STATE.OSLK()		298
STATE.POWER()		299
STATE.PROCESSOR()		300
STATE.RESET()		301
STATE.RUN()		301
STATE.TARGET()	State of target displayed in TRACE32 state line	301
SPE Function		301
SPE()	Content from SPE register	301
SSE Function		302
SSE()	Segment from SSE register	302
Stimuli Generator Function		303
hardware.STG()	TRUE if Stimuli Generator hardware	303
sYmbol Functions		304
In This Section		304
sYmbol.AutoLOAD.CHECK()	Update option for the symbol autoloader	304
sYmbol.AutoLOAD.CHECKCMD()	Load command for symbol autoloader	304

sYmbol.AutoLOAD.CONFIG()	Used sub-command	305
sYmbol.BEGIN()	First address of symbol	305
sYmbol.COUNT()	Number of symbols	306
sYmbol.ECA.BINary.GAPNUMBER()	Number of observability gaps	306
sYmbol.END()	Last address of symbol	306
sYmbol.EPILOG()	Address of return point	307
sYmbol.EXIST()	TRUE if symbol exists	308
sYmbol.EXIT()	Exit address of function	308
sYmbol.FUNCTION()	Function name	309
sYmbol.IMPORT()	Import file names	309
sYmbol.ISFUNCTION()	TRUE if symbol is function	309
sYmbol.ISVARIABLE()	TRUE if symbol is variable	310
sYmbol.LANGUAGE()	Selected high-level language	311
sYmbol.List.MAP.<x>()	Information about address ranges on the target	311
sYmbol.LIST.PROGRAM()	Path and file name of binary files	312
sYmbol.List.PROGRAM.<x>()	Information about loaded programs	313
sYmbol.List.SEction.<x>()	Information about section ranges	314
sYmbol.LIST.SOURCE()	File location of source file	316
sYmbol.MATCHES()	Number of occurrences	316
sYmbol.NAME()	Symbol path and name based on address	317
sYmbol.NAME.AT()	Resolve ambiguous symbols based on address	317
sYmbol.NEXT.BEGIN()	Start address of next symbol	318
sYmbol.RANGE()	Address range of symbol	318
sYmbol.SEARCHFILE()	Absolute path of source file	318
sYmbol.SECADDRESS()	Start address of section	320
sYmbol.SECEND()	End address of section	320
sYmbol.SECEXIST()	Check for existence of a section	320
sYmbol.SECNAME()	Section name	321
sYmbol.SECPRANGE()	Physical address range of section	321
sYmbol.SECRANGE()	Logical address range of section	321
sYmbol.SIZEOF()	Size of debug symbol	322
sYmbol.SOURCEFILE()	Name of source file	322
sYmbol.SOURCELINE()	HLL-line number of address	323
sYmbol.SOURCEPATH()	TRUE if path is search path	324
sYmbol.STATE()	Value from sYmbol.state window	324
sYmbol.TRANSPOSE()	Transpose program and module names	324
sYmbol.TYPE()	Type of symbol	325
sYmbol.VARNAME()	Name of variable or structure element	326
SYStem Functions		327
In This Section		327
SYStem.ACCESS.DENIED()	TRUE if memory access is denied	328
SYStem.AMBA()	TRUE if AMBA bus mode is selected	328
SYStem.BigEndian()	TRUE if target core runs in big endian mode	328

SYStem.CADlconfig.RemoteServer()		329
SYStem.CADlconfig.Traceconfig()		330
SYStem.CONFIG.<tap_position>()		331
SYStem.CONFIG.DEBUGPORT()		331
SYStem.CONFIG.DEBUGPORTTYPE()		331
SYStem.CONFIG.JTAGTAP()	Return the JTAG PRE and POST settings	332
SYStem.CONFIG.ListCORE()		335
SYStem.CONFIG.ListSIM()		336
SYStem.CONFIG.Slave()		336
SYStem.CONFIG.TAPState()		337
SYStem.CPU()	Name of processor	337
SYStem.GTL.CALLCOUNTER()	Amount of calls to GTL library	338
SYStem.GTL.CONNECTED()	Connection status	338
SYStem.GTL.CYCLECOUNTER()	load GTL interface for bit banging protocol	338
SYStem.GTL.LIBname()	Name of GTL library	338
SYStem.GTL.ModelINFO()	Info string from GTL API	339
SYStem.GTL.ModelINAME()	Model Name	339
SYStem.GTL.PLUGINVERSION()	Version number	339
SYStem.GTL.TransactorNAME()	Transactor name	340
SYStem.GTL.TransactorTYPE()	Transactor type	340
SYStem.GTL.VENDORID()	Vendor ID	340
SYStem.GTL.VERSION()	Version number	341
SYStem.HOOK()		341
SYStem.IMASKASM()		341
SYStem.IMASKHLL()		341
SYStem.INSTANCE()	Index of TRACE32 PowerView instance	342
SYStem.INSTANCECOUNT()	Count of GUIs connected to a PowerDebug	342
SYStem.IRISconfig.RemoteServer()		343
SYStem.JtagClock()		343
SYStem.LittleEndian()		343
SYStem.MCDCommand.ResultString()		344
SYStem.MCDconfig.LIBrary()		344
SYStem.Mode()		344
SYStem.NOTRAP()	1 if the option NOTRAP is active	345
SYStem.Option.DUALPORT()	State of like-named command	345
SYStem.Option.MACHINESPACES()	State of like-named command	345
SYStem.Option.MMUSPACES()	State of like-named command	346
SYStem.Option.EnReset()	State of like-named command	346
SYStem.Option.ResBreak()	State of like-named command	346
SYStem.Option.SPILLLOCation()	State of like-named command	347
SYStem.Option.ZoneSPACES()	State of like-named command	347
SYStem.RESetBehavior()	Current setting of RESetBehavior	348
SYStem.Up()	TRUE if debugger has access to debug resources	348

SYStem.USECORE()		350
SYStem.USEMASK()		351
TASK Functions		352
In This Section		352
TASK()	Name of current task	353
TASK.ACCESS()	Access class	353
TASK.ACCESS.ZONE()	Access class zone	353
TASK.BACK()	Background task number	353
TASK.CONFIG()	OS Awareness configuration information	354
TASK.CONFIGFILE()	Path of loaded OS Awareness	354
TASK.COUNT()	Number of tasks	354
TASK.CURRENT.MACHINEID()	ID of current machine	355
TASK.CURRENT.SPACEID()	ID of current MMU space	355
TASK.CURRENT.TASK()	Magic value of current task	355
TASK.CURRENT.TASKNAME()	Name of current task	355
TASK.FIRST()	First task in list	356
TASK.FORE()	Foreground task number	356
TASK.ID()	ID of task	356
TASK.MACHINE.ACCESS()	Default access class	356
TASK.MACHINE.ID()	ID of machine	357
TASK.MACHINE.NAME()	Name of machine	357
TASK.MACHINE.VTTB()	VTTB of machine	358
TASK.MAGIC()	Task magic number	358
TASK.MAGICADDRESS()	'magic address'	359
TASK.MAGICRANGE()	Range of 'magic address'	359
TASK.MAGICSIZE()	Size of 'magic address'	359
TASK.NAME()	Name of task	360
TASK.NEXT()	Next task in list	360
TASK.ORTIFILE()	Path of loaded ORTI file	361
TASK.SPACE.COUNT()	Number of spaces	361
TASK.SPACEID()	Space ID of task	362
TERM Functions (Terminal Window)		363
In This Section		363
TERM.LINE()	Get line from terminal window	363
TERM.NEWHANDLE()	Get next free terminal handle	363
TERM.READBUSY()	TRUE as long as TERM.READ is in progress	364
TERM.RETURNCODE()	Get returncode from terminal routine	364
TERM.TRIGGERED()	Get trigger state of terminal window	365
TPIU Functions		366
In This Section		366
TPIU.PortMode()	Port mode setting	366
TPIU.PortSize()	Port size setting	366

TPIU.SWVPrescaler()	SWVPrescaler value	367
TPUBASE Function		367
TPUBASE.ADDRESS()	Address of TPU	367
Trace Functions		368
In This Section		368
Trace.FIRST()	Get record number of first trace record	368
Trace.FLOW()	TRUE if trace method is flow trace	369
Trace.FLOW.ERRORS()	Get number of flow errors / hard errors	369
Trace.FLOW.FIFOFULL()	Get number of FIFO overflows	370
Trace.MAXSIZE()	Get max. size of trace buffer in records	370
Trace.METHOD()	Currently configured trace method	371
Trace.METHOD.Analyzer()	TRUE if the trace method is Analyzer	371
Trace.METHOD.ART()	TRUE if the trace method is ART	371
Trace.METHOD.CAnalyzer()	TRUE if the trace method is CAnalyzer	371
Trace.METHOD.FDX()	TRUE if the trace method is FDX	372
Trace.METHOD.HAnalyzer()	TRUE if the trace method is HAnalyzer	372
Trace.METHOD.Integrator()	TRUE if the trace method uses the Integrator	372
Trace.METHOD.IProbe()	TRUE if the trace method uses the IProbe	372
Trace.METHOD.LA()	TRUE if the trace method is LA	373
Trace.METHOD.LOGGER()	TRUE if the trace method is LOGGER	373
Trace.METHOD.ONCHIP()	TRUE if the trace method is ONCHIP	373
Trace.METHOD.Probe()	TRUE if trace method uses the PowerProbe	373
Trace.METHOD.SNOOPer()	TRUE if the trace method is SNOOPer	374
Trace.RECORD.ADDRESS()	Get address recorded in trace record	374
Trace.RECORD.DATA()	Get data recorded in trace record	374
Trace.RECORD.OFFSET()	Get address in trace record as number	375
Trace.RECORD.TIME()	Get timestamp of trace record	375
Trace.RECORDS()	Get number of used trace records	375
Trace.SIZE()	Get current trace buffer size in records	376
Trace.STATE()	Get state of PowerTrace hardware	376
Trace.STATistic.COUNT()	Number of occurrences of selected function	377
Trace.STATistic.EXIST()	TRUE if function exists in trace statistics	377
Trace.STATistic.FIRST()	Record number of start point for statistic analysis	377
Trace.STATistic.IMAX()	Longest time between function entry and exit	377
Trace.STATistic.IMIN()	Shortest time between function entry and exit	378
Trace.STATistic.Internal()	Time spent within the selected function	378
Trace.STATistic.LAST()	Record number of end point for statistic analysis	378
Trace.STATistic.MAX()	Maximum time of selected function	378
Trace.STATistic.MIN()	Minimum time of selected function	379
Trace.STATistic.Total()	Total time of selected function	379
Trace.TraceCONNECT()	Name of trace sink of the SoC	380
TRACEPORT Function		381

In This Section		381
TRACEPORT.LaneCount()	Number of serial lanes	381
TRACK Functions		382
In This Section		382
TRACK.ADDRESS()	Get tracking address	382
TRACK.COLUMN()	Number of column where the found item starts	382
TRACK.LINE()	Number of line containing the found item	382
TRACK.RECORD()	Number of record containing the found item	384
TRACK.STRING()	Current selection in a TRACE32 window	384
TRACK.TIME()	Timestamp of current tracking record	385
TRANS Functions (Debugger Address Translation)		386
In This Section		386
TRANS.LIST.NUMBER()	Number of TRANS.List entries	386
TRANS.LIST.LOGRANGE()	Query TRANS.List entry	387
TRANS.LIST.PHYSADDR()	Query TRANS.List entry	388
TRANS.LIST.TYPE()	Query TRANS.List entry	389
TRANS.ENABLE()	TRUE if address translation is enabled	390
TRANS.INTERMEDIATE()	Convert a guest logical address	390
TRANS.INTERMEDIATE.VALID()	TRUE if address translation is valid	391
TRANS.LINEAR()	Convert logical to linear address	391
TRANS.LINEAR.VALID()	TRUE if address translation is valid	392
TRANS.LOGICAL()	Convert physical to logical address	392
TRANS.LOGICAL.VALID()	TRUE if address translation is valid	393
TRANS.PHYSICAL()	Convert logical to physical address	393
TRANS.PHYSICAL.VALID()	TRUE if address translation is valid	396
TRANS.TABLEWALK()	TRUE if address translation table walk is ON	396
TSS Function		397
TSS()	TSS base address	397
Var Functions		398
In This Section		398
Var.ADDRESS()	Address of HLL expression	398
Var.BITPOS()	Bit position inside a C bit field	398
Var.BITSIZE()	Size of bit field element	399
Var.END()	Last address of HLL expression	399
Var.EXIST()	TRUE if HLL expression exists	400
Var.FVALUE()	Contents of HLL expression	401
Var.ISBIT()	TRUE if HLL expression is a bit field element	401
Var.RANGE()	Address range of HLL expression	402
Var.SIZEOF()	Size of HLL expression	402
Var.STRING()	Zero-terminated string or variable contents	403
Var.TYPEOF()	Type of HLL expression	403
Var.VALUE()	Value of HLL expression	404

VCO Function		405
VCO()	Frequency of VCO generator	405
VERSION Functions		406
In This Section		406
VERSION.BUILD()	Upper build number	407
VERSION.BUILD.BASE()	Lower build number	407
VERSION.CABLE()	Hardware version of debug cable	408
VERSION.DATE()	Version date YYYY/MM	408
VERSION.ENVironment()	TRACE32 environment setting	408
VERSION.FirmWare.DEBUG()	Version number of firmware	409
VERSION.SERIAL()	Serial number	409
VERSION.SERIAL.CABLE()	First serial number of debug cable	409
VERSION.SERIAL.DEBUG()	Serial number of debug module	410
VERSION.SERIAL.Integrator()	Serial number of PowerIntegrator	410
VERSION.SERIAL.NEXUSadapter()	Serial number of nexus adapter	410
VERSION.SERIAL.PREPROcessor()	Serial number of preprocessor	410
VERSION.SERIAL.POWERPROBE()	Serial number of PowerProbe	411
VERSION.SERIAL.POWERTRACEAUXPORT()	S/N of device at PT aux port	411
VERSION.SERIAL.SERialPort1()	S/N of device at Serial Port 1 of PT Serial	411
VERSION.SERIAL.WHISKER()	S/N of whiskers at CombiProbe or μ Trace	411
VERSION.SERIAL.TRACE()	Serial number of trace module	412
VERSION.SOFTWARE()	Release build or nightly build, etc.	413
VERSION.SOFTWARE.TYPE()	Software build type	414
VPU Functions		415
In This Section		415
VPU()	Value of VPU register	415
VPUCR()	Value of VRSAVE or VSCR register	415

History

- 27-May-2024 New functions [Trace.STATistic.FIRST\(\)](#) and [Trace.STATistic.LAST\(\)](#).
- 13-May-2024 New function [COVerage.IDLE\(\)](#).
- 08-May-2024 New functions [COMPonentNAME\(\)](#) and [COMPonentNUMBER\(\)](#).
- 03-May-2024 New function [TERM.NEWHANDLE\(\)](#).
- 27-Mar-2024 New function [ID.POWERTRACEAUXPORT\(\)](#).
- 25-Jan-2024 New function [sYmbol.ECA.BINary.GAPNUMBER\(\)](#).
- 20-Nov-2023 New function [COVerage.Percentage\(\)](#).
- 21-Aug-2023 New function [Register.Valid\(\)](#).
- 06-Jun-2023 New function [VERSION.SOFTWARE.TYPE\(\)](#).
- 05-Jun-2023 New function [PER.BASE\(\)](#).
- 02-May-2023 New functions: [Analyzer.CONFIG.POWERTRACESERIAL2\(\)](#) and [hardware.POWERTRACESERIAL2\(\)](#).
- 18-Apr-2023 New optional parameter for [Symbol.SOURCEFILE\(\)](#).
- 20-Feb-2023 New functions: [ID.SerialPort1\(\)](#) and [VERSION.SERIAL.SerialPort1\(\)](#).
- 18-Nov-2022 New function: [PBI\(\)](#).
- 18-Nov-2022 New functions: [VERSION.SERIAL.Integrator](#), [VERSION.SERIAL.NEXUSadapter](#), and [VERSION.SERIAL.POWERPROBE](#).
- 02-Nov-2022 All **hardware** functions are now grouped in the chapter '[Hardware Functions](#)'. The descriptions have also been updated.
- 22-Aug-2022 New **THUMB** parameter for [CPU.FEATURE\(\)](#) function supported by the Arm architecture.
- 09-May-2022 New functions: [SYStem.GTL.CALLCOUNTER\(\)](#) and [SYStem.GTL.CYCLECOUNTER\(\)](#).

09-May-2022 New function: [FDX.TargetSTALLS\(\)](#).

06-May-2022 New functions: [PER.ADDRESS\(\)](#), [PER.VALUE\(\)](#), and [PER.VALUE.STRING\(\)](#).

08-Apr-2022 Added optional parameters to the functions [TASK.MAGICADDRESS\(\)](#), [TASK.MAGICRANGE\(\)](#), and [TASK.MAGICSIZE\(\)](#).

01-Apr-2022 Removed functions: **hardware.SCU()**, **hardware.TA32()**, **SYStem.TRACEEXT()**, **SYStem.TRACEINT()**, and **Analyzer.CONFIG.RISCTRACE()**.

30-Mar-2022 New function: [sYmbol.TRANSPOSE\(\)](#).

09-Mar-2022 New function: [COVerage.LOAD.KEY\(\)](#).

04-Mar-2022 New function: [ETM.TraceCORE\(\)](#).

04-Mar-2022 New function: [CABLE.GalvanicISolation.FIRMWARE\(\)](#).

24-Feb-2022 Removed functions: **INTERFACE.VAST()** and **INTERFACE.VDI()**.

10-Feb-2022 New function: [COMPOnent.TYPE\(\)](#).

03-Feb-2022 New function: [TERM.READBUSY\(\)](#).

19-Jan-2022 New function: [PER.SAVEINDEX\(\)](#).

Dec-2021 New functions: [sYmbol.List.PROGRAM.<x>\(\)](#), and [sYmbol.List.SECTION.<x>\(\)](#).

Nov-2021 New functions: [SYStem.GTL.ModelINFO\(\)](#), [SYStem.GTL.ModelNAME\(\)](#), [SYStem.GTL.TransactorNAME\(\)](#), [SYStem.GTL.TransactorTYPE\(\)](#), and [DEBUGGER.FEATURE\(\)](#).

In This Document

This document lists all the *target-related functions* and *tool-related functions* available for the different debug systems.

In addition, the document provides important background information about functions in TRACE32 and explains the purpose and use of functions in TRACE32.

The capital letters in function names represent the short form of the function. Any function name can be written in its long or short form. For example `Data.Byte()` could be also written as `D.B()`

How This Document is Organized

- **Difference between Functions and Commands in TRACE32:** This section is primarily intended for users who are new to TRACE32. As a new user, make sure that you also read the next two sections.
- **Purpose of Functions:** Briefly describes and illustrates the purpose of functions in TRACE32 by way of four examples.
- **How to Use Functions:** Briefly describes and illustrates how to use functions in TRACE32 by way of four examples.
- **Which return values of functions can be printed?:** Provides background information.
- **Groups of Functions** (e.g. **ACCESS Functions**, **ADDRESS Functions** etc.): Describes the *target-related* and *tool-related functions*, including source code examples, screenshots, and photos.

Difference between Functions and Commands in TRACE32

In TRACE32, functions are *not* the same as commands. Commands are used to perform actions, e.g. open a window, modify configuration settings, etc. Whereas functions are used to return information about hard and software and convert formats and data.

Functions have trailing parentheses(), whereas commands are used without parentheses:

Function()	Command
SYStem.UP ()	SYStem.state

Functions and commands can have identical names to emphasize that they are related. But this is not always the case, as the example below shows:

Related function and command	Function()	Command
identical names	Analyzer.SIZE ()	Analyzer.SIZE <records>
not identical names	STATE.RUN ()	Go

Next:

- [Purpose of Functions](#)
- [How to Use Functions](#)

Purpose of Functions

Functions in TRACE32 have two main purposes:

1. Return status information about:
 - The target (see [Example 1](#))
 - The TRACE32 tools (see [Example 2](#))
 - The TRACE32 software (see [Example 3](#))
2. Convert specific formats or data into other formats or data (see [Example 4](#)).

Example 1: Return Status of the Target

Returns the status of the target:

```
PRINT STATE.RUN()           ; Returns the status of the run-flag
                             ; as a boolean.
                             ; TRUE: cpu is running in the target
                             ; (or is out of control).
                             ; FALSE: cpu is not running.
```

Example 2: Return Status of a TRACE32 Tool

Returns the status of a TRACE32 tool, here the serial cable:

```
PRINT VERSION.SERIAL.CABLE() ; Returns the serial number of
                             ; the debug license
                             ; (Nexus adapter or debug cable).
```

Example 3: Return the Version Number

Returns the version number of the TRACE32 software:

```
PRINT VERSION.SOFTWARE()     ; Returns the version number of
                             ; your TRACE32 installation.

PRINT SOFTWARE.VERSION()     ; Alternative command
```

Example 4: Convert a String

Convert a string to upper case:

```
PRINT STRing.UPR("hello world") ; Converts the string to HELLO WORLD
```

How to Use Functions

In TRACE32, you can use functions as follows:

1. Within PRACTICE scripts (see [Example 1](#))
2. To parametrize commands (see [Example 2](#))
3. Type them directly into the TRACE32 command line
 - [Example 3](#) points out the importance of the output commands **PRINT** and **Data.Print**
 - [Example 4](#) points out the importance of access class specifiers for address functions.

Example 1: In PRACTICE Scripts

Functions are normally used within PRACTICE scripts:

```
...  
; verify the FLASH contents  
Data.LOAD.COSMIC demo.h12 /DIFF  
IF FOUND()  
    PRINT "Verify error after FLASH programming"  
ELSE  
    PRINT "FLASH programming completed successfully"  
...
```

Example 2: As Parameters in Commands


Functions can be used to parametrize commands:

```
; Get the value of register 13, and then dump the memory contents  
; starting at this address  
  
Data.dump Register(R13)      ; Command: Data.dump  
                             ; Function Register\(\) is used as command  
                             ; parameter.  
                             ; R13: Register 13 of ARM family chips  
                             ; Note: "R" is part of the register name.  
  
; Here, the register name is AL.  
  
Data.dump Register(AL)      ; AL: Lower 8 bit of register AX of the  
                             ; x86 family.
```

Example 3: Together with the Output Commands PRINT and Data.Print

You can type functions directly into the TRACE32 command line. In this case it is necessary to use an additional output command like **PRINT** or **Data.Print**, depending on the return value of the function.


```
; Returns the current working directory.  
PRINT "Working directory is: " OS.Pwd()
```




Example 4: Address Function and Their Access Class Specifiers

An address function, such as **Data.Long()**, always requires a parameter together with an **access class** specifier. In the example below, the access class specifier is **D** for data memory. A plain integer value, such as `0x1234ffff`, without an access class specifier is *not* a valid address.

```
; Returns the memory contents of a long value (32-bit) from the  
; data memory (D:)  
PRINT Data.Long(D:0x1234abc8)  
  
; 'D:1024.' is a valid, decimal address due to postfix "."  
PRINT Data.Long(D:1024.)  
  
; Fails because the address does not have a access class specifier.  
PRINT Data.Long(0x1234ffff)
```



The **access class** specifier is **D** (**View** menu > **Dump**)



For lists of target-specific memory class specifiers, see **TRACE32 > Help** menu > **Processor Architecture Manual**.

Simply search for “Access Classes”.

Which Return Values of Functions can be Printed?

The following return values of functions can be printed:

- [Addresses](#)
- [ASCII values](#)
- [Boolean](#)
- Numerical values:
 - [Binary](#)
 - [Decimal](#)
 - [Float](#)
 - [Hex](#)
- [Ranges, address ranges, time ranges](#)
- [String](#)
- [Time values](#)

Related Documents

For training material, refer to:

- [Training PRACTICE](#)

For more functions, refer to:

- [PowerView Function Reference](#)
- [Stimuli Generator Function Reference](#)

In This Section

See also

- [ACCESS.isGUEST\(\)](#)
- [ACCESS.isHYPERVISOR\(\)](#)

ACCESS.isGUEST()

TRUE if access class belongs to guest

[build 90005 - DVD 02/2018]

Syntax:

ACCESS.isGUEST(<address>)

Returns TRUE if the [access class](#) of the specified <address> belongs to a guest in the hypervisor environment.

- For ARM, this is the non-secure access class (N: and related ones).
- For x86, this is the guest access class (G: and related ones).
- For PowerPC, this is the guest access class (G: and related ones).

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

NOTE:

If [SYSTEM.Option.MACHINESPACES](#) is set to **ON**, then the machine ID of an address is the better criterion to determine whether the address belongs to a guest machine or the hypervisor.
See function [ADDRESS.isGUEST\(\)](#).

Examples:

```
; on ARM, guest machines are usually running in non-secure mode, so
; guest addresses usually use access class N: and related.

PRINT ACCESS.isGUEST(N:0xC0000000)           ; TRUE

PRINT ACCESS.isGUEST(H:0xC0000000)           ; FALSE
```


Syntax:

ACCESS.isHYPERVISOR(<address>)

Returns TRUE if the [access class](#) belongs to the hypervisor in the hypervisor environment.

- For ARM, this is the hypervisor access class (H: and related ones).
- For x86, this is the host access class (H: and related ones).
- For PowerPC, this is the hypervisor access class (H: and related ones).

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

NOTE:

If [SYStem.Option.MACHINESPACES](#) is set to **ON**, then the machine ID of an address is the better criterion to determine whether the address belongs to a guest machine or the hypervisor.
See function [ADDRESS.isGUEST\(\)](#).

Examples:

```
; on ARM, the host machine which runs the hypervisor is usually running
; in hypervisor mode, so hypervisor addresses use access class H: and
; related
PRINT ACCESS.isHYPERVISOR(H:0xC0000000)      ; TRUE

PRINT ACCESS.isHYPERVISOR(N:0xC0000000)      ; FALSE

PRINT ACCESS.isHYPERVISOR(Z:0xC0000000)      ; FALSE
```

In This Section

See also

- ADDRESS.ACCESS()
 - ADDRESS.ACCESS.CMPSTRICT()
 - ADDRESS.INSTR.LEN()
 - ADDRESS.isGUEST()
 - ADDRESS.isINTERMEDIATE()
 - ADDRESS.isNONSECUREEX()
 - ADDRESS.isPHYSICAL()
 - ADDRESS.isSECURE()
 - ADDRESS.MACHINEID()
 - ADDRESS.OFFSET()
 - ADDRESS.RANGE.END()
 - ADDRESS.SEGMENT()
 - ADDRESS.STRACCESS()
- ADDRESS.ACCESS.CMP()
 - ADDRESS.EXPANDACCESS()
 - ADDRESS.isDATA()
 - ADDRESS.isHYPERVISOR()
 - ADDRESS.isNONSECURE()
 - ADDRESS.isONCHIP()
 - ADDRESS.isPROGRAM()
 - ADDRESS.isSECUREEX()
 - ADDRESS.MAU()
 - ADDRESS.RANGE.BEGIN()
 - ADDRESS.RANGE.SIZE()
 - ADDRESS.SPACE()
 - ADDRESS.WIDTH()

ADDRESS.ACCESS()

Access class as ordinal number

Syntax:

ADDRESS.ACCESS(<address>)
ADDRESS.SPACE(<address>) (deprecated)

Gets the access class as ordinal number from the address.

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

ADDRESS.ACCESS.CMP()

Compare access classes

[build 110619 - DVD 02/2020]

Syntax:

ADDRESS.ACCESS.CMP(<address1>,<address2>)

Compares the access classes of <address1> and <address2> and returns TRUE if they are equal, FALSE otherwise. Missing information in one address will be neglected and the comparison may still return TRUE if the rest of the access class information is equal.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Examples:

```
PRINT ADDRESS.ACCESS.CMP (NP:0x10,NP:0x60) ; TRUE
PRINT ADDRESS.ACCESS.CMP (N:0x50,NP:0x60) ; TRUE
PRINT ADDRESS.ACCESS.CMP (ND:0x50,NP:0x50) ; FALSE
```

ADDRESS.ACCESS.CMPSTRICT()

Compare access classes, strict

[build 110619 - DVD 02/2020]

Syntax: ADDRESS.ACCESS.CMPSTRICT(<address1>,<address2>)

Compares the access classes of <address1> and <address2> and returns TRUE if they are equal, FALSE otherwise. Missing information in one address will yield the comparison to be FALSE.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Examples:

```
PRINT ADDRESS.ACCESS.CMP (NP:0x10,NP:0x60) ; TRUE
PRINT ADDRESS.ACCESS.CMP (N:0x50,NP:0x60) ; FALSE
PRINT ADDRESS.ACCESS.CMP (ND:0x50,NP:0x50) ; FALSE
```

ADDRESS.EXPANDACCESS()

Fully qualified access class

[build 75614 - DVD 09/2016]

Syntax: ADDRESS.EXPANDACCESS(<address>)

Converts an address combining the passed access class and the current CPU status. The returned access class can be referred to as fully qualified.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

In this example, the passed access classes (C and A) and the returned expanded access classes (NSD and ANSD) belong to an ARM Cortex-A9 with TrustZone, which is in the non-secure supervisor state.

```
PRINT ADDRESS.EXPANDACCESS (C:0x0) ; returns NSD:0x0
PRINT ADDRESS.EXPANDACCESS (A:0x0) ; returns ANSD:0x0
```

Syntax: **ADDRESS.INSTR.LEN(<address>)**

Returns the length in bytes of the instruction at a given address.

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

ADDRESS.isDATA()

Check if memory class refers to data

Syntax: **ADDRESS.isDATA(<address>)**

Returns TRUE when the memory class of the address is referring to data.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Syntax: **ADDRESS.isGUEST(<address>)**

Returns TRUE if the machine ID of the specified <address> belongs to a guest machine in the hypervisor environment. The use of this function requires **SYStem.Option.MACHINESPACES** to be set to **ON**.

Parameter Type: [Address](#). Remember to include the [machine ID](#) in the <address>.

Return Value Type: [Boolean](#).

Examples:

```
SYStem.Option.MACHINESPACES ON

; if the machine ID of an address is > 0, it is a guest address -
; regardless of the access class.
PRINT ADDRESS.isGUEST(D:0x1:::0xC0000000)           ; TRUE

PRINT ADDRESS.isGUEST(D:0x0:::0xC0000000)           ; FALSE
```

Syntax: **ADDRESS.isHYPERVISOR(<address>)**

Returns TRUE if the machine ID of the specified <address> belongs to the host machine where the hypervisor is running. The use of this function requires **SYStem.Option.MACHINESPACES** to be set to **ON**.

Parameter Type: [Address](#). Remember to include the [machine ID](#) in the <address>.

Return Value Type: [Boolean](#).

Examples:

```
SYStem.Option.MACHINESPACES ON

; if the machine ID of an address is 0, it is a hypervisor address -
; regardless of the access class.
PRINT ADDRESS.isHYPERVISOR(D:0x0:::0xC0000000)       ; TRUE

PRINT ADDRESS.isHYPERVISOR(D:0x1:::0xC0000000)       ; FALSE
```

Syntax:

ADDRESS.isINTERMEDIATE(<address>)

Returns TRUE when the memory class of the address is an intermediate address.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

ADDRESS.isNONSECURE()

TRUE if non-secure (TrustZone) access

32-bit and 64-bit ARM cores

[build 77032 - DVD 02/16]

Syntax:

ADDRESS.isNONSECURE(<address>)

Checks if the address passed as parameter will force a non-secure (TrustZone) access.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Example:

```
PRINT ADDRESS.isNONSECURE(AHB:0x0)           ; returns FALSE()
PRINT ADDRESS.isNONSECURE(ZAHB:0x0)          ; returns FALSE()
PRINT ADDRESS.isNONSECURE(NAHB:0x0)          ; returns TRUE()
```

Syntax:

ADDRESS.isNONSECUREEX(<address>)

Checks if the address passed as parameter combined with the current CPU status will cause a non-secure (TrustZone) access. This function is a combination of [ADDRESS.isNONSECURE\(\)](#) and [ADDRESS.EXPANDACCESS\(\)](#).

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

In example 1, the CPU is in non-secure state.

```
Register.Set NS 1 ; non-secure state
PRINT ADDRESS.isNONSECUREEX (AHB:0x0) ; returns TRUE()
PRINT ADDRESS.isNONSECUREEX (ZAHB:0x0) ; returns FALSE()
PRINT ADDRESS.isNONSECUREEX (NAHB:0x0) ; returns TRUE()
```

In example 2, the CPU is in secure state.

```
Register.Set NS 0 ; secure state
PRINT ADDRESS.isNONSECUREEX (AHB:0x0) ; returns FALSE()
PRINT ADDRESS.isNONSECUREEX (ZAHB:0x0) ; returns FALSE()
PRINT ADDRESS.isNONSECUREEX (NAHB:0x0) ; returns TRUE()
```

Syntax:

ADDRESS.MACHINEID(<address>)

Extracts the [machine ID](#) from the specified <address>.

Parameter Type: [Address](#).

Return Value Type: [Decimal value](#).

Examples:

```
SYStem.Option.MACHINESPACES ON

ECHO ADDRESS.MACHINEID (D:0x3:::0xC0000000) ; returns 3.

ECHO ADDRESS.MACHINEID (H:0x0:::0xC0000000) ; returns 0.
```

Syntax:

ADDRESS.MAU(<address>)

Data.MAU(<address>) (deprecated)
[build 42354 - DVD 02/2013]

ADDRESS.WIDTH(<address>) (deprecated)
[build 20337 - DVD 12/2009]

Returns the minimal addressable unit size.


Parameter Type: [Address](#).

Return Value Type: [Decimal value](#).


In this example, the TRACE32 Instruction Set Simulator for ARM is used. The return value 1 means that each address points to 1 byte in memory. The return value 4 means that each address points to 4 bytes in memory.

```
ECHO ADDRESS.MAU(D:0x1)           ;returns 1
Data.dump D:0x1 /Byte /NoAscii

ECHO ADDRESS.MAU(C15:0x1)         ;returns 4
Data.dump C15:0x1 /NoAscii
```



A The address 0x1 of the access class SD: points to 1 byte in memory.



B The address 0x1 of the Coprocessor access class C15: points to 4 bytes in memory.

Syntax:

ADDRESS.OFFSET(<address>)

The <address>-object of TRACE32, which is often returned by other functions, always contains the class and the numerical value of the specific memory address. The function **ADDRESS.OFFSET()** returns that numerical value from <address>. The class is omitted.

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT ADDRESS.OFFSET(SR:0000FF8)           ;returns 0FF8
PRINT ADDRESS.OFFSET(TRACK.ADDRESS())      ;returns 2228
PRINT ADDRESS.OFFSET(sieve)
```

ADDRESS.isONCHIP()

TRUE if on-chip address area

C166

Syntax:

ADDRESS.isONCHIP(<address>)

Returns TRUE when the address refers to on-chip address area.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

ADDRESS.isPHYSICAL()

TRUE if physical address

Syntax:

ADDRESS.isPHYSICAL(<address>)

Returns TRUE when the memory class of the address is a physical address.
Useful to determine if **TRANS.PHYSICAL()** succeed in translating a logical to a physical address.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Syntax:

ADDRESS.isPROGRAM(<address>)

Returns TRUE when the memory class of the address is referring to program.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

ADDRESS.isSECURE()

TRUE if secure (TrustZone) access

32-bit and 64-bit ARM cores

[build 77032 - DVD 02/2016]

Syntax:

ADDRESS.isSECURE(<address>)

Checks if the address passed as a parameter will force a Secure (TrustZone) access.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Example:

```
PRINT ADDRESS.isSECURE(AHB:0x0)           ; returns FALSE()
PRINT ADDRESS.isSECURE(ZAHB:0x0)          ; returns TRUE()
PRINT ADDRESS.isSECURE(NAHB:0x0)          ; returns FALSE()
```

Syntax:

ADDRESS.isSECUREEX(<address>)

Checks if the address passed as a parameter combined with the current CPU status will cause an Secure (TrustZone) access. Basically this function is a combination of [ADDRESS.isSECURE\(\)](#) and [ADDRESS.EXPANDACCESS\(\)](#).

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

In example 1, the CPU is in non-secure state.

```
Register.Set NS 1                                ; non-secure state
PRINT ADDRESS.isSECUREEX(AHB:0x0)                ; returns FALSE()
PRINT ADDRESS.isSECUREEX(ZAHB:0x0)                ; returns TRUE()
PRINT ADDRESS.isSECUREEX(NAHB:0x0)                ; returns FALSE()
```

In example 2, the CPU is in secure state.

```
Register.Set NS 0                                ; secure state
PRINT ADDRESS.isSECUREEX(AHB:0x0)                ; returns TRUE()
PRINT ADDRESS.isSECUREEX(ZAHB:0x0)                ; returns TRUE()
PRINT ADDRESS.isSECUREEX(NAHB:0x0)                ; returns FALSE()
```

Syntax: **ADDRESS.RANGE.BEGIN(<addressrange>)**

Returns the lowest address value from <addressrange>.

Parameter Type: [Address range](#).

Return Value Type: [Address](#).

Example:

```
PRINT ADDRESS.RANGE.BEGIN(P:0x1000--0x2000)           ; returns P:0x1000
PRINT ADDRESS.RANGE.BEGIN(Var.RANGE(flags))
PRINT ADDRESS.RANGE.BEGIN(P:0x20..0x30 || P:0x13++0x03) ; returns P:0x13
```

Syntax: **ADDRESS.RANGE.END(<addressrange>)**

Returns the highest address value from <addressrange>.

Parameter Type: [Address range](#).

Return Value Type: [Address](#).

Examples:

```
PRINT ADDRESS.RANGE.END(P:0x1000--0x2000)           // returns P:0x2000
PRINT ADDRESS.RANGE.END(Var.RANGE(flags))
PRINT ADDRESS.RANGE.END(P:0x20..0x30 || P:0x13++0x03) // returns P:0x30
```

Syntax: **ADDRESS.RANGE.SIZE(<addressrange>)**

Returns the size of an address range.

Parameter Type: [Address range](#).


Return Value Type: [Hex value](#).

Example: In this script, the start and end address of the HLL variable `flags` is calculated as well as the size of its address range. The output to the [AREA.view](#) window is formatted with the [PRINTF](#) command.

```
PRIVATE &rg

&rg="flags"
PRINTF %COLOR.RED "%16s: %s" "address range of" "&rg"
PRINTF "%16s: %#!A" "start" ADDRESS.RANGE.BEGIN(Var.RANGE(&rg))
PRINTF "%16s: %#!A" "end" ADDRESS.RANGE.END(Var.RANGE(&rg))
PRINTF "%16s: %i bytes " "size" ADDRESS.RANGE.SIZE(Var.RANGE(&rg))
PRINTF %CONTINUE "(%#x)" ADDRESS.RANGE.SIZE(Var.RANGE(&rg))

AREA.view
```



Syntax: **ADDRESS.SEGMENT(<address>)**

Returns the segment (space ID) of an address.

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT ADDRESS.SEGMENT(D: 0x012A: 0xC00208A)
```

ADDRESS.STRACCESS()

Access class of an address

[build 51173 - DVD 02/2014]

Syntax: **ADDRESS.STRACCESS(<address>)**

Returns the access class of an address. Useful in combination with [TRANS.PHYSICAL\(\)](#) to verify that the translation was successful and the returned address is really physical or linear.

Parameter Type: [Address](#).

Return Value Type: [String](#).

Example:

```
TRANSlation.Create 0--1000 9000
TRANSlation.ON

PRINT TRANS.PHYSICAL(vm:0)           // returns AVM:9000 (for
                                     // architectures with MMU)

PRINT ADDRESS.OFFSET(TRANS.PHYSICAL(VM:0)) // returns 0x9000

PRINT ADDRESS.STRACCESS(TRANS.PHYSICAL(VM:0)) // returns "AVM:"
```

Analyzer Functions

This figure provides an overview of the return values of some of the Analyzer functions. For descriptions of the illustrated functions and the functions not shown here, see below.

Analyzer.STATE()

Analyzer.RECORDS()

Analyzer.SIZE()

Analyzer.THRESHOLD()

Analyzer.MODE()

Analyzer.TRACK.RECORD()

Analyzer.RECORD.ADDRESS()

Analyzer.RECORD.DATA()

Analyzer.RECORD.TIME()

See also

- ☐ Analyzer()

☐ Analyzer.CONFIG.POWERTRACE()

☐ Analyzer.CONFIG.POWERTRACE3()

☐ Analyzer.CONFIG.POWERTRACESERIAL2()

☐ Analyzer.COUNTER.TIME()

☐ Analyzer.FIRST()

☐ Analyzer.FLOW.FIFOFULL()

☐ Analyzer.ISCHANNELUP()

☐ Analyzer.MODE()

☐ Analyzer.RECORD.ADDRESS()

☐ Analyzer.RECORD.OFFSET()

☐ Analyzer.RECORDS()

☐ Analyzer.SIZE()

☐ Analyzer.THRESHOLD()

☐ Analyzer.TRACK.RECORD()
- ☐ Analyzer.CONFIG()

☐ Analyzer.CONFIG.POWERTRACE2()

☐ Analyzer.CONFIG.POWERTRACESERIAL()

☐ Analyzer.COUNTER.EVENT()

☐ Analyzer.DSEL()

☐ Analyzer.FLOW.ERRORS()

☐ Analyzer.FOCUS.EYE()

☐ Analyzer.MAXSIZE()

☐ Analyzer.PROBEREVISION()

☐ Analyzer.RECORD.DATA()

☐ Analyzer.RECORD.TIME()

☐ Analyzer.REF()

☐ Analyzer.STATE()

☐ Analyzer.TraceCONNECT()

☐ Analyzer.TRIGGER.TIME()

Analyzer()

Check if Analyzer command group is available

Syntax:

Analyzer()

Analyzer.CONFIG() (deprecated)

Returns TRUE in the following cases:

- A TRACE32 trace hardware is connected (not TRACE32 CombiProbe and TRACE32 µTrace (MicroTrace)).
- A TRACE32 Instruction Set Simulator is used.
- A TRACE32 Front-End is used to debug a virtual target that provide trace memory.
- A TRACE32 Front-End is used to debug a RTL simulations / emulations that provides trace capability.

Return Value Type: Boolean.

Analyzer.CONFIG.<powertrace>()

Check if specified PowerTrace connected

Syntax:

Analyzer.CONFIG.<powertrace>()

<powertrace>:

POWERTRACE | POWERTRACE2 | POWERTRACESERIAL | POWERTRACE3

Full function name only required for HELP.Index.

Analyzer.CONFIG.POWERTRACE()
Analyzer.CONFIG.POWERTRACE2()
Analyzer.CONFIG.POWERTRACESERIAL()
Analyzer.CONFIG.POWERTRACESERIAL2()
Analyzer.CONFIG.POWERTRACE3()

Returns TRUE if the connected TRACE32 tool includes the specified PowerTrace type, FALSE otherwise.

<powertrace>	Description
POWERTRACE	Returns TRUE in case of TRACE32 POWERTRACE / ETHERNET.
POWERTRACE2	Returns TRUE in case of TRACE32 POWERTRACE II.
POWERTRACESERIAL	Returns TRUE in case of TRACE32 POWERTRACE SERIAL.
POWERTRACESERIAL2	Returns TRUE in case of TRACE32 POWERTRACE SERIAL II.
POWERTRACE3	Returns TRUE in case of TRACE32 POWERTRACE III.

Return Value Type: Boolean.

Analyzer.COUNTER.EVENT()

Get value of trigger program event counter

NEXUS MPC5XXX MDO8/MDO12/MDO16

Syntax:

Analyzer.COUNTER.EVENT(<counter_name>)

The trigger unit allows to count events by using EVENTCOUNTERs. EVENTCOUNTERs have to be declared in the trigger program by the following command:

EVENTCOUNTER <counter_name> [<event>]

Returns the current value of <counter_name> if the trigger program is loaded.

Parameter Type: String.

Return Value Type: Decimal value.

Syntax: **Analyzer.COUNTER.TIME(<counter_name>)**

The trigger unit allows to count events by using TIMECOUNTERs. TIMECOUNTERs have to be declared in the trigger program by the following command:

TIMECOUNTER <counter_name> [<time>]

Returns the current value of <counter_name> if the trigger program is loaded.

Parameter Type: [String](#).

Return Value Type: [Time value](#).

Syntax: **Analyzer.DSEL()**

Reserved for internal usage.

Return Value Type: [String](#).

[build 71062 - DVD 09/2016]

Syntax: **Analyzer.FIRST()**

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

Syntax: **Analyzer.FLOW.ERRORS()**

Returns the number of flow errors / hard errors found while processing the trace recording.

Return Value Type: [Decimal value](#).

Please be aware that the return value of this function is the accumulated count of events that were encountered while processing the trace recording. All opened windows showing trace data contribute to this value. The value is reset when a new trace recording is made, or when the **Trace.FLOWSTART** or **Trace.FLOWPROCESS** command is executed.

The use of this function is only recommended if you want to find out if a specified part of a trace recording is error free. The part to be analyzed can be defined using **Trace.STATistic.FIRST** and **Trace.STATistic.LAST**. If the defined part is error free (and thus this function returns zero), the analysis results are reliable as well.

Example 1: This script shows how to return only the number of flow errors and hard errors in the trace that is currently visible within the **Analyzer.List** window. If you now scroll up or down in the **Analyzer.List** window or increase the window size, more trace data will be decoded, and thus the number of errors returned by the function may increase.

```
Analyzer.List  
  
PRINT Analyzer.FLOW.ERRORS()  
  
; scroll up or down in the window  
  
PRINT Analyzer.FLOW.ERRORS()
```

Example 2: This script shows how to obtain the exact number of flow errors in the whole trace recording.

```
Trace.Find FLOWERROR /ALL  
PRINT FOUND.COUNT()
```

Analyzer.FLOW.FIFOFULL()

Get number of FIFO overflows

Syntax: **Analyzer.FLOW.FIFOFULL()**

Returns the number of **FIFO overflows** found while processing the trace recording.

Return Value Type: **Decimal value.**

Please be aware that the return value of this function is the accumulated count of events that were encountered while processing the trace recording. All opened windows showing trace data contribute to this value. The value is reset when a new trace recording is made, or when the **Trace.FLOWSTART** or **Trace.FLOWPROCESS** command is executed.

The use of this function is only recommended if you want to find out if a specified part of a trace recording is error free. The part to be analyzed can be defined using **Trace.STATistic.FIRST** and **Trace.STATistic.LAST**. If the defined part is error free (and thus this function returns zero), the analysis results are reliable as well.

Example: This script shows how to obtain the exact number of FIFO overflows in the whole trace recording.

```
Analyzer.Find FIFOFULL /ALL  
PRINT FOUND.COUNT()
```

Syntax:

Analyzer.FOCUS.EYE(<channel>,<c_time>,<c_voltage>,<tm>,<am>,<n>)

Checks a data eye previously scanned by the [Analyzer.TestFocusEye](#) command against violations. This function allows you to determine the quality of a data eye via a PRACTICE script, and not just through visual inspection.

Parameter and Description: Use the following parameters to define the region of interest (ROI) that you want to check within the data eye:

<channel>	Parameter Type: String . For a list of channel names, refer to the Analyzer.ShowFocusEye command. To check all channels, use "all"
<c_time>, <c_voltage>	Parameter Type: Float . Time is given on the x-axis, voltage is given on the y-axis. The intersection of the two values defines the center C of the ROI.
<tm>	Parameter Type: Float . Time
<am>	Parameter Type: Float . Voltage
<n>	Parameter Type: Float . Changes the ROI from a rectangle to a hexagon. Rectangle: n = 1.0 Hexagon: n > 1.0 The greater n , the wider the hexagon.

Return Value Type: [Hex value](#).

Example: The function returns 0 if the data eye is clean, and it returns non-zero if there is anything in the data eye. The last tested pattern is shown in the [Analyzer.ShowFocusEye](#) window.

```
LOCAL &val

;Check the quality of the data eye for channel TS
&val=Analyzer.FOCUS.EYE(TS,0.0,1.65,2.0,0.7,1.0)
IF &val==0
    PRINT "Data eye is OK"

;Check the quality of the data eye for all channels
PRINT Analyzer.FOCUS.EYE("all",3.0,0.9,4.0,0.5,2.0)
```

Check if serial link is established

Syntax: **Analyzer.ISCHANNELUP()**

In the case of FALSE you have to repeat the channel training.

Return Value Type: Boolean.

Syntax:

Analyzer.MAXSIZE()

Returns the maximum size of the Analyzer trace buffer in records if a TRACE32 trace hardware is connected.

Returns the current size of the Analyzer trace buffer in records if a TRACE32 Instruction Set Simulator or a TRACE32 Front-End is used.

Return Value Type: [Decimal value](#).

Analyzer.MODE()

Get Analyzer recording mode

Syntax:

Analyzer.MODE()

Returns the current recording mode of the analyzer.

Return Value Type: [Decimal value](#).

Return Value and Description:

0	Fifo mode
1	Stack mode
2	Leash mode
3	PIPE mode
4	RTS mode (real time profiling)
5	STREAM mode (endless trace)

Analyzer.MODE.FLOW()

Check if Analyzer operates as flowtrace

[\[Go to figure\]](#)

Syntax:

Analyzer.MODE.FLOW() (deprecated)

Returns TRUE if the analyzer operates as **FlowTrace**.

Return Value Type: [Boolean](#).

Syntax:	Analyzer.PCIE.CONFIG("<register_field>")
<i><register_field></i> :	DeviceID VendorID STATus CoMmanD ClassCode REVision HeaderType BaseAddressRegister0 BaseAddressRegister1 BaseAddressRegister2 BaseAddressRegister3 BaseAddressRegister4 BaseAddressRegister5 SubsystemID SubsystemVendorID MaxPayloadSizeSupported MaxPayloadSize MaxLinkSpeed MaxLinkWidth LinkSpeed LinkWidth

Returns the value of the specified register field from the PCIe configuration space of the analyzer.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Syntax: **Analyzer.PCIE.ISCONFIGURED()**

Returns TRUE if the analyzer configuration is complete, so that the PCIe link can be used for data transfer.

Return Value Type: [Boolean](#).

Example 1: This script checks if the manual PCIe trace setup performed in the previous steps was successful. The previous setup steps are not shown in this script.

```
IF Analyzer.PCIE.ISCONFIGURED()==FALSE()  
(  
    IF Analyzer.ISCHANNELUP()==FALSE()  
        ;PCIe hardware link is down  
    ELSE  
        ;PCIe link is up, but configuration is not complete  
)
```

Example 2: This script instructs TRACE32 to wait until the target operating system has successfully configured the analyzer for PCIe trace.

```
SCREEN.WAIT Analyzer.ISCHANNELUP()  
SCREEN.WAIT Analyzer.PCIE.ISCONFIGURED()  
SYSTEM.Mode.Attach  
Break  
...
```

Syntax: **Analyzer.PCIE.Register(<register_offset>)**

Returns the value of the specified 32-bit register from the PCIe configuration space of the analyzer. The register offset is given in 32-bit increments.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#). Range: **0**. to **1023**.

Return Value Type: [Hex value](#).

Syntax:

Analyzer.PROBEREVISION()

Returns the revision number of the NEXUS probe.The StarCore NEXUS probe is out of production since 2010.

Return Value Type: [Decimal value](#).

Analyzer.RECORDS()

Get number of used trace records

[\[Go to figure\]](#)

Syntax:

Analyzer.RECORDS()

Returns the number of records in the Analyzer.

If the state is **OFF** and the current mode is **STREAM**, this function will block until all buffered data has been received.

Return Value Type: [Decimal value](#).

Analyzer.RECORD.ADDRESS()

Get address recorded in trace record

[\[Go to figure\]](#)

Syntax:

Analyzer.RECORD.ADDRESS(<record_number>)

Returns the address from the specified record of the Analyzer trace. If the specified record does not contain an address C:0x0 is returned.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

Example 1:

```
PRINT Analyzer.RECORD.ADDRESS(-9.)           ;return value example: R:0x226C
```

Example 2: This example shows how to return the address recorded in the reference record. The address is then used to display the memory contents of the trace reference record in a **Data.dump** window.

```
Analyzer.List Default /Track ;open an Analyzer.List window
Analyzer.REF -11895.         ;set this trace record as reference record
Analyzer.GOTO Analyzer.REF() ;go to the specified trace reference record

;get the address of the trace reference record, and then display the
;memory contents for this trace reference record in a Data.dump window
Data.dump Analyzer.RECORD.ADDRESS(Analyzer.REF()) /Track
```

In the **Analyzer.List** window, right-click another trace record, and then select **Set Ref**. After you have set a new trace reference record, the **Data.dump** window updates accordingly because of the **Track** option.

Analyzer.RECORD.DATA()

Get data recorded in trace record

[\[Go to figure\]](#)

Syntax:

Analyzer.RECORD.DATA(<record_number>)

Returns the data from the specified record of the Analyzer trace. If the specified record does not contain data the function returns 0FFFFFFFFFFFFFFF.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Analyzer.RECORD.OFFSET()

Get address in trace record as number

Syntax:

Analyzer.RECORD.OFFSET(<record_number>)

Returns the number within the address from the specified record of the Analyzer trace. If the specified record does not contain an address 0 is returned.

```
PRINT Analyzer.RECORD.ADDRESS(-100.)      ; prints NR:0xFFFF:0xC0014A08

PRINT Analyzer.RECORD.OFFSET(-100.)      ; prints 0xC0014A08
```

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Syntax: **Analyzer.RECORD.TIME(<record_number>)**

Returns the timestamp of the specified record in fixed length format. The timestamp is relative to the trace zero point. For details refer to [Trace.ZERO](#).

If the record does not provide timing information (dummy record), the timestamp of the preceding record is returned.

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

Example:

```
Trace.List %TimeFixed Time.ZERO Default /Track

PRINT Analyzer.RECORD.TIME(-119700.)
```

The screenshot shows the debugger's trace window and command window. The trace window displays a list of records with timestamps. The record at address 12.008408300s is highlighted, and its timestamp is shown in the command window.

record	i.zero	run	address	cycle	data	symbol
684	12.008408000s		R:00002234	fetch	E3520012	\\armle\\arm\\sieve+0x0C
-119702	12.008408100s		R:00002238	fetch	DA000006	\\armle\\arm\\sieve+0x10
-119701	12.008408200s		R:00002258	fetch	EAF00000	\\armle\\arm\\sieve+0x30
-119700	12.008408300s		R:00002240	fetch	E3A04001	\\armle\\arm\\sieve+0x18
684	12.008408400s		R:00002244	fetch	E1A0E002	\\armle\\arm\\sieve+0x1C
-119699	12.008408400s		R:00002248	fetch	E0822004	\\armle\\arm\\sieve+0x20
-119698	12.008408500s					

The command window shows the command: `B::PRINT Analyzer.RECORD.TIME(-119700.)` and the result: `12.008408300s`.

Syntax:

Analyzer.REF()

The command **Analyzer.REF** allows to mark a trace record as reference record. The function returns the record number of the reference record.

Return Value Type: [Decimal value](#).

Analyzer.SIZE()

Get current trace buffer size in records

[\[Go to figure\]](#)

Syntax:

Analyzer.SIZE()

Returns the current size of the trace buffer in records.

Return Value Type: [Decimal value](#).

Analyzer.STATE()

Get state of Analyzer

[\[Go to figure\]](#)

Syntax:

Analyzer.STATE()

Returns the current state of the Analyzer. If the state is **OFF** and the current mode is **STREAM**, this function will block until all buffered data has been received.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state
5	Analyzer hardware not available.
9	OFF state, but data is still being processed (PIPE and RTS modes only)

Syntax:

Analyzer.THRESHOLD()

Returns the threshold voltage of the parallel preprocessor.

Return Value Type: [Float](#).

Syntax:

Analyzer.TraceCONNECT()

Returns the name of the currently selected trace sink of the SoC. In case no trace-sink is selected/available, the function returns **NONE**. The trace sink is selected with the [<trace>.TraceCONNECT](#) command.

Return Value Type: [String](#).

Example: See [Onchip.TraceCONNECT\(\)](#).

Syntax: **Analyzer.TRACK.RECORD()**

After a successful search operation, this function returns the record number.

Return Value Type: [Decimal value](#).

Example: This example shows how to search for and return the record numbers of the first, second, and all records of the symbol **sieve**.

```
; Finds the first occurrence of the symbol sieve  
Trace.Find , Address sieve  
; Returns the record number of the first occurrence  
IF FOUND()  
    PRINT Analyzer.TRACK.RECORD()  
  
; Search for the next occurrence of the symbol sieve  
Trace.Find ; Running the command without any arguments  
            ; repeats the previous search  
; Returns the record number of the next occurrence  
IF FOUND()  
    PRINT Analyzer.TRACK.RECORD()
```

Syntax: **Analyzer.TRIGGER.TIME()**

Returns the time of the trigger point in the trace.

Return Value Type: [Time value](#).




Example:

```
;define trace trigger point at function entry of func20()
Break.Set func20 /TraceTrigger

;and trace a little bit longer
Trace.TDelay 1%

;run program for trace recording
...

;show statistics +/-100 us around the trigger point at func20()
PRINT Analyzer.TRIGGER.TIME()
Trace.STATistic.FIRST Analyzer.TRIGGER.TIME()-100.us
Trace.STATistic.LAST  Analyzer.TRIGGER.TIME()+100.us
Trace.STATistic.sYmbol
```



ARMARCHVERSION()

ARM architecture version of CPU

ARM debuggers

[build 57602 - DVD 02/2015]

Syntax:

ARMARCHVERSION(["<parameter>"])

<parameter>:

minor

major

Returns the ARM architecture version of the selected CPU.

The parameter is optional (see table below).


Return Value Type: [Decimal value](#).

Return Value and Description:

Parameter	Return value	Description
None	0x0	ARMv4 / ARM7
	0x1	ARMv4 / ARM9
	0x5	ARMv5
	0x6	ARMv6
	0x7	ARMv7
	0x8	Armv8
	0x8<x>	Armv8.x, e.g. 0x81 for Armv8.1
	0x9<x>	Armv9.x, e.g. 0x91 for Armv9.1
minor	Returns minor version number. E.g. ARMARCHVERSION("minor") returns "0x1" for Armv8.1.	
major	Returns major version number. E.g. ARMARCHVERSION("major") returns "0x8" for Armv8.1.	

Advanced Register Trace (ART) Functions

This figure provides an overview of the return values of some of the ART functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- | | | | |
|-------------------------------------|-----------------------------------|------------------------------------|--------------------------------------|
| ART.FIRST() | ART.MAXSIZE() | ART.MODE() | ART.RECORD.ADDRESS() |
| ART.RECORD.OFFSET() | ART.RECORD.TIME() | ART.RECORDS() | ART.REF() |
| ART.SIZE() | ART.STATE() | ART.TRACK.RECORD() | |

ART.FIRST()

Get record number of first trace record

[build 71062 - DVD 09/2016]

Syntax:

ART.FIRST()

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

Syntax:

ART.MAXSIZE()

Returns the maximum possible size of the ART trace buffer in records.

Return Value Type: [Decimal value](#).

Syntax:

ART.MODE()

Returns the current recording mode of the ART.

Return Value Type: [Decimal value](#).

Return Value and Description:

0	Fifo mode
1	Stack mode

Syntax:

ART.RECORD.ADDRESS(<record_number>)

Returns the sampled address (access class and offset) from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

Syntax: **ART.RECORD.OFFSET(<record_number>)**

Returns the address-offset of the sampled address from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Syntax: **ART.RECORD.TIME(<record_number>)**

Returns the timestamp of the specified record. For an example, see [Analyzer.RECORD.TIME\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

Syntax: **ART.RECORDS()**

Returns the number of records stored in the trace buffer.

Return Value Type: [Decimal value](#).

Syntax: **ART.REF()**

The number of the selected reference record in the analyzer trace.

Return Value Type: [Decimal value](#).

Syntax:

ART.SIZE()

Returns the size of the trace buffer.

Return Value Type: [Decimal value](#).

Syntax:

ART.STATE()

Returns the state of the ART trace.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

Syntax:

ART.TRACK.RECORD()

After a successful search operation, this function returns the record number. For an example, see [Analyzer.TRACK.RECORD\(\)](#).

Return Value Type: [Decimal value](#).

In This Section

See also

- [AUTOFOCUS\(\)](#)
- [AUTOFOCUS.OK\(\)](#)
- [AUTOFOCUS.FREQUENCY\(\)](#)

AUTOFOCUS()

TRUE if AutoFocus preprocessor attached

[build 07808 - DVD 09/2007]

Syntax:

AUTOFOCUS()

Returns TRUE if an AutoFocus preprocessor is attached.

Return Value Type: [Boolean](#).

AUTOFOCUS.OK()

TRUE if command execution successful

[build 23129, DVD 11/2010]

Syntax:

AUTOFOCUS.OK()

Returns TRUE if the last execution of the command [Analyzer.AutoFocus](#) or [Analyzer.TestFocus](#) was successful.

Return Value Type: [Boolean](#).

AUTOFOCUS.FREQUENCY()

Frequency of trace-port clock

[build 23129, DVD 11/2010]

Syntax:

AUTOFOCUS.FREQUENCY()

Returns the frequency of the trace-port clock detected by the last execution of the command [Analyzer.AutoFocus](#) or [Analyzer.TestFocus](#) was successful.

Return Value Type: [Decimal value](#).

In This Section

See also

- AVX
- AVX512
- AVX()
- AVX512()

AVX()

Content of AVX register

Syntax: **AVX(<register_name>.<column_number>)**

Returns a 32-bit segment of the selected 256-bit AVX register. See also [AVX](#) command group.

Parameter Type: [String](#).


Parameter and Description:

<register_name>	The register names are listed in the AVX.view window.
<column_number>	The column numbers start at 0 and are read from right to left in the AVX.view window. See example below. A column <i>k</i> corresponds to the bit range $(k \cdot 32 + 31) - (k \cdot 32)$, where $0 \leq k \leq 7$

Return Value Type: [Hex value](#).

Example: This demo script returns 32-bit values of the register **YMM1** from the column **0** (bits 31 to 0) and the column **7** (bits 255 to 224) of the [AVX.view](#) window.

```
AVX.view
AVX.Set YMM1 123 243 345 67 689 789 809 9009
PRINT "Register|Bit Range|Col.|Value"
PRINT " YMM1 | 31-0 | 0 | " AVX(YMM1.0) ;32-bit value from col. 0
PRINT " YMM1 | 255-224 | 7 | " AVX(YMM1.7) ;32-bit value from col. 7
```



A Register names. **0 - 7** Column numbers - from right to left - in the [AVX.view](#) window.

Syntax:

AVX512(<register_name>.<column_number>)

Returns a 32-bit segment of the selected 512-bit AVX512 register. See also [AVX512](#) command group.

Parameter Type: [String](#).

Parameter and Description:

<register_name>	The register names are listed in the AVX512.view window.
<column_number>	The column numbers start at 0 and are read from right to left in the AVX512.view window. For an example, refer to the related function AVX(). A column k corresponds to the bit range $(k \cdot 32 + 31) - (k \cdot 32)$, where $0 \leq k \leq 15$

Return Value Type: [Hex value](#).

In This Section

See also

- [Break.Alpha.EXIST\(\)](#)
- [Break.Beta.EXIST\(\)](#)
- [Break.Charly.EXIST\(\)](#)
- [Break.Program.EXIST\(\)](#)
- [Break.ReadWrite.EXIST\(\)](#)

Break.Alpha.EXIST()

TRUE if Alpha breakpoint exists

[build 75340 - DVD 09/2016]

Syntax:

Break.Alpha.EXIST(<address>)

Returns TRUE if an Alpha breakpoint exists.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Example:

```
List.Mix                                ;optional step: display a listing

Break.Set func2 /Alpha                  ;set an Alpha breakpoint at the
                                        ;symbol 'func2'

PRINT Break.Alpha.EXIST(func2)          ;returns TRUE, i.e. the Alpha breakpoint
                                        ;exists at the symbol 'func2'
```

Break.Beta.EXIST()

TRUE if Beta breakpoint exist

[build 75340 - DVD 09/2016]

Syntax:

Break.Beta.EXIST(<address>)

Returns TRUE if a Beta breakpoint exists.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Syntax: **Break.Charly.EXIST(<address>)**

Returns TRUE if a Charly breakpoint exists.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Syntax: **Break.Program.EXIST(<address>)**

Returns TRUE if an enabled program breakpoint exists at the given address location.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Syntax: **Break.ReadWrite.EXIST(<address>)**

Returns TRUE if an enabled data address breakpoint (read, write, or read-write) exists at the given address location.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

In This Section

See also

- [BMC](#)
 - [BMC.COUNTER\(\)](#)
 - [BMC.COUNTER.BYNAME.CORE\(\)](#)
 - [BMC.OVERFLOW\(\)](#)
 - [BMC.OVERFLOW.BYNAME.CORE\(\)](#)
- [BMC.CLOCK\(\)](#)
 - [BMC.COUNTER.BYNAME\(\)](#)
 - [BMC.COUNTER.CORE\(\)](#)
 - [BMC.OVERFLOW.BYNAME\(\)](#)
 - [BMC.OVERFLOW.CORE\(\)](#)

BMC.CLOCK()

Frequency of core clock

[build 72352 - DVD 09/2016]

Syntax:

BMC.CLOCK()

Returns the frequency set with the **BMC.CLOCK** command.

Return Value Type: [Decimal value](#).

BMC.COUNTER()

Value of a benchmark counter

Syntax:

BMC.COUNTER(<counter_index>)

Returns the counter value of the benchmark counter with the specified index. See also **BMC** command group. In a multicore environment, the **BMC.COUNTER()** function returns the accumulated value of all cores.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Example: For PMN**3** use BMC.COUNTER(**3**).

```
PRINT BMC.COUNTER(3) ;prints the result to the TRACE32 message line
```

Syntax:

BMC.COUNTER.BYNAME("<counter_name>")

Returns the counter value of the benchmark counter with the specified name. See also **BMC** command group. In a multicore environment, the **BMC.COUNTER.BYNAME()** function returns the accumulated value of all cores.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example: For ETM1 use BMC.COUNTER.BYNAME("ETM1").

```
;prints the result to the TRACE32 message line
PRINT BMC.COUNTER.BYNAME ( "ETM1 " )
```

Syntax:

BMC.COUNTER.CORE(<counter_index>, <core_index>)

Returns the counter value of the benchmark counter of the specified core and index. See also **BMC** command group.

Parameter and Description:

<counter_index>	Parameter Type: Decimal value .
<core_index>	Parameter Type: Decimal value .

Return Value Type: [Hex value](#).

Example: For PMN**3** of core **#1** use BMC.COUNTER.CORE(**3**, **1**).

```
;prints the result to the TRACE32 message line
PRINT BMC.COUNTER.CORE ( 3 , 1 )
```

Syntax: **BMC.COUNTER.BYNAME.CORE**("<counter_name>", <core_index>)

Returns the counter value of the benchmark counter with the specified name. See also **BMC** command group. In a multicore environment, the **BMC.COUNTER.BYNAME.CORE()** function returns the accumulated value of all cores.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example: For PMN0 of core #1 use **BMC.COUNTER.CORE**("PMN0", 1).

```
;prints the result to the TRACE32 message line  
PRINT BMC.COUNTER.BYNAME.CORE ( " PMN0 " , 1)
```

BMC.OVERFLOW()

TRUE if benchmark counter overflow

[build 72015 - DVD 08/2016]

Syntax: **BMC.OVERFLOW**(<counter_index>)

Returns TRUE if the benchmark counter has overflown. In a multicore environment, the **BMC.OVERFLOW** function returns the OR'ed overflow status of all cores.

Parameter Type: [Decimal value](#).

Return Value Type: [Boolean](#).

BMC.OVERFLOW.BYNAME()

TRUE if benchmark counter overflow

[build 72015 - DVD 08/2016]

Syntax: **BMC.OVERFLOW.BYNAME**(<counter_name>)

Returns TRUE if the benchmark counter has overflown. In a multicore environment, the **BMC.OVERFLOW.BYNAME()** function returns the OR'ed overflow status of all cores.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Syntax:

BMC.OVERFLOW.CORE(<counter_index>, <core_index>)

Returns TRUE if the benchmark counter of the specified core has overflown.

Parameter and Description:

<counter_index>	Parameter Type: Decimal value .
<core_index>	Parameter Type: Decimal value .

Return Value Type: [Boolean](#).

Syntax:

BMC.OVERFLOW.BYNAME.CORE("<counter_name>", <core_index>)

Returns TRUE if the benchmark counter of the specified core has overflown.

Parameter and Description:

<counter_name>	Parameter Type: String .
<core_index>	Parameter Type: Decimal value .

Return Value Type: [Boolean](#).

In This Section

See also

- [BSDL](#)
 - [BSDL.CHECK.FLASHCONF\(\)](#)
 - [BSDL.GetDRBit\(\)](#)
- [BSDL.CHECK.BYPASS\(\)](#)
 - [BSDL.CHECK.IDCODE\(\)](#)
 - [BSDL.GetPortLevel\(\)](#)

BSDL.CHECK.BYPASS()

Chain bypass test

[build 28569 - DVD 06/2011]

Syntax:

BSDL.CHECK.BYPASS()

Executes a boundary scan BYPASS test and returns TRUE if it passes.

Return Value Type: [Boolean](#).

BSDL.CHECK.FLASHCONF()

Flash configuration test

[build 28569 - DVD 06/2011]

Syntax:

BSDL.CHECK.FLASHCONF()

Checks the FLASH definition and the pin mapping for the boundary scan interface; returns TRUE, when FLASH configuration has no errors.

Return Value Type: [Boolean](#).

BSDL.CHECK.IDCODE()

Chain IDCODE test

[build 28569 - DVD 06/2011]

Syntax:

BSDL.CHECK.IDCODE()

Executes a boundary scan IDCODE test and returns TRUE if it passes.

Return Value Type: [Boolean](#).

Syntax:

BSDL.GetDRBit(<chip_number>,<bit_number>)

Returns the last read value of bit <bit_number> from chip <chip_number>. If the requested bit was not read before, -1 is returned.

Parameter and Description:

<chip_number>	Parameter Type: Decimal or hex or binary value . Number of IC in the boundary scan chain. Range: 1. to <n>.
<bit_number>	Parameter Type: Decimal or hex or binary value . Bit index of the current data register. Range: 0. to <i>.

Return Value Type: [Decimal value](#).

Syntax:

BSDL.GetPortLevel(<chip_number>,"<port_name>")

Returns the port level of <port_name> from chip <chip_number> from the last boundary scan capture.

Parameter and Description:

<chip_number>	Parameter Type: Decimal or hex or binary value . Number of IC in the boundary scan chain. Range: 1. to <n>.
<port_name>	Parameter Type: String . Valid port name from the BSDL file for the specified <chip_number>.

Return Value Type: [Decimal value](#).

Return Value and Description:

0	Low signal level
1	High signal level
2	Unknown level (e.g. floating output port)
-1	Error

In This Section

See also

- ❑ [CABLE.GalvanicISolation\(\)](#)
 - ❑ [CABLE.GalvanicISolation.SERIAL\(\)](#)
 - ❑ [CABLE.SERIAL\(\)](#)
- ❑ [CABLE.GalvanicISolation.FIRMWARE\(\)](#)
 - ❑ [CABLE.NAME\(\)](#)
 - ❑ [CABLE.TWOWIRE\(\)](#)

CABLE.GalvanicISolation()

Cable has galvanic isolation

[build 81072 - DVD 02/2017]

Syntax:

CABLE.GalvanicISolation()

Returns TRUE if the cable has galvanic isolation.

Return Value Type: [Boolean](#).

CABLE.GalvanicISolation.FIRMWARE()

Adapter firmware version

[build 81097 - DVD 02/2017]

Syntax:

CABLE.GalvanicISolation.FIRMWARE()

Return the firmware version of the galvanic isolation adapter as a string. The same string is also shown in the [VERSION.HARDWARE](#) window. An empty string is returned if no adapter is plugged.

Return Value Type: [String](#).

CABLE.GalvanicISolation.SERIAL()

Serial number of adapter

[build 81072 - DVD 02/2017]

Syntax:

CABLE.GalvanicISolation.SERIAL()

Returns the serial number of the galvanic isolation adapter. The same serial number is also shown in the [VERSION.HARDWARE](#) window. An empty string is returned if no adapter is plugged.

Return Value Type: [String](#).

Syntax:

CABLE.NAME()

Returns the debug cable name. The same cable name is also shown in the **VERSION.HARDWARE** window.

Return Value Type: **String**.

Example:

```
PRINT CABLE.NAME()      ; Returns the cable name, e.g.:
                        ; - OCDS Uni-Dir Debug Cable V0
                        ; - ARM Debug Cable V4b
```

Syntax:

CABLE.SERIAL()

Returns the first serial number of the plugged debug cable. It is the same serial number that is also shown in the **VERSION.HARDWARE** window.

Return Value Type: **String**.

Syntax:

CABLE.TWOWIRE()

Returns TRUE if the used debug hardware supports two-wire debugging like cJTAG or SWD.

Return Value Type: **Boolean**.

Example:

```
;Check if the cpu family is ARM. If not, the block is skipped.
IF CPUFAMILY()=="ARM"
(
    IF CABLE.TWOWIRE() ;DebugCable supports Serial Wire Debug (SWD)?
        SYStem.CONFIG SWD
)
```

In This Section

The CACHE functions give access to the status data of all cache lines, e.g. Valid, Dirty tag address and others. Cache lines are addressed by their Set and Way indices.

If the target processor implements an L1 Unified Cache (used for both instruction and data), use the **CACHE.IC** functions to access the status information.

See also

■ CACHE	❑ CACHE.DC.DIRTY()	❑ CACHE.DC.DIRTYMASK()	❑ CACHE.DC.LRU()
❑ CACHE.DC.TAG()	❑ CACHE.DC.VALID()	❑ CACHE.DC.VALIDMASK()	❑ CACHE.IC.DIRTY()
❑ CACHE.IC.DIRTYMASK()	❑ CACHE.IC.LRU()	❑ CACHE.IC.TAG()	❑ CACHE.IC.VALID()
❑ CACHE.IC.VALIDMASK()	❑ CACHE.L2.DIRTY()	❑ CACHE.L2.DIRTYMASK()	❑ CACHE.L2.LRU()
❑ CACHE.L2.SHARED()	❑ CACHE.L2.SHAREDMASK()	❑ CACHE.L2.TAG()	❑ CACHE.L2.VALID()
❑ CACHE.L2.VALIDMASK()	❑ CACHE.L3.DIRTY()	❑ CACHE.L3.DIRTYMASK()	❑ CACHE.L3.LRU()
❑ CACHE.L3.TAG()	❑ CACHE.L3.VALID()	❑ CACHE.L3.VALIDMASK()	

CACHE.DC.DIRTY()

Dirty-flag of L1 Data Cache Line

Syntax:

CACHE.DC.DIRTY(<set>,<way>)

Returns TRUE if the specified set/way of the data cache is DIRTY.

On processors with unified L1 cache, use **CACHE.IC.DIRTY()**.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

Syntax:

CACHE.DC.DIRTYMASK(<set>,<way>)

Returns a value containing all DIRTY flags of the specified set/way of the data cache. Use for caches with multiple DIRTY flags/sectors per cache line.

On processors with unified L1 cache, use **CACHE.IC.DIRTYMASK()**.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

[build 52317]

Syntax:

CACHE.DC.LRU(<set>)

Returns the index of the least recently used (next to be replaced) way of the specified set. Only a few processors provide this information.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

Syntax:

CACHE.DC.TAG(<set>,<way>)

Returns the address tag of the specified set/way of the data cache.

On processors with unified L1 cache, use **CACHE.IC.TAG()**.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

Syntax:

CACHE.DC.VALID(<set>,<way>)

Returns TRUE if the specified set/way of the data cache is VALID.

On processors with unified L1 cache, use **CACHE.IC.VALID()**.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

Syntax:

CACHE.DC.VALIDMASK(<set>,<way>)

Returns a value containing all VALID flags of the specified set/way of the data cache. Use for caches with multiple valid flags/sectors per cache line.

Use **CACHE.IC.VALIDMASK()** for systems with unified L1 cache.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

CACHE.IC.DIRTY()

Dirty-flag of L1 Unified Cache Line

Syntax:

CACHE.IC.DIRTY(<set>,<way>)

Returns TRUE if the specified set/way of the unified L1 cache is DIRTY. For instruction caches, the result is always FALSE.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

CACHE.IC.DIRTYMASK()

Dirty-flag mask of L1 Unified Cache Line

Syntax:

CACHE.IC.DIRTYMASK(<set>,<way>)

For processors with unified L1 cache. Returns a value containing all DIRTY flags of the specified set/way of the cache line, and zero for pure instruction caches. Use for caches with multiple dirty flags/sectors per cache line.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

CACHE.IC.LRU()

LRU information of L1 Instruction Cache Line

[build 52317]

Syntax:

CACHE.IC.LRU(<set>)

Returns the index of the least recently used (next to be replaced) way of the specified set. Only a few processors provide this information.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

Syntax:

CACHE.IC.TAG(<set>,<way>)

Returns the address tag of the specified set/way of the instruction (or unified) cache.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

CACHE.IC.VALID()

Valid-flag of L1 Instruction Cache Line

Syntax:

CACHE.IC.VALID(<set>,<way>)

Returns TRUE if the specified set/way of the instruction (or unified) cache is VALID.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

CACHE.IC.VALIDMASK()

Valid-flag mask of L1 Instruction Cache Line

Syntax:

CACHE.IC.VALIDMASK(<set>,<way>)

Returns a value containing all VALID flags of the specified set/way of the instruction (or unified) cache. Use for caches with multiple valid flags/sectors per cache line.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

Syntax:

CACHE.L2.DIRTY(<set>,<way>)

Returns TRUE if the specified set/way of the L2 cache has the DIRTY flag set. If the cache ways are split up in sectors, the result is true if at least one of the DIRTY flags is set.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

Syntax:

CACHE.L2.DIRTYMASK(<set>,<way>)

Returns a value containing all DIRTY flags of the specified set/way of the L2 cache. Use for caches with multiple dirty flags/sectors per cache line.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

[build 52317]

Syntax:

CACHE.L2.LRU(<set>)

Returns the index of the least recently used (next to be replaced) way of the specified set. Only a few processors provide this information.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

Syntax:

CACHE.L2.SHARED(<set>,<way>)

Returns TRUE if the specified set/way of the L2 cache has the SHARED flag set. If the cache ways are split up in sectors, the result is true if at least one of the SHARED flags is set.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

CACHE.L2.SHAREDMASK()

Shared-flag mask of L2 Cache Line

Syntax:

CACHE.L2.SHAREDMASK(<set>,<way>)

Returns a value containing all SHARED flags of the specified set/way of the L2 cache. Use for caches with multiple shared flags/sectors per cache line.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

CACHE.L2.TAG()

Address Tag of L2 Cache Line

Syntax:

CACHE.L2.TAG(<set>,<way>)

Returns the address tag of the specified set/way of the L2 cache.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

Syntax:

CACHE.L2.VALID(<set>,<way>)

Returns TRUE if the specified set/way of the L2 cache has the VALID flag set. If the cache ways are split up in sectors, the result is true if at least one of the VALID flags is set.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

Syntax:

CACHE.L2.VALIDMASK(<set>,<way>)

Returns a value containing all VALID flags of the specified set/way of the L2 cache. Use for caches with multiple valid flags/sectors per cache line.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

Syntax:

CACHE.L3.DIRTY(<set>,<way>)

Returns TRUE if the specified set/way of the L3 cache has the DIRTY flag set. If the cache ways are split up in sectors, the result is true if at least one of the DIRTY flags is set.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

Syntax:

CACHE.L3.DIRTYMASK(<set>,<way>)

Returns a value containing all DIRTY flags of the specified set/way of the L3 cache. Use for caches with multiple dirty flags/sectors per cache line.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

Syntax:

CACHE.L3.LRU(<set>)

Returns the index of the least recently used (next to be replaced) way of the specified set. Only a few processors provide this information.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

Syntax:

CACHE.L3.TAG(<set>,<way>)

Returns the address tag of the specified set/way of the L3 cache.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

Syntax:

CACHE.L3.VALID(<set>,<way>)

Returns TRUE if the specified set/way of the L3 cache has the VALID flag set. If the cache ways are split up in sectors, the result is true if at least one of the VALID flags is set.

Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Boolean](#).

Syntax:

CACHE.L3.VALIDMASK(<set>,<way>)

Returns a value containing all VALID flags of the specified set/way of the L3 cache. Use for caches with multiple valid flags/sectors per cache line.


Parameter and Description:

<set>	Parameter Type: Decimal or hex or binary value .
<way>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

CAnalyzer Functions

This figure provides an overview of the return values of some of the CAnalyzer functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- [CAnalyzer\(\)](#)
- [CAnalyzer.CableTYPE\(\)](#)
- [CAnalyzer.FEATURE\(\)](#)
- [CAnalyzer.MAXSIZE\(\)](#)
- [CAnalyzer.RECORD.ADDRESS\(\)](#)
- [CAnalyzer.RECORD.OFFSET\(\)](#)
- [CAnalyzer.RECORDS\(\)](#)
- [CAnalyzer.SIZE\(\)](#)
- [CAnalyzer.TraceCLOCK\(\)](#)
- [CAnalyzer.TracePort\(\)](#)
- [CAnalyzer.BOTHCables\(\)](#)
- [CAnalyzer.DebugCable\(\)](#)
- [CAnalyzer.FIRST\(\)](#)
- [CAnalyzer.PIN\(\)](#)
- [CAnalyzer.RECORD.DATA\(\)](#)
- [CAnalyzer.RECORD.TIME\(\)](#)
- [CAnalyzer.REF\(\)](#)
- [CAnalyzer.STATE\(\)](#)
- [CAnalyzer.TraceCONNECT\(\)](#)
- [CAnalyzer.TRACK.RECORD\(\)](#)

Syntax:

CAAnalyzer()

Returns TRUE if a Compact Analyzer hardware is available, meaning that the **CAAnalyzer.*** command group and the **<trace>.METHOD CAAnalyzer** selection can be used.

Refer to “**CAAnalyzer**” in General Commands Reference Guide C, page 26 (general_ref_c.pdf) for more information.

Return Value Type: Boolean.

CAAnalyzer.BOTHCables()

TRUE if both debug cables are plugged

[\[build 49264 - DVD 02/2014\]](#) [\[Go to figure\]](#)

Syntax:

CAAnalyzer.BOTHCables()

Returns TRUE if both DebugCableA and DebugCableB are plugged to the CombiProbe or µTrace (MicroTrace).

Return Value Type: Boolean.

CAAnalyzer.CableTYPE()

Type of adapter

[\[Go to figure\]](#)

Syntax:

CAAnalyzer.CableTYPE(<int>)

Parameter Type: Decimal value.

Return Value Type: Decimal value.

Returns the type of adapter plugged to the Compact Analyzer hardware. This function is similar to the function **ID.WHISKER()**, except for the following differences:

- It returns a decimal value instead of a hexadecimal value.
- In simulator mode or if the plugged whisker is LA-4509 COMBIPROBE-IN-MIPI34, it returns the value 1.
- For the QuadProbe, it always returns 0.

Lauterbach recommends using **ID.WHISKER()** in new scripts.

Example:

```
;return value 1 means that a standard whisker cable is plugged at
;connector A
PRINT CAnalyzer.CableTYPE(0)
```

CAnalyzer.DebugCable()

CombiProbe whisker cable is A or B

[build 49264 - DVD 02/2014] [\[Go to figure\]](#)

Syntax:

CAnalyzer.DebugCable()

Returns which CombiProbe whisker cable is used for debugging: "A" or "B"

Return Value Type: [String](#).

CAnalyzer.FEATURE()

Query features of CAnalyzer hardware

[build 81635 - DVD 02/2017]

Syntax:

CAnalyzer.FEATURE(<feature>)

Returns whether the Lauterbach hardware that provides the CAnalyzer functionality supports a certain feature. The return value of this function only depends on the Lauterbach hardware and possibly the TRACE32 software version, not on any user settings or the target system.

The main use of this function is for scripts to avoid using commands that may be locked.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Return Value and Description:

TRUE()	Feature is supported by current hardware and software. This does not imply that the feature is usable with the current target system.
FALSE()	Feature is not supported or not known to the current software version.

The following *<feature>* parameters are currently supported:

<feature>	Description
SWV	Hardware supports ARM Serial Wire Viewer / Serial Wire Output.
SWV.SAMPLE	Hardware supports setting sample delays for individual bits of an SWV transmission and also supports focus diagnostics (see CAalyzer.ShowFocus , implies SWV).
PTI	Hardware supports any parallel trace port.
PTI.SAMPLE	Hardware supports setting individual sample delays for individual data lines of a parallel trace port and also supports focus diagnostics (see CAalyzer.ShowFocus , implies PTI).
PTI.TERMINATION	Hardware supports parallel termination for the data lines of a parallel trace port that can be controlled using the command CAalyzer.TERMination (implies PTI).
TPIU	Hardware supports decoding and filtering options for ARM TPIU / CoreSight trace ports (implies PTI).
TPIU.SAMPLE	Shorthand for TPIU and PTI.SAMPLE .
TPIU.TERMINATION	Shorthand for TPIU and PTI.TERMINATION .
STP	Hardware supports decoding and filtering options for direct STM (STPv1 or STPv2) output (implies PTI).
STP.SAMPLE	Shorthand for STP and PTI.SAMPLE .

Example:

```
; Script produced by STORE * CAalyzerFocus. To avoid "Command locked"
; error messages when executing this script on different hardware, all
; commands are guarded by explicit checks whether hardware support is
; available.

IF CAalyzer()
(
  IF CAalyzer.FEATURE(TPIU.SAMPLE)
  (
    CAalyzer.SAMPLE D0 -1.555
    CAalyzer.SAMPLE D1 -2.177
    CAalyzer.SAMPLE D2 -2.177
    CAalyzer.SAMPLE D3 -1.866
  )
  CAalyzer.THreshold 1.3
  IF CAalyzer.FEATURE(TPIU.TERMination)
  (
    CAalyzer.TERMination ON
  )
)
```


Syntax: **CAAnalyzer.FIRST()**

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

Syntax: **CAAnalyzer.MAXSIZE()**

Returns the maximum possible size of the Compact Analyzer trace buffer in records (value depends on the currently selected tracing mode, too).

Return Value Type: [Decimal value](#).

Syntax: **CAalyzer.PIN(<pin_name>)**

Returns the status of trace pins as binary.

Parameter Type: [String](#).

Return Value Type: [Binary value](#).

CAalyzer.RECORD.ADDRESS()

Get address recorded in trace record

[build 38764]

Syntax: **CAalyzer.RECORD.ADDRESS(<record_number>)**

Returns the sampled address (access class and offset) from the specified record. For an example, see [Analyzer.RECORD.ADDRESS\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

CAalyzer.RECORD.DATA()

Get data recorded in trace record

[build 38764]

Syntax: **CAalyzer.RECORD.DATA(<record_number>)**

Returns the sampled data of the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

CAAnalyzer.RECORD.OFFSET()

Get address in trace record as number

Syntax: **CAAnalyzer.RECORD.OFFSET(<record_number>)**

Returns the address-offset of the sampled address from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

CAAnalyzer.RECORD.TIME()

Get timestamp of trace record

[build 38764]

Syntax: **CAAnalyzer.RECORD.TIME(<record_number>)**

Returns the timestamp of the specified record. For an example, see [Analyzer.RECORD.TIME\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

CAAnalyzer.RECORDS()

Get number of used trace records

[\[Go to figure\]](#)

Syntax: **CAAnalyzer.RECORDS()**

Returns the number of records in the Compact Analyzer.

If the state is **OFF** and the current mode is **STREAM**, this function will block until all buffered data has been received.

Return Value Type: [Decimal value](#).

CAAnalyzer.REF()

Get record number of reference record

Syntax: **CAAnalyzer.REF()**

Returns the number of the selected reference record in the Compact Analyzer trace.

Return Value Type: [Decimal value](#).

Syntax:

CAnalyzer.SIZE()

Returns the actual defined logical size of the Compact Analyzer trace buffer in records.

Return Value Type: [Decimal value](#).

Syntax:

CAnalyzer.STATE()

Returns the state of the Compact Analyzer.

If the state is **OFF** and the current mode is **STREAM**, this function will block until all buffered data has been received.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state
8	SPY state
9	OFF state, but data is still being processed (PIPE and RTS modes only)

Syntax: CAalyzer.TraceCLOCK()

Get the current value of the **CAalyzer.TraceCLOCK** setting. This is useful to query the SWV baud rate detected by the **CAalyzer.AutoFocus** command from a PRACTICE script.

If the frequency was not yet set or automatic detection was unsuccessful, a negative value is returned. Otherwise, the frequency is returned in Hz.

Return Value Type: [Decimal value](#).

Example 1: Print the detected trace clock after automatic detection

```
; Set the trace output to Serial Wire Viewer mode
TPIU.PortType SWV

; Perform automatic rate detection
CAalyzer.AutoFocus

IF CAalyzer.TraceCLOCK()>=0.
(
    PRINT "Detected baud rate is " \
        FORMAT.FLOAT(0,3,CAalyzer.TraceCLOCK()/1.0e6) \
        " MHz."
)
```

Example 2: A script to automatically find a suitable SWV prescaler is included with your TRACE32 installation. To access this script, run the following command

```
PSTEP ~/demo/arm/etc/serial_wire_viewer/swv_autocalibration.cmm
```

Syntax: CAalyzer.TraceCONNECT()

Returns the name of the currently selected trace sink of the SoC. In case no trace-sink is selected/available, the function returns **NONE**. The trace sink is selected with the [<trace>.TraceCONNECT](#) command.

Return Value Type: [String](#).

Example: See [Onchip.TraceCONNECT\(\)](#).

CAalyzer.TracePort()

CombiProbe whisker cable is A or B

[build 49264 - DVD 02/2014] [\[Go to figure\]](#)

Syntax: CAalyzer.TracePort()

Returns which CombiProbe whisker cable is used for tracing: "A" or "B"

Return Value Type: [String](#).

CAalyzer.TRACK.RECORD()

Get record number matching search

Syntax: CAalyzer.TRACK.RECORD()

After a successful search operation, this function returns the record number. For an example, see [Analyzer.TRACK.RECORD\(\)](#).

Return Value Type: [Decimal value](#).

CERBERUS.IOINFO()

IOINFO of Cerberus module

TriCore

[build 66413 - DVD 02/2016]

Syntax:

CERBERUS.IOINFO()

Returns the IOINFO of the Cerberus module.

Return Value Type: [Hex value](#).

CERBERUS.IOINFO.IFLCK()

TRUE if IF_LCK bit in Cerberus INONFO set

TriCore

[build 66413 - DVD 02/2016]

Syntax:

CERBERUS.IOINFO.IFLCK()

Returns TRUE if the IF_LCK bit in the Cerberus IOINFO is set, FALSE otherwise.

Return Value Type: [Boolean](#).

CHIP.EmulationDevice()

TRUE if emulation device

[build 74844 - DVD 09/2016]

Syntax:

CHIP.EmulationDevice()

For PowerPC: This function returns TRUE if an Emulation Device was detected.

For TriCore/PCP/GTM/C166/XC2000ED: This function returns TRUE if an Emulation Device was selected in the CPU list, e.g. TC1797ED, TC275TE.

Return Value Type: [Boolean](#).

CHIP.STEPping()

Major silicon step of an TriCore AURIX device

TriCore

[build 49713 - DVD 02/2014]

Syntax:

CHIP.STEPping()

Returns the major silicon step of an TriCore AURIX device.

Return Value Type: [String](#).

In This Section

See also

- [CIProbe\(\)](#)
[CIProbe.RECORDS\(\)](#)
- [CIProbe.ADC.ENABLE\(\)](#)
[CIProbe.SIZE\(\)](#)
- [CIProbe.ADC.SHUNT\(\)](#)
[CIProbe.STATE\(\)](#)
- [CIProbe.MAXSIZE\(\)](#)
[CIProbe.TRACK.RECORD\(\)](#)

CIProbe()

TRUE if Compact Analyzer hardware

Syntax:

CIProbe()

Returns TRUE if a Compact Analyzer (CombiProbe or μTrace (MicroTrace)) hardware is plugged and used with a logic analyzer/analog probe.

Return Value Type: [Boolean](#).

CIProbe.ADC.ENABLE()

TRUE if channel is enabled

Syntax:

CIProbe.ADC.ENABLE(<channel>)

Returns TRUE if the specified analog channel of the Analog Probe is enabled.

Return Value Type: [Boolean](#).

CIProbe.ADC.SHUNT()

Get shunt-resistor value

Syntax:

CIProbe.ADC.SHUNT(<channel>)

Returns the shunt-resistor value of the specified current measurement <channel> of the Analog Probe.

Return Value Type: [Float](#).

Syntax:

CIProbe.MAXSIZE()

Returns the maximum size of the Compact Analyzer (CombiProbe) trace buffer, which is assigned to the CIProbe, in records.

Return Value Type: [Decimal value](#).

CIProbe.RECORDS()

Get number of used trace records

Syntax:

CIProbe.RECORDS()

The number of records currently stored in the trace buffer.

Return Value Type: [Decimal value](#).

CIProbe.SIZE()

Get current trace buffer size in records

[build 38323 - DVD 08/2012]

Syntax:

CIProbe.SIZE()

Returns the actual defined logical size of the Compact Analyzer (CombiProbe) trace buffer which is assigned to the CIProbe, in records.

Return Value Type: [Decimal value](#).

Syntax:

CIProbe.STATE()

Returns the state of the Compact Analyzer for CIProbe.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

Syntax:

CIProbe.TRACK.RECORD()

After a successful search operation, this function returns the record number. For an example, see [Analyzer.TRACK.RECORD\(\)](#).

Return Value Type: [Decimal value](#).

CMIBASE()

Base addresses of CMI modules

[build 58596]

Syntax:	CMIBASE (<instance>)
<instance>:	1. 2.

Returns the base address of the primary or secondary CMI module. A base address is set with the command **SYStem.CONFIG.CMI.Base**.


Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

COMPonent Functions

This figure provides an overview of the return values of the COMPonent functions. For descriptions of the illustrated functions, see below.

[COMPonent.AVAILABLE\(\)](#)



In This Section

See also

[COMPonent.AVAILABLE\(\)](#) [COMPonent.BASE\(\)](#) [COMPonent.NAME\(\)](#) [COMPonent.TYPE\(\)](#)

COMPonent.AVAILABLE() TRUE if debug/trace peripherals available on CPU

[\[Go to figure\]](#)

Syntax: **COMPonent.AVAILABLE(" <component_name> ")**

Returns TRUE if the specified debug/trace peripheral <component_name> is available on this CPU.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Example:

```
; set up base address of ETB1 and make it available
SYStem.CONFIG.ETB1.Base 0x123

; prints TRUE
PRINT COMPonent.AVAILABLE ( "ETB1 " )
```

Syntax:

COMPONENT.BASE("<component_name>",<core>)

Returns the base address for the specified debug/trace peripheral <component_name> and <core>.

Parameter and Description:

<component_name>	Parameter Type: String.
<core>	Parameter Type: Decimal value. In case <core> is -1, the current core is used.

Return Value Type: Address.

Example:

```
; set up base address of ETB1
SYStem.CONFIG.ETB1.Base 0x123

; print offset of base address (123)
PRINT ADDRESS.OFFSET(COMPONENT.BASE("ETB1",-1))
```

Syntax:

COMPONENT.NAME("<component_name>",<core>)

Returns the user-defined name for the specified debug/trace peripheral <component_name> and <core>, if a name was defined for that component with the command **SYStem.CONFIG.<component>.Name**.

Parameter and Description:

<component_name>	Parameter Type: String.
<core>	Parameter Type: Decimal value. In case <core> is -1, the current core is used.

Return Value Type: String. An empty string is returned if the component does not exist or has no user-defined name.

Example:

```
; assign a user-defined name to the 1st CoreSight Funnel
SYStem.CONFIG.FUNNEL1.Name "STM-Funnel"

; print name of the 1st Funnel
ECHO COMPonent.NAME("FUNNEL1",-1)
```

COMPonent.TYPE()

Type of debug/trace peripherals

[build 95283 - DVD 09/2018]

Syntax:

COMPonent.TYPE("<component_name>")

Returns the user-defined type for the specified debug/trace peripheral <component_name>.

Parameter Type: [String](#).

Return Value Type: [String](#). An empty string is returned if the component does not exist.

COMPonentNAME()

Name of debug/trace peripheral

[build 169044 - DVD 09/2024]

Syntax:

COMPonentNAME("<component_type>",<index>")

Returns the name of the n-th component of the specified <component_type>, where n is the given <index>.


Parameter and Description:

<component_type>	Parameter Type: String .
<index>	Parameter Type: Decimal value . 0 <= index < COMPonentNUMBER("<component_type>")

Return Value Type: [String](#).

Example:

```
SYStem.CONFIG.ETB1.Base APB:0x4
SYStem.CONFIG.ETB2.Base APB:0x8
SYStem.CONFIG.ETB5.Base APB:0xC
&i=0.
RePeaT COMPONENTNUMBER("ETB")
(
    PRINT "base address of " COMPONENTNAME("ETB", &i) " is " \
        COMPONENT.BASE(COMPONENTNAME("ETB", &i), -1.)
    &i=&i+1.
)
```



COMPONENTNUMBER()

Number of valid debug/trace peripherals

[build 169044 - DVD 09/2024]

Syntax: **COMPONENTNUMBER("<component_type>")**

Returns the count of valid components belonging to the specified type *<component_type>*.

Parameter Type: [String](#).


Return Value Type: [Decimal value](#).

Example:

```
SYStem.CONFIG.ETB1.Base APB:0x4
SYStem.CONFIG.ETB2.Base APB:0x8
SYStem.CONFIG.ETB5.Base APB:0xC
PRINT COMPONENTNUMBER("ETB") " configured ETB components"
; prints "3 configured ETB components" to AREA
```


CORE Functions


These figures provide an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.




SYSTEM.CONFIG.CoreNumber 6 . informs TRACE32 that this multicore chip has six cores. (The right arrow button is deactivated at core 6.)

CONFIGNUMBER()

CORE.NUMBER()



CORE()



The same values as in the CORE.SHOWACTIVE window (left)

In This Section

See also

- CORE
- ❑ CORE()
- ❑ CORE.ISASSIGNED()
- ❑ CORE.NAMES()
- ❑ CORE.PHYSICALTOLOGICAL()
- ❑ CORENUMBER()
- ❑ CONFIGNUMBER()
- ❑ CORE.ISACTIVE()
- ❑ CORE.LOGICALTOPHYSICAL()
- ❑ CORE.NUMBER()
- ❑ CORENAME()

Syntax: **CONFIGNUMBER()**

Returns the number of cores as set by the command **SYStem.CONFIG.CoreNumber**.

Return Value Type: [Decimal value](#).

Example:

```
;Inform TRACE32 about the total number of cores of a multicore chip
SYStem.CONFIG.CoreNumber 6.

;Specify the location of the debug registers (CoreSight ARM only)
SYStem.CONFIG COREBASE 100, 200, 300, 400, 500, 600

;Start core assignment at this <core> of this <chip>
SYStem.CONFIG.CORE          1.          1.

;- The cores 1, 2, 4, 5 (= four cores) are assigned to the TRACE32
; PowerView GUI
;- The cores 3 and 6 are skipped (= two cores)
CORE.ASSIGN 1. 2. 4. 5.

SYStem.Up

;Open the configuration window.
SYStem.CONFIG.state /Jtag ;When clicking the right arrow button on
                          ;the JTAG tab, you cannot go beyond core 6.

;Returns 6 because you have informed TRACE32 that this multicore
;chip has 6 cores.
PRINT CONFIGNUMBER()
```

Syntax: **CORE()**

Returns the core selected with the **CORE.select** or **CORE.List** command.

Return Value Type: [String](#).

Syntax: **CORE.ISACTIVE("<core>")**

Returns TRUE if the specified core is active, FALSE if the core is inactive.

Parameter Type: [String](#). If the <core> consists of just a number, then append a dot; see example 2. The core names are displayed in the **Cores** drop-down list of the [state line](#) and in the **CORE.SHOWACTIVE** window. If the string is empty, then the state of the currently selected core is returned.

Return Value Type: [Boolean](#).

Example 1: This script line shows how to specify a core name in a big.LITTLE system

```
PRINT CORE.ISACTIVE("1b")    ;prints TRUE to the message line if the core
                             ;named "1b" is active
```

Example 2: This script line shows how to specify a core name in an SMP system

```
PRINT CORE.ISACTIVE("3.")    ;prints TRUE to the message line if core
                             ;number 3 is active
                             ;remember to append a dot to the core number
```

Example 3:

```
PRINT CORE.ISACTIVE(CORE.NAMES(5.))
```

Syntax:

CORE.ISASSIGNED(<core_number>)

Returns TRUE if a physical core is assigned to the current debug session, FALSE otherwise. To assign cores to TRACE32, use **CORE.ASSIGN**.

Parameter and Description:

<core_number>	Parameter Type: Decimal value. Number of a physical core. Range: 1. <= core_number <= CONFIGNUMBER() • Min.: 1. • Max.: Return value of CONFIGNUMBER()
---------------	---

Return Value Type: [Boolean](#).

Example:

```
;The physical cores 1, 3, 5 are assigned to the debug session.
;The other cores are skipped.
CORE.ASSIGN 1. 3. 5.

SYStem.Up

;Returns FALSE in this example because the physical core 2 was skipped.
IF CORE.ISASSIGNED(2.)==TRUE()
(
    PRINT CORE.PHYSICALTOLOGICAL(2)
)
```

Syntax:

CORE.LOGICALTOPHYSICAL(<core_number>)

Returns the physical core number of a logical core.

Parameter and Description:

<core_number>	Parameter Type: Decimal value. Core number of a logical core. Range: 0. <= core_number <= CORE.NUMBER() - Min.: 0. - Max.: Return value of CORE.NUMBER()-1.
---------------	--

Return Value Type: [Decimal value](#).

Return Value and Description:

1 ... <n>	Number of the physical core. The highest number <n> equals the return value of CONFIGNUMBER() .
Error message	The error message “value too large” is displayed if <core_number> is out of bounds.

Example:

```
;The physical cores 1, 2, 3, 4 are assigned to the debug session.
CORE.ASSIGN 1. 2. 3. 4.

SYStem.Up

PRINT CORE.LOGICALTOPHYSICAL(0.) CORE.LOGICALTOPHYSICAL(1.)
PRINT CORE.LOGICALTOPHYSICAL(2.) CORE.LOGICALTOPHYSICAL(3.)
;Result:
;The logical core numbers 0, 1, 2, 3 correspond to
;the physical core numbers 1, 2, 3, 4
```

See also: [CORE.PHYSICALTOLOGICAL\(\)](#), [CORE.ISASSIGNED\(\)](#)

Syntax: **CORE.NAMES(<index>)**

Retrieves all physical core names of the SMP system.

Parameter Type: [Decimal value](#).

Return Value Type: [String](#).

Example: The **CORE.NAMES()** function is used to loop through the cores assigned to TRACE32, and the **CORE.ISACTIVE()** function returns whether a core is active or inactive.

```
SYStem.CPU Cortexa15A7
SYStem.CONFIG.CoreNumber 14.

;assign the cores of a big.LITTLE SMP system to TRACE32
CORE.ASSIGN BIGLITTLE 1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. 13. 14.

;enter debug mode
SYStem.Up

GOSUB printstate

CORE.SHOWACTIVE

ENDDO

printstate:

&i=0.
nextcore:
&name=CORE.NAMES(&i)
IF "&name"!=" "
(
    &state=CORE.ISACTIVE("&name")
    IF &state==TRUE()
        PRINT "active core : &name"
    &i=&i+1.
    GOTO nextcore
)

RETURN
```

Syntax:

CORENAME()

Returns the name of the core within a selected chip.

Return Value Type: [String](#). The name and spelling is the same that is shown in the [SYSem.CONFIG.state](#) window on the **Miscellaneous** tab.

Syntax:

CORE.NUMBER()
CORENUMBER() (deprecated)

Returns the number of logical cores assigned to the current debug session.

For each assigned core, the [CORE.SHOWACTIVE](#) window and the **Cores** list contain one entry. To assign cores to TRACE32, use the command [CORE.ASSIGN](#).

NOTE:

Do not confuse the number of cores currently assigned to TRACE32 with the actual number of cores physically implemented on a multicore chip.
It is possible to assign fewer cores to TRACE32 than there are on a multicore chip.

Return Value Type: [Decimal value](#).

Return Value and Description:

1	Single-core debug session.
Integer greater than 1	SMP debug session (Symmetrical Multicore Processing).

Example 1: Let's assume a multicore chip has 6 cores, and just 4 of them are assigned to TRACE32. As a result, **CORE.NUMBER()** returns 4.

```
;select a multicore chip
SYStem.CPU CortexA7MPCore

;Inform TRACE32 about the total number of cores of a multicore chip
SYStem.CONFIG.CoreNumber 4.

;Specify the location of the debug registers    (CoreSight ARM only)
SYStem.CONFIG COREBASE DAP:0x100 DAP:0x200 DAP:0x300 DAP:0x400
;Start core assignment at this <core> of this <chip>
SYStem.CONFIG.CORE                1.                1.

;- The cores 1, 2, 4 (= three cores) are assigned to the TRACE32
; PowerView GUI
;- The core 3 is skipped
CORE.ASSIGN 1. 2. 4.

;Prints 3 because three cores were assigned to the debug session
PRINT CORE.NUMBER()
```

Example 2: A single-core debug session is set up for core 3 of a multicore chip.

```
SYStem.CPU CortexA7MPCore                ;select a multicore chip

;Inform TRACE32 about the total number of cores of a multicore chip
SYStem.CONFIG.CoreNumber 4.

;Specify the location of the debug registers    (CoreSight ARM only)
SYStem.CONFIG COREBASE DAP:0x100 DAP:0x200 DAP:0x300 DAP:0x400

;Start core assignment at this <core> of this <chip>
SYStem.CONFIG.CORE                1.                1.

CORE.ASSIGN 3.                        ;assign only core 3 to the debug session
```


Syntax:

CORE.PHYSICALTOLOGICAL(<core_number>)

Returns the logical core number of a physical core. If the core is not assigned to the current debug session, an error is shown in the message line.

Parameter and Description:

<core_number>	Parameter Type: Decimal value. Number of a physical core. Range: 1. <= core_number <= CONFIGNUMBER() - Min.: 1. - Max.: The return value of CONFIGNUMBER()
---------------	---

Return Value Type: [Decimal value](#).


Return Value and Description:

0 ... <n>	Number of the logical core. The highest number <n> equals the return value of CORE.NUMBER() .
Error message	The error message “value not allowed” is displayed if <core_number> refers to a physical core that is not assigned to the current debug session. See CORE.ISASSIGNED() .

Example: For each physical core assigned to the TRACE32 PowerView GUI, the physical and logical core numbers are printed to an [AREA.view](#) window.

```
&physical=1.      ;the number of the first physical core is always 1

WHILE &physical<=CONFIGNUMBER()
(
  IF CORE.ISASSIGNED(&physical)==TRUE()
  (
    ;returns the physical core number for this logical core
    PRINT "Physical core: " &physical
    PRINT %CONTINUE " (logical: " CORE.PHYSICALTOLOGICAL(&physical) " )"
  )
  &physical=&physical+1. ;increment to next physical core
)
```



Reason for the gaps in the sequence of physical core numbers:
Only the cores 1, 2, 4, and 5 were assigned with the command [CORE.ASSIGN](#) 1. 2. 4. 5.
The cores 3 and 6 were intentionally skipped.

See also: [CORE.LOGICALTOPHYSICAL\(\)](#)

Count Functions

The **Count** functions give access to the measurement results of the **Count.state** window.

In This Section

See also

- [Count](#)
- [Count.Frequency\(\)](#)
- [Count.LEVEL\(\)](#)
- [Count.Time\(\)](#)
- [Count.VALUE\(\)](#)

Count.Frequency()

Frequency of last measurement

[build 67178 - DVD 02/2016]

Syntax:

Count.Frequency()

Returns the frequency in Hz of the last measurement started with the command **Count.GO**. If the last measurement was not a frequency measurement, the function aborts with an error.

Return Value Type: [Decimal value](#).

Example:

```
; select signal source (here: MCKO) and operation mode
Count.Select MCKO
Count.Mode Frequency

; do measurement
Count.Go

PRINT "F=" Count.Frequency() "Hz" ;Output: "F=169440Hz"
```

Count.LEVEL()

Level of frequency counter input

Syntax:

Count.LEVEL()

Current logical level of the frequency counter input.

Return Value Type: [Time value](#).

Syntax:

Count.Time()

Returns the time of the last period or pulse duration measurement started with the command **Count.GO**. If the last measurement was not a period or pulse duration measurement, the function aborts with an error.

Return Value Type: Time value.

Example:

```
; select signal source (here: PowerProbe eXt.3) and operation mode
Probe.CSelect eXt.3
Count.Mode Period

; do measurement
Count.Go

PRINT "Period=" Count.Time()           ;Output: "Period=0.000105900s"
```

Syntax:


Count.VALUE()

If the **Counter** is configured to count events, this function returns the result samples when the command **Count.GO** is issued. If the Counter is configured for frequency, period or pulse duration measurement, the result of the function is undefined.

Return Value Type: Hex value.

COverage Functions

This figure provides an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.



METHOD

state

Option

SourceMetric

ObjectCode

MatchPolicy

commands

In This Section

See also

- COverage

□ COverage.Percentage()
- COverage.BDONE()

□ COverage.SCOPE()
- COverage.IDLE()

□ COverage.SourceMetric()
- COverage.LOAD.KEY()

□ COverage.TreeWalk()

Syntax:

COVerage.BDONE(<address_range>)

Returns a byte count of all instructions that have been executed.

Parameter Type: [Address range](#).

Return Value and Description:

-1	The data is invalid, or the user has clicked Stop on the TRACE32 main toolbar to abort the function.
Greater than or equal to 0	Byte count of all executed instructions within the specified range.

Return Value Type: [Decimal value](#).

Example: Different types of input parameters are shown. The function accepts both address ranges and other functions that return address ranges as input.

```
; address range
PRINT COVerage.BDONE(P:0x1FFFC220--P:0x1FFFC299)

; function main
PRINT COVerage.BDONE(Var.RANGE(main))

; module crt0 of the executable sort
PRINT COVerage.BDONE(sYmbol.RANGE(\\sort\crt0))
```

NOTE:

The specified range has to be identical to the limits of the function / functions being tested. Otherwise inaccuracies may occur.

COVerage.IDLE()

TRUE if all trace data for code coverage are processed

[\[build 169162 - DVD 09/2024\]](#)

Syntax:

COVerage.IDLE()

Returns TRUE if all available trace data for code coverage have been processed. This function is useful for detecting whether the processing of RTS and SPY modes has been completed.

Return Value Type: [Boolean](#).

Syntax:

COVerage.LOAD.KEY()

Returns the key from the last ACD file (*.acd) that was loaded with COVerage.LOAD.

Return Value Type: String.

COVerage.Percentage()

Percentage of code coverage

[build 164726 - DVD 02/2024]

Syntax:

COVerage.Percentage(<symbol_name>)

Returns the percentage of achieved code coverage for the specified symbol using the currently selected source metric.

Parameter Type: String.

Return Value Type: Float.

COVerage.SCOPE()

Degree of code coverage

[build 37864 - DVD 08/2012] [Go to figure]

Syntax:

COVerage.SCOPE(<address_range>)

Returns the degree of code coverage within the specified range.

Parameter Type: Address range.

Return Value Type: Decimal value.

Return Value and Description:

-1	Returns -1 if the data is invalid or if the user has clicked Stop on the TRACE32 main toolbar to abort the function.
0	At least one instruction not fully executed.
1	At least one branch only taken.
2	At least one branch never taken.
3	At least one branch never and one only taken.
4	Fully executed.

Example: This script demonstrates the usage of the **COverage.SCOPE()** function with different types of input parameters. The function **COverage.SCOPE()** accepts both address ranges and other functions that return address ranges as input.

```
; address range
COverage.SCOPE(P:0x1FFFC220--P:0x1FFFC299)

; function main
COverage.SCOPE(Var.RANGE(main))

; module crt0 of the executable sort
COverage.SCOPE(symbol.RANGE(\\sort\\crt0))
```

NOTE:	The specified range has to be identical to the limits of the function / functions being tested. Otherwise inaccuracies may occur.
--------------	---

Syntax:

COverage.SourceMetric()

Returns the current code coverage criterion for HLL lines that was set with the command [COverage.Option.SourceMetric](#).

Return Value Type: [String](#).

Return Value and Description:

ObjectCode	The tags of the corresponding block of assembly instructions are mapped to the HLL line.
Statement	Statement coverage
Decision	Decision coverage
MCDC	Modified condition/decision coverage (MC/DC)

For details, see [COverage.Option.SourceMetric](#).

Example: See `~/demo/coverage/multi_file_report/create_report.cmm`.

Syntax:

COverage.TreeWalk(<action>)

<action>:

Init | Recurse | CONTinue

Traverses the code coverage tree that has been prepared by the command **COverage.TreeWalkSETUP**.

Parameter Type: **String**.

Parameter and Description:

Init	Returns the first node of the tree.
Recurse	Returns the next node of the tree.
Continue	Returns the next node on the same or higher level.

Return Value Type: **String**.

Example 1:

```
PRIVATE &node

COverage.TreeWalkSETUP                                ; create a tree with all
                                                         ; code coverage symbols

&node=COverage.TreeWalk("Init")                      ; get the first tree element
WHILE "&node"!=" "
(
  IF STRing.SCAN("&node","\",0.)==0.                  ; element is a module
  (
    PRINT "The next module is: &node"
  )
  ELSE IF STRing.SCAN("&node","--",0.)>-1.            ; element is an HLL line
  (
    PRINT "The next HLL line is: &node"
  )
  ELSE                                              ; element is a function
  (
    PRINT "The next function is: &node"
  )
  &node=COverage.TreeWalk("Recurse")                ; get the next tree element
)
```

Example 2: A more complex demo script is included in your TRACE32 installation. To access the script, run this command:
B::CD.PSTEP ~/demo/coverage/multi_file_report/create_report.cmm

In This Section

See also

- SYStem.CPU
 - ❑ CPU.ADDRESS()
 - ❑ CPU.FEATURE()
 - ❑ CPU.SUBFAMILY()
 - ❑ CPUCOREVERSION()
 - ❑ CPUFAMILY()
 - ❑ CPUIS()
- ❑ CPU()
 - ❑ CPU.ADDRESS.PhysicalINDEX()
 - ❑ CPU.PINCOUNT()
 - ❑ CPUBONDOUT()
 - ❑ CPUDERIVATE()
 - ❑ CPUHELP()
 - ❑ CPUIS64BIT()

CPU.ADDRESS()

Start address of memory section

ARC, TriCore

[build 106881 - DVD 09/2019]

Syntax:	CPU.ADDRESS(<section>)
<section>: (ARC)	XCCM YCCM
<section>: (TriCore)	SFR CSFR

Returns the start address of the memory or register block <section>.

Parameter Type: [String](#).

Return Value Type: [Address](#).

CPU.ADDRESS.PhysicalINDEX()

Section start address of given core

TriCore

[build 125278 - DVD 09/2020]

Syntax:	CPU.ADDRESS.PhysicalINDEX("<section>",<core_number>)
---------	--

Returns the start address of the memory or register block <section> for the given core.

Parameter and Description:

<section>	Parameter Type: String . Name of the memory or register block. For legal values see CPU.ADDRESS() .
<core_number>	Parameter Type: Decimal value . Number of a physical core. Range: 1. <= core_number <= CONFIGNUMBER() - MIN.: 1. - MAX.: The return value of CONFIGNUMBER()

Return Value Type: [Address](#).

CPU.FEATURE()

TRUE if CPU feature exists

[build 57631] [\[Example\]](#)

Syntax:

CPU.FEATURE(<feature_string>)

Tests whether the selected CPU has a certain feature. The function returns TRUE if the CPU implements the specified feature. If the feature it not supported, or if <feature_string> is unknown, the function returns FALSE. The tables below show the generic and architecture dependent feature strings.

Parameter Type: [String](#).

Parameter and Description:

All Architectures - Allowed keywords for <feature_string>

<feature_string>	Description
BMC [build 71934 - DVD 02/2016]	TRUE if the selected CPU implements benchmark counters / performance monitors.
IPA	TRUE if the core uses intermediate physical addresses for guest address translation (hypervisor).
MACHINESPACES	TRUE if command SYStem.Option.MACHINESPACES can be used for this CPU to enable machine-specific address spaces (hypervisor).
MMU	TRUE if the selected core has a memory management unit (MMU).
PCSNOOP [build 67662 - DVD 02/2016]	TRUE if the program counter of the selected CPU can be read by the debugger while the CPU is running.
ZONESPACES	TRUE if command SYStem.Option.ZoneSPACES can be used for this CPU to enable zone-specific (CPU mode-specific) address spaces.

<feature_string>	Description
BIGLITTLE	TRUE if the selected CPU supports the ARM bigLITTLE technology.
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.
CORESIGHT	TRUE if the selected CPU supports the ARM Coresight debug and trace technology.
CP15	TRUE if the selected CPU supports CP15 register access.
DTLBDUMP	TRUE if the selected CPU supports data TLB dumping using command MMU.DUMP.DTLB .
EXTENDEDPHYSICALADDRESS	TRUE if the selected CPU has 32bit logical addresses and more than 32bit physical addresses. Physical addresses are displayed with bits 32 and larger separated by a colon (A:0x00:0x00000000).
FPU	TRUE if the selected CPU has a Vector Floating Point (VFP) coprocessor.
HYPERVISOR	TRUE if the selected CPU has a hypervisor zone (ARM Virtualization Extension).
ITLBDUMP	TRUE if the selected CPU supports instruction TLB dumping using command MMU.DUMP.ITLB .
JAZELLE	TRUE if the selected CPU has the ARM Jazelle execution mode.
L1DCACHE	TRUE if the selected CPU has a level 1 data cache.
L1DCACHEDUMP	TRUE if the selected CPU supports level 1 data cache dump using command CACHE.DUMP .
L1ICACHE	TRUE if the selected CPU has a level 1 instruction cache.
L1ICACHEDUMP	TRUE if the selected CPU supports level 1 instruction cache dumping using command CACHE.DUMP .
L2CACHE	TRUE if the selected CPU has a level 2 cache.
L2CACHEDUMP	TRUE if the selected CPU supports level 2 cache dump using command CACHE.DUMP .
LPAAE	TRUE if the selected CPU has a memory management unit (MMU) and supports the Large Physical Address Extension (LPAAE) mode.
MPU	TRUE if the selected CPU has a memory protection unit (MPU).
NEON	TRUE if the selected CPU has a ARM NEON Extension.
SECURE	TRUE if the selected CPU has a secure zone (e.g. ARM TrustZone).
SECUREEL2	TRUE if the selected CPU has a non-secure and a secure EL2 mode.

<feature_string>	Description
SME	TRUE if the selected CPU has a scalable matrix extension (SME).
SPR	TRUE if the selected CPU supports SPR register access.
SVE	TRUE if the selected CPU has a scalable vector extension (SVE).
THUMB	TRUE if the selected CPU supports thumb instruction set.
TLB0DUMP	TRUE if the selected CPU supports TLB0 dumping using command MMU.DUMP.TLB0 .
TLB1DUMP	TRUE if the selected CPU supports TLB1 dumping using command MMU.DUMP.TLB1 .
VBAR	TRUE if the VBAR register is available in the selected CPU.

C6000 Architecture - Allowed keywords for <feature_string>

<feature_string>	Description
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.

C7000 Architecture - Allowed keywords for <feature_string>

<feature_string>	Description
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.
L2CACHE	TRUE if the selected core has a L2 cache.

<feature_string>	Description
BMC	TRUE if the selected core has performance monitor registers (PMR).
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.
COREMPU	TRUE if the selected core has a memory protection unit (MPU).
EFPU	TRUE if the selected core has the EFPU floating point unit.
EFPU2	TRUE if the selected core has the EFPU2 floating point unit.
FLE	TRUE if the selected core supports the std. PowerPC opcodes.
FPU	TRUE if the selected core has the standard PowerPC FPU floating point unit.
HYPERVISOR	TRUE if the selected core implements the hypervisor programming model.
L1DCACHE	TRUE if the selected core has an L1 data cache.
L1ICACHE	TRUE if the selected core has an L1 instruction cache.
L1UNIFIEDCACHE	TRUE if the selected core has a unified L1 cache.
L2CACHE	TRUE if the selected core has a L2 cache.
ONCHIP_PCFIFO	TRUE if the selected core has the PCFIFO on-chip trace (MPC55XX/56XX).
ONCHIP_TR2MEM	TRUE if the processor implements trace-to-memory (MPC57XX/QorIQ).
SPE	TRUE if the selected core has the signal processing engine (SPE).
VLE	TRUE if the selected core supports variable length encoded instruction set.

<feature_string>	Description
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.
FPU	TRUE if the selected core has a floating point unit (FPU).
FXU [build 108274 - DVD 09/2019]	TRUE if the selected CPU has FXU registers (extended floating point unit).
MPU	TRUE if the selected CPU has a memory protection unit (MPU).

RISC-V Architecture - Allowed keywords for <feature_string>

<feature_string>	Description
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.
FPU	TRUE if the selected core has a floating point unit (FPU).
VPU	TRUE if the selected core has a vector processing unit (VPU).

TRICORE Architecture - Allowed keywords for <feature_string>

<feature_string>	Description
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.
HSM [build 124752 - DVD 09/2020]	TRUE if the selected CPU has an HSM core.

<feature_string>	Description
CONDISA	TRUE if the instruction set architecture of the selected core provides for conditional instructions.
CONDTRACE	TRUE if the trace data for conditional instructions indicates whether the condition code check was passed or failed.

Return Value Type: [Boolean](#).

Example:

```
SYStem.CPU CortexA15      ;select CPU CortexA15
PRINT CPU.FEATURE(SECURE) ;SECURE feature available? --> TRUE
```

CPU.PINCOUNT()

For internal usage only

[build 75532 - DVD 09/2016]

Syntax:

CPU.PINCOUNT()

For internal use only.

CPUBONDOUT()

Name of boundout processor

Syntax:

CPUBONDOUT()

Returns the name of the bondout processor.

Return Value Type: [String](#).

CPUCOREVERSION()

Core or architecture version of CPU

Syntax:

CPUCOREVERSION()

Returns the CPU's core or architecture version, e.g. "TriCore v1.3.1".

Return Value Type: [String](#).

Syntax:

CPUDEIRIVATE()

Returns the main part of the processor name.

Return Value Type: [String](#).

Syntax:

CPUFAMILY()

Returns the family name of the processor.

Return Value Type: [String](#).

Syntax:

CPUHELP()

Reserved for internal usage.

Return Value Type: [String](#).

Syntax: **CPUIS(<search_string>)**

Returns a boolean value after comparing the currently selected name of the processor with the given search string. The search string can contain wildcards and characters are **not** interpreted as **case-sensitive**.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Example:

```
IF (CPUIS("TC*ED"))
    PRINT "TriCore Emulation Device detected"

; instead of the more complex alternative:
IF ((CPU()=="TC1798ED") || (CPU()=="TC1793ED") || (CPU()=="TC1791ED"))
    PRINT "TriCore Emulation Device detected"
```

Syntax: **CPUIS64BIT()**
ARM64() (deprecated)

Returns TRUE when the target architecture is 64-bit e.g. ARM64.

Return Value Type: [Boolean](#).

In This Section

See also

- [DAP.Available\(\)](#)
- [DAP.USER0\(\)](#)
- [DAP.USER1\(\)](#)

DAP.Available()

TRUE if debugging via DAP is supported

Syntax:

DAP.Available()

Returns TRUE if both the attached debug cable and the selected CPU support debugging via the DAP interface.

Return Value Type: [Boolean](#).

DAP.USER<x>()

Status of the DAP user pin

ICD-TriCore and ICD-C166

Syntax:

DAP.USER0()
DAP.USER1()

Returns the status of the DAP `USER0` or `USER1` pin. Low level is FALSE, high level is TRUE. For details, see [“Application Note Debug Cable TriCore”](#) (app_tricore_ocds.pdf).

Return Value Type: [Boolean](#).

In This Section

See also

- [Data.AL.ERRORS\(\)](#)
 - [Data.Float\(\)](#)
 - [Data.Long\(\)](#)
 - [Data.Long.Byte\(\)](#)
 - [Data.Long.Long\(\)](#)
 - [Data.LongLong\(\)](#)
 - [Data.LongLong.LittleEndian\(\)](#)
 - [Data.PByte\(\)](#)
 - [Data.Quad.BigEndian\(\)](#)
 - [Data.Quad.LittleEndian\(\)](#)
 - [Data.Quad.Quad\(\)](#)
 - [Data.SByte\(\)](#)
 - [Data.Short.BigEndian\(\)](#)
 - [Data.SLong\(\)](#)
 - [Data.STRingN\(\)](#)
 - [Data.TByte\(\)](#)
 - [Data.Word.BigEndian\(\)](#)
 - [Data.Word.LittleEndian\(\)](#)
 - [Data.WSTRING\(\)](#)
 - [Data.WSTRING.LittleEndian\(\)](#)
- [Data.Byte\(\)](#)
 - [Data.HByte\(\)](#)
 - [Data.Long.BigEndian\(\)](#)
 - [Data.Long.LittleEndian\(\)](#)
 - [Data.Long.Word\(\)](#)
 - [Data.LongLong.BigEndian\(\)](#)
 - [Data.MAU\(\)](#)
 - [Data.Quad\(\)](#)
 - [Data.Quad.Byte\(\)](#)
 - [Data.Quad.Long\(\)](#)
 - [Data.Quad.Word\(\)](#)
 - [Data.Short\(\)](#)
 - [Data.Short.LittleEndian\(\)](#)
 - [Data.STRing\(\)](#)
 - [Data.SUM\(\)](#)
 - [Data.Word\(\)](#)
 - [Data.Word.Byte\(\)](#)
 - [Data.Word.Word\(\)](#)
 - [Data.WSTRING.BigEndian\(\)](#)

Data.<value_width>()

Memory contents in default endianness

[\[Examples\]](#)

Syntax:	Data.<value_width>(<address>)
<value_width>:	Byte Short Word TByte Long PByte HByte SByte SLong Quad LongLong
Full function name only required for HELP.Index:	Data.Byte(<address>) Data.Short(<address>) Data.Word(<address>) Data.TByte(<address>) Data.Long(<address>) Data.PByte(<address>) Data.HByte(<address>) Data.SByte(<address>) Data.SLong(<address>) Data.Quad(<address>) Data.LongLong(<address>)

Reads a value from memory using the specified <width> and <address>. The address must be classified, e.g. D:0x200, while each symbol has its own implicit memory class.

The possible memory classes depend on the target CPU. The appropriate list can be found in the chapter “Access Classes” of the particular [Processor Architecture Manual](#).

<value_width>	Description of Data.<value_width>()
Byte	Returns a single byte from memory.
Short [build 20186 - DVD 12/2009]	Returns a word (16-bit) from memory. Same as function Data.Word(). NOTE: Please don't mix up the function <code>Data.Short()</code> and its function short form <code>D.S()</code> with the command <code>Data.Set</code> and its command short form <code>D.S</code> NOTE: <code>D.S()</code> was an alias for <code>Data.STRing()</code> in former versions of TRACE32.
Word	Returns a word (16-bit) from memory.
TByte	Returns a 3-byte value from memory.
Long	Returns a long value (32-bit) from memory. NOTE: Please don't mix up the function <code>Data.Long()</code> and its function short form <code>D.L()</code> with the command <code>Data.List</code> and its command short form <code>D.L</code>
PByte	Returns a 5-byte value from memory.
HByte	Returns a 6-byte value from memory.
SByte	Returns a 7-byte value from memory.
SLong	Returns a signed long value from memory - sign extended internally to a 64-bit value.
Quad	Returns a 64-bit value from memory. Same as function Data.LongLong() .
LongLong [build 20186 - DVD 12/2009]	Returns a 64-bit value from memory. Same as function Data.Quad() .

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

Example 1:

```
PRINT Data.Byte(D:0x200)    // long form of the function name

PRINT Data.Byte(a+17.)      // prints the memory contents of the address
                             // of target program symbol "a" plus offset
                             // 17 independent of the symbol type

PRINT Data.Byte(0x200)      // fails - parameter is a numeric constant
                             // and no address
                             // access mode specifier e.g. "D:" or "P:"
                             // is missing
```

Example 2:

```
PRINT Data.TByte(D:0x200)

PRINT Data.TByte(0x200)    // fails - parameter is a numeric constant
                           // and no address
                           // access mode specifier e.g. "D:" or "P:"
                           // is missing
```

Example 3:

```
// Set bit 4 of 32-bit value in memory
Data.Set A:0x10200 %Long Data.Long(A:0x10200)|0x10

// Clear second byte of 32-bit value in memory
Data.Set A:0x10300 %Long Data.Long(A:0x10300)&~0xff00
```

Syntax:	Data.<value_width>.<endianness>(<address>)
<value_width>:	Byte Short Word TByte Long PByte HByte SByte SLong Quad LongLong
<endianness>:	LittleEndian BigEndian
Full function name only required for HELP.Index:	Data.Short.BigEndian(<address>) Data.Short.LittleEndian(<address>) Data.Word.BigEndian(<address>) Data.Word.LittleEndian(<address>) Data.Long.BigEndian(<address>) Data.Long.LittleEndian(<address>) Data.LongLong.BigEndian(<address>) Data.LongLong.LittleEndian(<address>) Data.Quad.BigEndian(<address>) Data.Quad.LittleEndian(<address>)

Reads a value of the size <value_width> from memory at the given address in the given byte order.

The address must be classified, e.g. D:0x200, while each symbol has its own implicit memory class.

The possible memory classes depend on the target CPU. The appropriate list can be found in the chapter “Access Classes” of the particular [Processor Architecture Manual](#).

<value_width>.<endianness>	Description of Data.<value_width>.<endianness>()
Short.BigEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to big endian. Same as function Data.Word.BigEndian() .
Short.LittleEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to little endian. Same as function Data.Word.LittleEndian() .
Word.BigEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to big endian. Same as function Data.Short.BigEndian() .
Word.LittleEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to little endian. Same as function Data.Short.LittleEndian() .
Long.BigEndian	Returns a long value (32-bit) from memory, while the byte order of the word is forced to big endian.
Long.LittleEndian	Returns a long value (32-bit) from memory, while the byte order of the word is forced to little endian.
LongLong.BigEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to big endian. Same as function Data.Quad.BigEndian() .

<value_width>. <endianness>	Description of Data.<value_width>.<endianness>()
LongLong.LittleEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to little endian. Same as function Data.Quad.LittleEndian() .
Quad.BigEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to big endian. Same as function Data.LongLong.BigEndian() .
Quad.LittleEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to little endian. Same as function Data.LongLong.LittleEndian() .

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

Examples:

```
// Set bit 4 of 32-bit value in memory
Data.Set A:0x10200 %Long %BE Data.Long.BigEndian(A:0x10200) | 0x10

// Clear second byte of 32-bit value in memory
Data.Set A:0x10300 %Long %BE Data.Long.BigEndian(A:0x10300) &~0xff00
```


Syntax:	Data.<value_width>.<access_width>(<address>)
<value_width>:	WORD LONG QUAD
<access_width>:	Byte Word Long
Full function name only required for HELP.Index:	Data.Word.Byte(<address>) Data.Word.Word(<address>) Data.Long.Byte(<address>) Data.Long.Word(<address>) Data.Long.Long(<address>) Data.Quad.Byte(<address>) Data.Quad.Word(<address>) Data.Quad.Long(<address>) Data.Quad.Quad(<address>)

Reads a value of the size <value_width> from memory at the given address. The memory is therefore accessed with <access_width> if this access width is supported by the CPU and/or memory class.

The address must be classified, e.g. D:0x200, while each symbol has its own implicit memory class.

The possible memory classes depend on the target CPU. The appropriate list can be found in the chapter “Access Classes” of the particular [Processor Architecture Manual](#).

<value_width>. <access_width>	Description of Data.<value_width>.<access_width>()
Word.Byte	Performs two 8-bit accesses to return a 16-bit value from memory.
Word.Word	Alias for Data.Word() .
Long.Byte	Performs four 8-bit accesses to return a 32-bit value from memory.
Long.Word	Performs two 16-bit accesses to return a 32-bit value from memory.
Long.Long	Alias for Data.Long() .
Quad.Byte	Performs eight 8-bit accesses to return a 64-bit value from memory.
Quad.Word	Performs four 16-bit accesses to return a 64-bit value from memory.
Quad.Long	Performs two 32-bit accesses to return a 64-bit value from memory.
Quad.Quad	Alias for Data.Quad() .

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

Example:

```
ECHO Data.Long.Byte(D:0x200)
```

See also commands: [MAP.BUS8](#), [MAP.BUS16](#), and [MAP.BUS32](#)

Data.AL.ERRORS()

Get number of errors detected by Data.AllocList

Syntax:

Data.AL.ERRORS()

Returns the number of errors detected by the [Data.AllocList](#) command.

Return Value Type: [Decimal value](#).

Data.Float()

Get floating point number

Syntax:

Data.Float("<format>",<address>)

Reads a floating point number from memory.

Parameter and Description:

<format>	Parameter Type: String .
<address>	Parameter Type: Address .

Return Value Type: [Float](#).

Examples:

```
PRINT Data.Float("IEEE",D:0x200)
PRINT Data.Float("IEEE",Var.ADDRESS(f_voltage[0].fVal))
PRINT Data.Float("IEEEDBL",D:0x200)
```

Syntax: **Data.STRING(<address>)**

Reads a zero-terminated string from memory. The address must be classified, e.g. D:0x200, while each symbol has its own implicit memory class.

Parameter Type: [Address](#).

Return Value Type: [String](#).


Example:

```
LOCAL &str1 &str2

Data.Set VM:0x0  "Hello World!" 0      ;set two zero-terminated strings
Data.Set VM:0x30 "Hello Universe!" 0    ;to the TRACE32 virtual memory

&str1=Data.STRING(VM:0x0)              ;read the first string
&str2=Data.STRING(VM:0x30)             ;read the second string

PRINT "&str1    &str2"                 ;print both to the message line
AREA.view                             ;display both in the AREA window
```



- A In the byte-formatted output, 00 indicates a zero-terminated string.
- B In the ASCII-formatted output, ~~NU~~ indicates a zero-terminated string.

Syntax:

Data.STRINGN(<address>,<length>)

Reads a string from memory. The result is a zero-terminated string. The address must be classified, e.g. D:0x3a0, while each symbol has its own implicit memory class. If the string length is smaller than <length>, only <length> characters are returned.

Parameter and Description:

<address>	Parameter Type: Address .
<length>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [String](#).

Example:

```
PRINT Data.STRINGN(D:0x3a0,10.)    ;reads 10 characters starting at
                                   ;memory address D:0x3a0
```

Syntax:

Data.SUM()

Gets the checksum of the last executed [Data.SUM](#) command.

Return Value Type: [Hex value](#).

Example:

```
Data.Set P:0x00--0xff %Byte 1
Data.SUM P:0x00--0xff
PRINT Data.SUM()                ;displays the value 0x100
```

Syntax:

Data.SWAP.<value_width>.<swap_width>(<value>)

<value_width>:

Word | Long | Quad

<swap_width>:

Byte | Word | Long

Full function name only required for HELP.Index:

Data.SWAP.Word.Byte(<value>)
Data.SWAP.Long.Byte(<value>)
Data.SWAP.Long.Word(<value>)

Data.SWAP.Quad.Byte(<value>)
Data.SWAP.Quad.Word(<value>)
Data.SWAP.Quad.Long(<value>)

Swaps byte groups of the size <swap_width> in <value>. The input <value> is truncated or extended to the given <value_width>. This can be used to swap a data word between big and little endianness for example.

<value_width>. <swap_width>	Description of Data.SWAP.<value_width>.<swap_width>()
Word.Byte	Swaps bytes in a 16-bit word <value>[15:0]. Result: <value>[7:0][15:8]
Long.Byte	Swaps bytes in a 32-bit word <value>[31:0]. Result: <value>[7:0][15:8][23:16][31:24]
Long.Word	Swaps 16-bit words in a 32-bit word <value>[31:0]. Result: <value>[15:0][31:16]
Quad.Byte	Swaps bytes in a 64-bit word <value>[63:0]. Result: <value>[7:0][15:8][23:16][31:24][39:32][47:40][55:48][63:56]
Quad.Word	Swaps 16-bit words in a 64-bit word <value>[63:0]. Result: <value>[15:0][31:16][47:32][63:48]
Quad.Long	Swaps 32-bit words in a 64-bit word <value>[63:0]. Result: <value>[31:0][63:32]

Parameter Type: [Hex value](#).

Return Value Type: [Hex value](#).

Examples:

```
                                // Result:
PRINT Data.SWAP.Long.Byte(0xFF339922) // 0x229933FF
PRINT Data.SWAP.Long.Word(0xFF339922) // 0x9922FF33
PRINT Data.SWAP.Word.Byte(0xFF339922) // 0x2299                (truncated)
PRINT Data.SWAP.Quad.Long(0x9922)      // 0x0000992200000000 (extended)
```

Syntax: **Data.WSTRING(<address>)**

Reads a zero-terminated wide string from memory. The address must be classified, e.g. D:0x200, while each symbol has its own implicit memory class. The function extracts the least significant byte of each wide character.

If a BOM is found at the beginning of the string, it is removed from the output. An error is thrown if the BOM does not match the current endianness of the core.

Parameter Type: [Address](#).

Return Value Type: [String](#).

Example:

```
PRINT Data.WSTRING(D:0x200)
```

See also: [Data.STRING\(\)](#)

Data.WSTRING.BigEndian()

Get big-endian wide string

[build 43885 - DVD 02/2013]

Syntax: **Data.WSTRING.BigEndian(<address>)**

Reads a zero-terminated big-endian wide string from memory. The address must be classified, e.g. D:0x200, while each symbol has its own implicit memory class. The function extracts the least significant byte of each wide character.

If a BOM is found at the beginning of the string, it is removed from the output. An error is thrown if the BOM signals that the string is not big-endian.

Parameter Type: [Address](#).

Return Value Type: [String](#).

Syntax: **Data.WSTRING.LittleEndian(<address>)**

Reads a zero-terminated little-endian wide string from memory. The address must be classified, e.g. D:0x200, while each symbol has its own implicit memory class. The function extracts the least significant byte of each wide character.

If a BOM is found at the beginning of the string, it is removed from the output. An error is thrown if the BOM signals that the string is not little-endian.

Parameter Type: [Address](#).

Return Value Type: [String](#).

DEBUGGER.FEATURE()

Check debugger feature

[build 140670 - DVD 02/2022]

Syntax:	DEBUGGER.FEATURE(<feature>)
<feature>:	INSTRUCTIONSETSIMULATION

Returns TRUE if the started PowerView executable contains an instruction set simulator.

Parameter Type: [String](#).


Return Value Type: [Boolean](#).

DEBUGMODE()

Current debug mode

Syntax: **DEBUGMODE()**

Returns the current debug mode.



- A** Displays the current debug mode in the [state line](#).
- B** Right-click the current debug mode to change the debug mode manually.

Return Value Type: [String](#).

Return Value and Description:

ASM	Assembler mode. For more information, see Mode.Asm command.
MIX	Mixed mode. For more information, see Mode.Mix command.
HLL	High-level language mode. For more information, see Mode.Hll command.

Example: If the **DEBUGMODE()** function returns a value other than HLL, then the [Mode.Hll](#) command automatically sets the debug mode to HLL.

```
IF DEBUGMODE() != "HLL"  
    Mode.Hll
```

DISASSEMBLE.ADDRESS()

Disassembled instruction at address

[build 18929 - DVD 12/2009]

Syntax: **DISASSEMBLE.ADDRESS(<address>)**

Returns the disassembled instruction at a given address.

Parameter Type: [Address](#).

Return Value Type: [String](#).

DONGLEID Function

DONGLEID()

Serial number of USB WibuKey

Syntax:	DONGLEID(<wibukey_index>)
<wibukey_index>:	0 ...

Returns the serial number of your USB WibuKey.

Return Value Type: [Decimal value](#).

ELA Function (ARM Coresight Embedded Logic Analyzer)

ELABASE()	ELA base address
-----------	------------------

[build 77745 - DVD 02/2017]

Syntax:ELABASE()

Returns the base address of the ARM Coresight Embedded Logic Analyzer.

Return Value Type: [Address](#).

See also: [ELA](#) command group.

DPP Function (C166/ST10 only)

DPP()	Content of DPP register
-------	-------------------------

C166/ST10 only

Syntax:DPP(<register>)

Returns the content of the selected DPPn register.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

In This Section

See also

- [EPOC.DATAADDRESS\(\)](#)
- [EPOC.ENTRYPOINT\(\)](#)
- [EPOC.TEXTADDRESS\(\)](#)

EPOC.DATAADDRESS()

Start address of data area (EPOC debugger)

For EPOC debugger dbg only

Syntax:

EPOC.DATAADDRESS()

Returns the start address of the data area of the currently active debug task.

Return Value Type: [Hex value](#).

EPOC.ENTRYPOINT()

Entry address of debug task

For EPOC debugger dbg only

Syntax:

EPOC.ENTRYPOINT()

Returns the entry address of the currently active debug task.

Return Value Type: [Hex value](#).

EPOC.TEXTADDRESS()

Start address of code area (EPOC debugger)

For EPOC debugger dbg only

Syntax:

EPOC.TEXTADDRESS()

Returns the start address of the code area of the currently active debug task.

Return Value Type: [Hex value](#).

ERROR Functions (target-dependent)

ERROR.ADDRESS()

Address of last occurred memory access error

Syntax: **ERROR.ADDRESS()**

Returns the address of the occurred error from the last executed TRACE32 command.

Return Value Type: [Address](#)

```
ON.ERROR GOSUB error_handler


<Data.Set commands>

ON.ERROR nothing
ENDDO

error_handler:
    LOCAL &addr &cont
    &addr=ERROR.ADDRESS()
    DIALOG.YESNO "Error occurred accessing address &addr, continue?"
    ENTRY &cont
    IF &cont==FALSE()
        ENDDO
    RETURN
```

ETM Functions

This figure provides an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- | | | | |
|-------------------|------------------|------------------|-----------------------|
| ■ ETM | □ ETM() | □ ETM.ADDRCOMP() | □ ETM.ADDRCOMPTOTAL() |
| □ ETM.COUNTERS() | □ ETM.DATACOMP() | □ ETM.EXTIN() | □ ETM.EXTOUT() |
| □ ETM.FIFOFULL() | □ ETM.MAP() | □ ETM.PROTOCOL() | □ ETM.SEQUENCER() |
| □ ETM.TraceCore() | | | |

ETM() TRUE if ETM trace is available

[\[Go to figure\]](#)

Syntax: **ETM()**

Returns TRUE if ETM trace is available.

Return Value Type: [Boolean](#).

Syntax:

ETM.ADDRCOMP()

Returns the index number of the last ETM address comparator assigned (for internal usage only).

Return Value Type: [Decimal value](#).

ETM.ADDRCOMPTOTAL()

Number of ETM address comparator pair

Syntax:

ETM.ADDRCOMPTOTAL()

Returns the number of ETM address comparator pairs available.

Return Value Type: [Decimal value](#).

ETM.COUNTERS()

Number of ETM counters

Syntax:

ETM.COUNTERS()

Returns the number of ETM counters available.

Return Value Type: [Decimal value](#).

ETM.DATACOMP()

Number of ETM data comparators

[\[Go to figure\]](#)

Syntax:

ETM.DATACOMP()

Returns the number of ETM data comparators available.

Return Value Type: [Decimal value](#).

Syntax:

ETM.EXTIN()

Returns the number of external ETM inputs.

Return Value Type: [Decimal value](#).

Syntax:

ETM.EXTOUT()

Returns the number of external ETM outputs.

Return Value Type: [Decimal value](#).

Syntax:

ETM.FIFOFULL()

Returns 1 if ETM fifofull logic available.

Return Value Type: [Decimal value](#).

Syntax:

ETM.MAP()

Returns the number of ETM memory map decoders.

Return Value Type: [Decimal value](#).

Syntax:

ETM.PROTOCOL()

Returns the ETM protocol version.

Return Value Type: [Decimal value](#).

ETM.SEQUENCER()

Number of ETM sequencers

Syntax:

ETM.SEQUENCER()

Returns the number of ETM sequencers available.

Return Value Type: [Decimal value](#).

ETM.TraceCore()

TRUE if the core is traced

Arm

[build 127768 - DVD 02/2021]

Syntax:

ETM.TraceCore(<n>)

Allows to read back the configuration set by [ETM.TraceCORE](#). Returns TRUE if the specified core is traced.

Parameter Type: [Decimal value](#).

Return Value Type: [Boolean](#).

EXTENDED Function (Z80 only)

EXTENDED()

TRUE if register CBAR > 0

Syntax:

EXTENDED()

Returns TRUE if the register CBAR is > 0 (only Z80).

Return Value Type: [Boolean](#).

FDX.INSTRING()

Content at FDX memory address

Syntax:

FDX.INSTRING(<address>)

Returns the content at the given FDX memory address.

Parameter Type: [Address](#).

Return Value Type: [String](#).

FDX.TargetSTALLS()

Monitor FDX communication stalls on the target

[build 147494 - DVD 09/2022]

Syntax:

FDX.TargetSTALLS()

Returns TRUE when one of the FDX channels has been signalled as a stall of the FIFO used to transfer data from the target to the host since the last initialization.

Return Value Type: [Boolean](#).

In This Section

See also

- ▢ [FLAG\(\)](#)
- ▢ [FLAG.READ\(\)](#)
- ▢ [FLAG.WRITE\(\)](#)

FLAG()

TRUE if hardware flag system available

Syntax:

FLAG()

Returns TRUE if hardware flag system is available.

Return Value Type: [Boolean](#).

FLAG.READ()

FLAG memory bytes with read access bit

Syntax:

FLAG.READ(<address_range>)

Returns the number of bytes with set Read access bit of the Flag memory.

Parameter Type: [Address range](#).

Return Value Type: [Decimal value](#).

FLAG.WRITE()

FLAG memory bytes with write access bit

Syntax:

FLAG.WRITE(<address_range>)


Returns the number of bytes with set Write access bit of the Flag memory.

Parameter Type: [Address range](#).

Return Value Type: [Decimal value](#).

FLASH Functions

This figure provides an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.



A Alias range.

NOTE: All **FLASH.SECTOR.*()** functions do not take any ALIAS range into account, but observe only declared sectors.
For an example of an ALIAS range, see [A] in the figure above.

In This Section

See also

- FLASH
- FLASH.CFI.WIDTH()
- FLASH.ID()
- FLASH.List.TYPE()
- FLASH.ProgramMODE.OPTION()
- FLASH.SECTOR.END()
- FLASH.SECTOR.EXTRAValue()
- FLASH.SECTOR.OPTION()
- FLASH.SECTOR.RANGE()
- FLASH.SECTOR.STATE()
- FLASH.SECTOR.WIDTH()
- FLASH.TARGET.CODERANGE()
- FLASH.TARGET.FILE()
- FLASH.TARGET2.DATARANGE()
- FLASH.UNIT()
- FLASH.UNIT.END()
- FLASH.UNIT.NEXT()
- FLASH.CFI.SIZE()
- FLASH.CLock.Frequency()
- FLASH.List.STATE.PENDING()
- FLASH.ProgramMODE()
- FLASH.SECTOR.BEGIN()
- FLASH.SECTOR.EXIST()
- FLASH.SECTOR.NEXT()
- FLASH.SECTOR.OTP()
- FLASH.SECTOR.SIZE()
- FLASH.SECTOR.TYPE()
- FLASH.TARGET.BUILD()
- FLASH.TARGET.DATARANGE()
- FLASH.TARGET2.CODERANGE()
- FLASH.TARGET2.FILE()
- FLASH.UNIT.BEGIN()
- FLASH.UNIT.EXIST()

Syntax:

FLASH.CFI.SIZE(<address>,<bus_width>)

Returns the size of single or parallel CFI-conform FLASH devices.

Parameter and Description:

<address>	Parameter Type: Address .
<bus_width>	Parameter Type: String .

Return Value Type: [Hex value](#). Returns 0 if TRACE32 cannot read the CFI information.

Example:

```
PRINT FLASH.CFI.SIZE(P:0x0,Word)
PRINT FLASH.CFI.SIZE(D:0x40000000,Long)
```

Syntax:

FLASH.CFI.WIDTH(<address>)

Returns the data bus width of single or parallel CFI-conform FLASH devices.

Parameter Type: [Address](#).

Return Value Type: [String](#). Returns an empty string if TRACE32 cannot read the CFI information.

Syntax:

FLASH.CLock.Frequency()

Returns the FLASH clock value configured by the [FLASH.CLock](#) command. In case of the [FLASH.CLock AUTO](#) command, the function returns the frequency of the last time-measurement.

Return Value Type: [Decimal value](#).

Syntax:

FLASH.ID(<id_type>)

<id_type>:

MANID | MANIDBANK | DEVID | DEVID2 | DEVID3

After the **FLASH.GETID** command has been executed, you can use the **FLASH.ID()** function to return individual values from the output of the **FLASH.GETID** command, such as the manufacturer ID or device ID of a FLASH device.

Parameter Type: **String**.

Parameter and Description:

MANID	Manufacturer ID
MANIDBANK	Manufacturer ID bank
DEVID, DEVID2, DEVID3	Device ID 1, 2, or 3


Return Value Type: **Hex value**. Returns 0 if (a) the requested ID does not exist or (b) the **FLASH.GETID** command has not yet been executed or (c) the **FLASH.GETID** command has encountered an error.

Example:

```
FLASH.GETID 0x0 Word      ;print the FLASH manufacturer ID and the device
                           ;IDs to the message area A000
AREA.view                 ;optional step: open an AREA window to view the
                           ;output of the FLASH.GETID command

RePeaT 2.                 ;optional step: insert two empty lines
    PRINT " "

;you can now use the FLASH.ID() function to return individual values:
PRINT "Manufacturer ID: " FLASH.ID(MANID)
PRINT "Device ID 1      : " FLASH.ID(DEVID)
```



- A Output of the **FLASH.GETID** command
- B Individual values returned by the **FLASH.ID()** function from the output of the **FLASH.GETID** command.

Syntax:

FLASH.List.STATE.PENDING()

Returns the number of pending sectors in the **FLASH.List** window.

Return Value Type: [Decimal value](#).

Example: The function **FLASH.List.STATE.PENDING()** returns the number of modified sectors when **AUTO** or **ReProgram** mode is active.

```
FLASH.ReProgram.ALL
Data.LOAD.auto *
PRINT "Modified sectors: " FLASH.List.STATE.PENDING()
FLASH.ReProgram.off
```

Syntax:

FLASH.List.TYPE(<address>)

Returns the FLASH family code of a FLASH list entry. The code is displayed in the **type** column of the **FLASH.List** window.


Parameter Type: [String](#).

Return Value Type: [Address](#).

Example:

```
PRINT FLASH.List.TYPE(C:0x08000001) ;returns ALIAS

PRINT FLASH.List.TYPE(C:0x0C004003) ;returns TARGET
```



Syntax:

FLASH.ProgramMODE()

Returns the active FLASH programming mode.

Return Value Type: [String](#). An empty string is returned if none of the FLASH programming modes listed in the table below is active.

Return Value and Description:


AUTO	The auto programming mode has been activated with FLASH.AUTO .
Program	The FLASH programming mode has been activated with FLASH.Program .
ReProgram	The FLASH reprogramming mode has been activated with FLASH.ReProgram .

Example:

```
FLASH.List

;activate the FLASH reprogramming mode
FLASH.ReProgram C:0xA0004000--0xA00BFFF ;the active mode is shown in
                                           ;the 'state' column of the
                                           ;FLASH.List window

PRINT FLASH.ProgramMODE()                ;returns the active mode
                                           ;'ReProgram'
```



Syntax:

FLASH.ProgramMODE.OPTION()

Returns the active FLASH programming option.

Return Value Type: [String](#). An empty string is returned if none of the options listed in the table below is active.

Return Value and Description:

/OTP	FLASH programming for the OTP sector is active. See also FLASH.Program ... /OTP .
/CENSORSHIP	Auto programming for the FLASH security bytes is active. See also FLASH.AUTO ... /CENSORSHIP .


Example:

```
FLASH.Program 6. /OTP           ;activate the FLASH programming mode
                                ;for the OTP sector

FLASH.List                      ;the active option OTP is shown in the
                                ;'state' col. of the FLASH.List window

PRINT FLASH.ProgramMODE()       ;returns the active mode 'Program'

PRINT FLASH.ProgramMODE.OPTION() ;returns the active option '/OTP'
```



Syntax: **FLASH.SECTOR.BEGIN(<address>)**

Returns the start address of the sector. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

Syntax: **FLASH.SECTOR.END(<address>)**

Returns the end address of the sector. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

Syntax: **FLASH.SECTOR.EXIST(<address>)**

Returns TRUE if the sector exists. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Syntax: FLASH.SECTOR.EXTRAvalue(<address>)

Returns the extra value created with the command FLASH.Create. Please read the NOTE regarding the FLASH.SECTOR.*() functions.

The extra value and other information is displayed in the extra column of the FLASH.List window. The function FLASH.SECTOR.EXTRAvalue(), however, returns only the extra value.

Parameter Type: Address.


Return Value Type: Hex value.

Example:

```
;                                     <extra_value>
;                                     |
FLASH.Create 2. 0x00684000--0x00687FFF NOP Quad 0x0101 /INFO "HSM data"

FLASH.List

;returns 101, i.e. the <extra_value>, without leading zeros
PRINT FLASH.SECTOR.EXTRAvalue(C:0x00684000)
```



A The extra value, here 101, is displayed with leading zeros in the FLASH.List window.

Syntax:

FLASH.SECTOR.NEXT(<address>)

Returns the address of the next sector or address 0x0. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

Syntax:

FLASH.SECTOR.OTP(<address>)

Returns TRUE if the sector is declared as OTP. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

Syntax:

FLASH.SECTOR.OPTION(<address>,<option> | ALL)

Returns the options of a FLASH sector in the same syntax as used by the **FLASH.Create** command. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter and Description:

<address>	Parameter Type: Address . Any address of a sector. The address has to be classified, e.g. C:0x1000000 .
<option>	Parameter Type: String . You can pass any <option> of the FLASH.Create command, provided the result of the option is displayed in the FLASH.List window in the extra column. See screenshot below. An error message is displayed if an invalid option name is used.
ALL	Parameter Type: String . Returns all options of a sector that are displayed in the extra column. See screenshot below.

NOTE:

To return the extra value of a sector, use **FLASH.SECTOR.EXTRAvalue()**.


Return Value Type: [String](#). An empty string is returned if the option is not used for a sector.

Example:

```
FLASH.Create 0x1000000--0x100FFFF 0x4000 TARGET Long 0x0 \
                                     /AutoInc /KEEP 0x1003FFC--0x1003FFF
FLASH.Create 0x0400000--0x0403FFF 0x4000 TARGET Long 0x500 \
                                     /OTP /INFO "UTEST sector"
FLASH.List

PRINT FLASH.SECTOR.OPTION(C:0x1000000,KEEP)
                                ;returns: /KEEP 0x1003FFC--0x1003FFF

PRINT FLASH.SECTOR.OPTION(C:0x0400000,ALL)
                                ;returns: /OTP /INFO "UTEST sector"
```



Examples of <options> displayed in the **extra** column.
FLASH.SECTOR.OPTION()

FLASH.SECTOR.EXTRAvalue().
The option **AutoInc** of **FLASH.Create** affects the extra value.

Syntax:

FLASH.SECTOR.RANGE(<address>)

Returns the address range of a sector. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [Address range](#).

FLASH.SECTOR.SIZE()

Size in bytes

Syntax:

FLASH.SECTOR.SIZE(<address>)

Returns the size of the flash sector in bytes. Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

FLASH.SECTOR.STATE()

FLASH programming state

Syntax:

FLASH.SECTOR.STATE(<address>)

Returns the FLASH programming state of a sector. The state is displayed in the **state** column of the [FLASH.List](#) window.

Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [String](#). An empty string is returned if the specified address is not inside any sector or if the **state** column is empty.

Syntax:

FLASH.SECTOR.TYPE(<address>)

Returns the FLASH family code of a sector. The code is displayed in the **type** column of the **FLASH.List** window.

Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.


Parameter Type: [Address](#).

Return Value Type: [String](#). An empty string is returned if the specified address is not inside any sector.

Example:

```
PRINT FLASH.SECTOR.TYPE(C:0x08000001) ;returns an empty string because
                                         ;the address is neither in the
                                         ;sectors of unit 1. nor unit 2.

PRINT FLASH.SECTOR.TYPE(C:0x0C004003) ;returns TARGET
```



A Sectors of unit 1.

B Sectors of unit 2.

Syntax: **FLASH.SECTOR.WIDTH(<address>)**

Returns the width of a FLASH sector. The information is displayed in the **width** column of the **FLASH.List** window.

Please read the **NOTE** regarding the **FLASH.SECTOR.*()** functions.

Parameter Type: [Address](#).

Return Value Type: [String](#). Returns an empty string if the address is not inside any sector.

FLASH.TARGET.BUILD()

Build number of FLASH algorithm file

[build 33191 - DVD 02/2012]

Syntax: **FLASH.TARGET.BUILD(<file>)**

Returns the build number of the FLASH algorithm binary file or 0 if the file has no build number. The build number of the FLASH algorithm binary is independent of the TRACE32 build number.

Parameter Type: [String](#).

Return Value Type: [Decimal value](#).

Syntax:

FLASH.TARGET.CODERANGE()

FLASH.TARGET2.CODERANGE()

Returns the address range where the code of the FLASH algorithm binary file and the software breakpoint is located. The address range is declared with the **FLASH.TARGET** or **FLASH.TARGET2** command.

Return Value Type: [Address range](#).

Syntax:

FLASH.TARGET.DATARANGE()

FLASH.TARGET2.DATARANGE()

Returns the address range where the argument buffer, the data buffer, and the stack used by the FLASH algorithm binary file are located. The address range is declared with the **FLASH.TARGET** or **FLASH.TARGET2** command.

Return Value Type: [Address range](#).

Syntax:

FLASH.TARGET.FILE()
[build 48531]

FLASH.TARGET2.FILE()
[build 67392 - DVD 02/2016]

Returns the file name of the FLASH algorithm binary declared with the **FLASH.TARGET** or **FLASH.TARGET2** command.

Return Value Type: [String](#).

Syntax: **FLASH.UNIT(<address>)**

Returns the unit number of a FLASH sector. Returns 0 if the sector does not exist.

Parameter Type: [Address](#).

Return Value Type: [Decimal value](#).

FLASH.UNIT.BEGIN()

Unit start address

[build 41711]

Syntax: **FLASH.UNIT.BEGIN(<unit>)**

Returns the start address of the unit or displays the error #emu_flashnfnfnd if the unit does not exist.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

FLASH.UNIT.END()

Unit end address

[build 41711]

Syntax: **FLASH.UNIT.END(<unit>)**

Returns the end address of the unit or displays the error #emu_flashnfnfnd if the unit does not exist.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

Syntax:

FLASH.UNIT.EXIST(<unit>)

Returns TRUE if the unit exists, otherwise FALSE.

Parameter Type: [Decimal value](#).

Return Value Type: [Boolean](#).

Syntax:

FLASH.UNIT.NEXT(<unit>)

Returns the number of the next unit. Returns 0 if there is no next unit.

Parameter Type: [Decimal value](#).

Return Value Type: [Decimal value](#).

In This Section

See also

- FLASHFILE

□ FLASHFILE.GETBADBLOCK.NEXT()
- FLASHFILE.GETBADBLOCK.COUNT()

□ FLASHFILE.SPAREADDRESS()

FLASHFILE.GETBADBLOCK.COUNT()

Number of bad blocks

Syntax:

FLASHFILE.GETBADBLOCK.COUNT()

After the **FLASHFILE.GETBADBLOCK** command has been executed, this function returns the number of the bad blocks on the NAND flash memory.

Return Value Type: [Hex value](#).

Example:

```
FLASHFILE.GETBADBLOCK 0x0--0xFFFFF      ; test range 0x0--0xFFFFF for bad
                                           ; blocks

&badblockcount=FLASHFILE.GETBADBLOCK.COUNT()

PRINT "Number of bad blocks: " &badblockcount
```

FLASHFILE.GETBADBLOCK.NEXT()

Address of bad block

[\[Example\]](#)

Syntax:

FLASHFILE.GETBADBLOCK.NEXT()

After the **FLASHFILE.GETBADBLOCK** command has been executed, this function returns the addresses of the bad blocks on the NAND flash memory.

Return Value Type: [Hex value](#).

Example:

```
FLASHFILE.GETBADBLOCK 0x0--0xFFFFF      ; test range 0x0--0xFFFFF for bad
                                           ; blocks

&badblockcount=FLASHFILE.GETBADBLOCK.COUNT()
&loopNum=&badblockcount

WHILE (&loopNum>0)
(
    PRINT %Hex "Bad block address: 0x" FLASHFILE.GETBADBLOCK.NEXT()
    &loopNum=&loopNum-1.
)
```

FLASHFILE.SPAREADDRESS()

Address of spare area

Syntax:

FLASHFILE.SPAREADDRESS(<address>)

Returns the address of a NAND flash spare area (SP) based on the specified main area address.
<address> is the address of the main area.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Return Value Type: [Hex value](#).

Example: The page size of our example NAND flash main / spare area is 2048 byte / 64 byte, and each row stands for one page.

address	Main Area	SP	address
0x0			0x0
0x800			0x40
0x1000			0x80

```
;                                <main_area_address>
PRINT FLASHFILE.SPAREADDRESS(0x800)    ;returns the corresponding
                                       ;spare area address, here:
                                       ;0x40
```

In This Section

See also

- [FPU](#)
- [FPU\(\)](#)
- [FPU.RAW\(\)](#)
- [FPUCR\(\)](#)

FPU()

FPU register contents

Syntax:

FPU(<name>)

Returns the FPU register contents.

Parameter Type: [String](#).

Return Value Type: [Float](#).

FPUCR()

FPU control register contents

Syntax:

FPUCR(<name>)

Returns the FPU control register contents.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

FPU.RAW()

FPU register raw contents

AndeStar, ARM, C2000, ColdFire, MIPS32, MMDSP, PowerPC, SH

Syntax:

FPU.RAW(<name>)

Returns the hexadecimal raw content of the given FPU control register.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

FXU()	Content of FXU register
RH850	[build 81540 - DVD 09/2017]

Syntax: **FXU(<register_name>)**

Returns the content of the selected FXU register.

Parameter Type: [String](#).

Return Value Type: [String](#).

See also: [FXU](#) command group.

GROUP Function

GROUP.EXIST()	TRUE if group exists
---------------	----------------------

Syntax: **GROUP.EXIST(<group_name>)**

Returns TRUE if a group name already exists, FALSE otherwise.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

See also: [GROUP](#) command group.

In This Section

The hardware function allows to check which TRACE32 hardware is plugged in.

See also

- [hardware.COMBIPROBE\(\)](#)
 - [hardware.ICD\(\)](#)
 - [hardware.POWERINTEGRATOR2\(\)](#)
 - [hardware.POWERPROBE\(\)](#)
 - [hardware.POWERTRACE2\(\)](#)
 - [hardware.POWERTRACE3\(\)](#)
 - [hardware.POWERTRACESERIAL\(\)](#)
 - [hardware.UTRACE\(\)](#)
- [hardware.ESI\(\)](#)
 - [hardware.POWERINTEGRATOR\(\)](#)
 - [hardware.POWERNEXUS\(\)](#)
 - [hardware.POWERTRACE\(\)](#)
 - [hardware.POWERTRACE2LITE\(\)](#)
 - [hardware.POWERTRACEPX\(\)](#)
 - [hardware.QUADPROBE\(\)](#)

hardware.COMBIPROBE()

TRUE if CombiProbe

Syntax:

hardware.COMBIPROBE()

Returns TRUE if a COMBIPROBE hardware is connected.

Return Value Type: [Boolean](#).

hardware.ESI()

TRUE if EPROM Simulator

Syntax:

hardware.ESI()
ESI() (deprecated)

Returns TRUE if the debugger is running via the ESI (EPROM Simulator) hardware.

Return Value Type: [Boolean](#).

Syntax:

hardware.ICD()
BDM() (deprecated)
DEBUGger() (deprecated)
ICD() (deprecated)

Returns TRUE if TRACE32 PowerView communicates with the target via a TRACE32 debug hardware. Unlike the **hardware.POWERDEBUG()** function, this also includes legacy debug modules.

Return Value Type: [Boolean](#).

hardware.POWERDEBUG()

TRUE if TRACE32 PowerDebug hardware

Syntax:

hardware.POWERDEBUG()
POWERDEBUG() (deprecated)

Returns TRUE if TRACE32 PowerView communicates with the target via a µTrace (MicroTrace), POWER DEBUG or POWERTRACE / ETHERNET hardware module.

Return Value Type: [Boolean](#).

hardware.POWERINTEGRATOR()

TRUE if a PowerIntergrator

Syntax:

hardware.POWERINTEGRATOR()
POWERINTEGRATOR() (deprecated)
INTEGRATOR() (deprecated)

Returns TRUE if a POWER INTEGRATOR hardware module is connected.

Return Value Type: [Boolean](#).

hardware.POWERINTEGRATOR2()

TRUE if a PowerIntegrator II

Syntax:

hardware.POWERINTEGRATOR2()
POWERINTEGRATOR2() (deprecated)

Returns TRUE if a POWERINTEGRATOR II hardware module is connected.

Return Value Type: [Boolean](#).

Syntax:

hardware.POWERNEXUS()
POWERNEXUS() (deprecated)

Returns TRUE if a NEXUS ADAPTER is connected.

Return Value Type: [Boolean](#).

hardware.POWERPROBE()

TRUE is a PowerProbe

Syntax:

hardware.POWERPROBE()
POWERPROBE() (deprecated)
PROBE() (deprecated)

Returns TRUE if a POWERPROBE hardware module is connected.

Return Value Type: [Boolean](#).

hardware.POWERTRACE()

TRUE if a PowerTrace Module

Syntax:

hardware.POWERTRACE()
POWERTRACE() (deprecated)

Returns TRUE if a POWERTRACE module is connected.

Additional prerequisite is that a PREPROCESSOR / NEXUS ADAPTER is also plugged in. This is not required for POWER TRACE SERIAL.

Return Value Type: [Boolean](#).

hardware.POWERTRACE2()

TRUE if a PowerTrace II

[build 14028 - DVD 10/2008]

Syntax:

hardware.POWERTRACE2()
POWERTRACE2() (deprecated)

Returns TRUE if a POWER TRACE II or POWER TRACE II LITE hardware module is connected. Additional prerequisite is that a PREPROCESSOR / NEXUS ADAPTER is also plugged in.

Return Value Type: [Boolean](#).

Syntax: **hardware.POWERTRACE2LITE()**

Returns TRUE if a POWER TRACE II LITE hardware module is connected. Additional prerequisite is that a PREPROCESSOR / NEXUS ADAPTER is also plugged in.

Return Value Type: [Boolean](#).

hardware.POWERTRACE3()**TRUE if a PowerTrace III**

[build 124115 - DVD 09/2021]

Syntax: **hardware.POWERTRACE3()**

Returns TRUE if a POWER TRACE III hardware module is connected. Additional prerequisite is that a PREPROCESSOR / NEXUS ADAPTER is also plugged in.

Return Value Type: [Boolean](#).

hardware.POWERTRACEPX()**TRUE if a PowerTrace PX**

[build 79974 - DVD 02/2017]

Syntax: **hardware.POWERTRACEPX()**

Returns TRUE if a POWER TRACE PX hardware module is connected. Additional prerequisite is that a PREPROCESSOR / NEXUS ADAPTER is also plugged in.

Return Value Type: [Boolean](#).

hardware.POWERTRACESERIAL()**TRUE if a PowerTrace Serial**

[build 78458 - DVD 02/2017]

Syntax: **hardware.POWERTRACESERIAL()**

Returns TRUE if a POWER TRACE SERIAL hardware module is connected.

Return Value Type: [Boolean](#).

Syntax: **hardware.POWERTRACESERIAL2()**

Returns TRUE if a POWER TRACE SERIAL II hardware module is connected.

Return Value Type: [Boolean](#).

hardware.QUADPROBE()**TRUE if QuadProbe**

[build 63955 - DVD 09/2016]

Syntax: **hardware.QUADPROBE()**

Returns TRUE if a QUADPROBE hardware is plugged.

Return Value Type: [Boolean](#).

hardware.UTRACE()**TRUE if μ Trace**

[build 46956 - DVD 2013/08]

Syntax: **hardware.UTRACE()**

Returns TRUE if TRACE32 PowerView communicates with the target via a μ Trace (MicroTrace),

Return Value Type: [Boolean](#).

HVX()

Content of HVX register

[build 61364 - DVD 09/2015]

Syntax: **HVX(<register_name>)**

Returns the content of the selected HVX register.

Parameter Type: [String](#).

Return Value Type: [String](#).

See also: [HVX](#) command group.

In This Section

See also

- I2C
- I2C.DATA()
- I2C.PIN()

I2C.DATA()

Data read by I2C.TRANSFER

[build 62704 - DVD 09/2015]

Syntax:

I2C.DATA(<index>)
CAalyzer.I2C.DATA(<index>) (deprecated)

Returns byte <index> read with the command **I2C.TRANSFER**.

Parameter Type: [Decimal value](#).

Return Value Type: [Decimal value](#).

I2C.PIN()

Pin status

[build 62704 - DVD 09/2015]

Syntax:

I2C.PIN(<pin_name>)

<pin_name>:

SCL | SDA

Returns the pin status 0 or 1.

Parameter Type: [String](#).

Return Value Type: [Binary value](#).

See also: [I2C.PIN](#)

In This Section

See also

- ID.CABLE()
 - ID.PREPROcessor()
 - ID.WHISKER()
 - ID.CODENUMBER()
- ID.POWERTRACEAUXPORT()
 - ID.SERialPort1()
 - ID.CODE()

ID.CABLE()

Hardware ID of debug cable

Syntax:

ID.CABLE()

Returns the hardware ID of the debug cable (not the serial number).

Return Value Type: [Hex value](#).

ID.POWERTRACEAUXPORT()

Hardware ID of device at PT aux port

[build 132426 - DVD 02/2021]

Syntax:

ID.POWERTRACEAUXPORT()

Returns the hardware ID (not the serial number) of the device of a logic analyzer extension plugged into a PowerTrace device.

Return Value Type: [Hex value](#).

To get the serial number, use the function [VERSION.SERIAL.POWERTRACEAUXPORT\(\)](#).

Return Values for PowerTrace III or PowerTrace Serial 2

The return value corresponds to the extension device plugged into the port labelled **AUX PORT V1**.

Return Values	
0x00	No extension
0x27	LA-2500 Mixed-Signal Probe COB 2/MicroTrace/PT-III
0xFF	Unknown extension, please update the TRACE32 software.

The return value corresponds to the extension plugged into the port labelled **LOGIC ANALYZER PROBE**:

Return Values	
0x00	No extension
0x07	LA-7945 Standard Probe for PowerIntegrator
0x08	LA-7949 Analog Probe for PI/PT-II/CombiProbe/μTrace (MicroTrace)
0xFF	Unknown extension, please update the TRACE32 software.

ID.PREPROcessor()

Hardware ID of preprocessor

[build 12440 - DVD 10/2008]

Syntax:

ID.PREPROcessor()

HEADID() (deprecated)
[build 07808 - DVD 09/2007]

Returns the hardware ID of the preprocessor (not the serial number).

Return Value Type: [Hex value](#).

To return the serial number, use the function [VERSION.SERIAL.PREPROcessor\(\)](#).

Syntax:

ID.SERialPort1()

Returns a 16-bit ID specifying the type of the Lauterbach device plugged to Serial Port 1 of a PowerTrace Serial.

Return Value Type: [Hex value](#).

Return Value and Description:

0x2082	Aurora 2 Preprocessor
0x208A	PCIe Gen 4 Preprocessor
0x2002	PCIe Gen 3 x8 Slot-Card-Adapter
0x2009	PCIe Gen 3 x4 Slot-Card-Adapter
0x200A	PCIe Gen 3 x1 Slot-Card-Adapter
0x2004	Adapter for AGBT
0x200B	Adapter for AGBT/SGBT via HSTCU
0x2003	Universal Trace Adapter
0x2006	Adapter for RH850-34pin
0x2007	Adapter for RH850-40pin

Syntax: **ID.WHISKER(<int>)**

Returns the ID of the whisker cable connected to the connector specified by <int>.



Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Use cases for the function **ID.WHISKER(<int>)**:

- Scripts that use TRACE32 commands that only work if a specific whisker is connected. E.g. using the [ETA](#) command group requires that a **Conv. CombiProbe/μTrace (MicroTrace) to PI-Analog Probe** plus an **Analog Probe for PI/PT-II/CombiProbe/μTrace (MicroTrace)** is connected.
- A script designed for different tool configurations can use this function to parenthesize commands applicable only for a individual configuration.

μTRACE® FOR CORTEX®-M / USB 3




<int> Parameter	
0	For connector A
1	For connector B

Return Values	
0x00	No whisker
0x01	LA-4505 MIPI34 Whisker for CombiProbe/MicroTrace
0x02	LA-4515 DCI OOB Whisker for CombiProbe (Version 1)
0x04	LA-4551 Whisker Cable TriCore DAP for CombiProbe (no longer supported)
0x05	LA-4509 CombiProbe Intel x86/x64 MIPI34 (no series termination).
0x08	LA-4508 Conv. CombiProbe/μTrace (MicroTrace) to PI-Analog Probe plus LA-7949 Analog Probe for PI/PT-II/CombiProbe/μTrace (MicroTrace)
0x09	LA-4515 DCI OOB Whisker for CombiProbe (Version 2)
0x0B	LA-4400 USB-C Breakout Module (Type-C Port)
0x0E	LA-4553 AUTO26 Whisker for CombiProbe or LA-2763 Whisker dsPIC Dual Core for CombiProbe
0x10	LA-4511 Whisker Cable MIPI60-C for CombiProbe or LA-4517 Whisker Cable MIPI60-C for CombiProbe Long
0x11	LA-4571 Whisker Cable MIPI60-Cv2 for CombiProbe (Version 2)
0x12	LA-4513 MIPI20T-HS Whisker for CombiProbe/MicroTrace
0x26	LA-4571 Whisker Cable MIPI60-Cv2 for CombiProbe (Version 2.1)
0x27	LA-2500 Mixed-Signal Probe COB 2/MicroTrace/PT-III
0xFF	Unknown whisker, please update the TRACE32 software.

Not all whiskers are supported on both ports. For whiskers that occupy both ports of the CombiProbe, the ID is returned by ID.WHISKER(0.) and ID.WHISKER(1.) returns 0x00.

The function **hardware.UTRACE()** returns TRUE if a μTrace (MicroTrace) is connected. The function **hardware.COMBIPROBE()** returns TRUE if a CombiProbe or CombiProbe 2 is connected.



<int> Parameter	
0	For connector A
1	For connector B
2	For connector C
3	For connector D

Return Values	
0x32	LA-4611 Whisker MIPI60-Q QuadProbe Intel® x86/x64 connected.
0x00	No whisker connected.
0xff	Unknown whisker, please update the TRACE32 software.

The function [hardware.QUADPROBE\(\)](#) returns TRUE if a TRACE32 QuadProbe is connected.

Syntax: **IDCODE(<n>)**

Returns the JTAG ID code of the n-th TAP in your JTAG chain after executing **SYStem.DETECT IDCode**.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Example:

```
SYStem.DETECT IDCode
PRINT "1st device in JTAG daisy chain is 0x" %Hex IDCODE(0)
```

Syntax: **IDCODENUMBER()**

Returns the number of TAPs detected by **SYStem.DETECT IDCode**.

Return Value Type: [Decimal value](#).

In This Section

See also

- [Integrator\(\)](#)
 - [Integrator.ADC.SHUNT\(\)](#)
 - [Integrator.COUNTER.EXTERN\(\)](#)
 - [Integrator.DIALOGDSEL\(\)](#)
 - [Integrator.DSEL\(\)](#)
 - [Integrator.FIND.PI_WORD\(\)](#)
 - [Integrator.FLAG\(\)](#)
 - [Integrator.MAXSIZE\(\)](#)
 - [Integrator.PROGRAMFILENAME\(\)](#)
 - [Integrator.RECORD.TIME\(\)](#)
 - [Integrator.REF\(\)](#)
 - [Integrator.STATE\(\)](#)
 - [Integrator.USB\(\)](#)
- [Integrator.ADC.ENABLE\(\)](#)
 - [Integrator.COUNTER.EVENT\(\)](#)
 - [Integrator.COUNTER.TIME\(\)](#)
 - [Integrator.DIALOGDSELGET\(\)](#)
 - [Integrator.FIND.PI_CHANNEL\(\)](#)
 - [Integrator.FIRST\(\)](#)
 - [Integrator.GET\(\)](#)
 - [Integrator.PROBE\(\)](#)
 - [Integrator.RECORD.DATA\(\)](#)
 - [Integrator.RECORDS\(\)](#)
 - [Integrator.SIZE\(\)](#)
 - [Integrator.TRACK.RECORD\(\)](#)

Integrator()

TRUE if PowerIntegrator

Syntax:

Integrator()

Returns TRUE if a PowerIntegrator is connected.

Return Value Type: [Boolean](#).

Integrator.FIRST()

Get record number of first trace record

[build 71062 - DVD 09/2016]

Syntax:

Integrator.FIRST()

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

Syntax: **Integrator.ADC.ENABLE(<channel>)**

Returns the bitmask of enabled analog channels of the Analog Probe.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Integrator.ADC.SHUNT()Shunt-resistor value

Syntax: **Integrator.ADC.SHUNT(<channel>)**

Returns the shunt-resistor value of the specified current measurement <channel> of the Analog Probe.

Parameter Type: [String](#).

Return Value Type: [Float](#).

Integrator.ANALOG()

Syntax: **Integrator.ANALOG()**

Returns a value different from zero if analog probes are plugged in a PowerIntegrator hardware. For connector A..F, J..O the values are: 0x0001..0x0020, 0x0100..0x2000.

Return Value Type: [Hex value](#).

Integrator.COUNTER.EVENT()Get value of trigger program event counter

Syntax: **Integrator.COUNTER.EVENT(<counter_name>)**

Returns the value of an event counter of the PowerIntegrator CTU.

Parameter Type: [String](#).

Return Value Type: [Decimal value](#).

Integrator.COUNTER.EXTERN()

Value of trigger program external counter

Syntax:

Integrator.COUNTER.EXTERN(<counter_name>)

Returns the value of an extern counter of the PowerIntegrator CTU.

Parameter Type: [String](#).

Return Value Type: [Decimal value](#).

Integrator.COUNTER.TIME()

Get value of trigger program time counter

Syntax:

Integrator.COUNTER.TIME(<counter_name>)

Returns the value of an time counter of the PowerIntegrator CTU.

Parameter Type: [String](#).

Return Value Type: [Time value](#).

Integrator.DIALOGDSEL()

For internal usage only

Syntax:

Integrator.DIALOGDSEL(<string>)

For internal usage only.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Integrator.DIALOGDSELGET()

For internal usage only

Syntax:

Integrator.DIALOGDSELGET()

For internal usage only.

Return Value Type: [String](#).

Syntax: **Integrator.DSEL()**

For internal usage only.

Return Value Type: [String](#).

Integrator.FIND.PI_CHANNEL()

For internal usage only

Syntax: **Integrator.FIND.PI_CHANNEL(<signal_name>)**

Returns if the specified signal-name is defined (internal use only).

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Integrator.FIND.PI_WORD()

TRUE if signal word is defined

Syntax: **Integrator.FIND.PI_WORD(<signal_word>)**

Returns TRUE if the specified signal-word is defined.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Integrator.FLAG()

Check state of trigger program FLAG

Syntax: **Integrator.FLAG(<flag_name>)**

Returns the value of a flag of the PowerIntegrator CTU.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Syntax:

Integrator.GET(<channel_name>)

Returns the current value of the channel.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

0	High
1	Low

Integrator.MAXSIZE()

Get max. size of trace buffer in records

Syntax:

Integrator.MAXSIZE()

Returns the maximum size of the PowerIntegrator trace buffer in records (value depends on the actual selected tracing mode too).

Return Value Type: [Decimal value](#).

Integrator.PROBE()

For internal usage only

Syntax:

Integrator.PROBE()

Returns the bitmask of connected probes (internal use only).

Return Value Type: [Hex value](#).

Integrator.PROGRAMFILENAME()

File name of trigger program

Syntax:

Integrator.PROGRAMFILENAME()

Returns the file name of the active trigger program.

Return Value Type: [String](#).

Integrator.RECORD.DATA()

Get data recorded in trace record

Syntax:

Integrator.RECORD.DATA(<record_number>,<channel>)

Returns the sampled data from the specified record.

Parameter and Description:

<record_number>	Parameter Type: Decimal value .
<channel>	Parameter Type: String .

Return Value Type: [Hex value](#).

Integrator.RECORD.TIME()

Get timestamp of trace record

Syntax:

Integrator.RECORD.TIME(<record_number>)

Returns the timestamp from the specified record. For an example, see [Analyzer.RECORD.TIME\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

Integrator.RECORDS()

Get number of used trace records

Syntax:

Integrator.RECORDS()

Returns the number of records.

Return Value Type: [Decimal value](#).

Integrator.REF()

Get record number of reference record

Syntax:

Integrator.REF()

The command [Integrator.REF](#) allows to mark a trace record as reference record. The function returns the record number of the reference record.

Return Value Type: [Decimal value](#).

Integrator.SIZE()

Get current trace buffer size in records

Syntax:

Integrator.SIZE()

Returns the actual defined logical size of the Power Integrator trace buffer in records.

Return Value Type: [Decimal value](#).

Integrator.STATE()

Get state of the Integrator

Syntax:

Integrator.STATE()

Returns the state of the Integrator.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

Integrator.TRACK.RECORD()

Get record number matching search

Syntax:

Integrator.TRACK.RECORD()

After a successful search operation, this function returns the record number. For an example, see [Analyzer.TRACK.RECORD\(\)](#).

Return Value Type: [Decimal value](#).


Syntax: **Integrator.USB()**

Returns a value not equal to 0 if an USB2 probe is connected (internal use only).

Return Value Type: [Hex value](#).

INTERFACE Functions

This figure provides an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.



The **INTERFACE** functions return the `PBI=` setting in the configuration file (by default `config.t32`) irrespective of the current system mode setting. The system mode settings, such as **SYSystem.Mode Up** or **SYSystem.Mode Down**, are shown in the **SYSystem.state** window. They can be returned with the **SYSystem.Mode()** function.

To open the configuration file of a TRACE32 instance:

1. Choose **Help** menu > **About TRACE32**.
2. In the **VERSION** window, click the **edit** button.

In This Section

See also

- | | | | |
|-------------------------------------|----------------------------------|---------------------------------|----------------------------------|
| INTERFACE.CADI() | INTERFACE.GDB() | INTERFACE.GDI() | INTERFACE.HOST() |
| interface.HOSTMCI() | INTERFACE.IRIS() | INTERFACE.MCD() | INTERFACE.NAME() |
| INTERFACE.QNX() | INTERFACE.SIM() | | |

INTERFACE.CADI() TRUE if connection to target is via CADI interface

Syntax: **INTERFACE.CADI()**

Returns TRUE if the debugger is connected to the target via the CADI interface (`PBI=CADI`).

Return Value Type: **Boolean**.

INTERFACE.GDB()

TRUE if connection to target is via GDB interface

Syntax: **INTERFACE.GDB()**

Returns TRUE if the debugger is connected to the target via the GDB interface (`PBI=GDB`).

Return Value Type: [Boolean](#).

INTERFACE.GDI()

TRUE if connection to target via GDI interface

Syntax: **INTERFACE.GDI()**
GDI() (deprecated)

Returns TRUE if the debugger is connected to the target via the GDI interface (`PBI=GDI`).

Return Value Type: [Boolean](#).

INTERFACE.HOST()

TRUE if application is debugged on host

Syntax: **INTERFACE.HOST()**

Returns TRUE if the debugger is connected to the application via the Native Host Debugging interface (`PBI=HOST`).

Return Value Type: [Boolean](#).

interface.HOSTMCI()

TRUE if TRACE32 debug driver runs on host

[build 38565 - DVD 08/2012]

Syntax: **interface.HOSTMCI()**

Returns TRUE if the TRACE32 debug driver runs on the host to access the target CPU by native connections or artificial back-end interfaces. The result reflects the settings `PBI=MCILIB` or `PBI=MCISERVER` of the config file.

Return Value Type: [Boolean](#).

INTERFACE.IRIS()

TRUE if connection to target is via IRIS interface

Syntax:

INTERFACE.IRIS()

Returns TRUE if the debugger is connected to the target via the IRIS interface (`PBI=IRIS`).

Return Value Type: [Boolean](#).

INTERFACE.MCD()

TRUE if connection to target via MCD interface

Syntax:

INTERFACE.MCD()

Returns TRUE if the debugger is connected to the target via the MCD interface (`PBI=MCD`).

Return Value Type: [Boolean](#).

INTERFACE.NAME()

Name of debugger

[build 76305 - DVD 09/2016]

Syntax:

INTERFACE.NAME()

Returns the name of the debugger this GUI is connected to. This is the same name as printed in the [VERSION.view](#) window, e.g. "Power Debug USB 3.0", "Simulator" or "GDI".

Return Value Type: [String](#).

INTERFACE.QNX()

TRUE if PBI=QNX

Syntax:

INTERFACE.QNX()

Returns TRUE if TRACE32 is connected to a process-level debugger for QNX (`PBI=QNX`).

Return Value Type: [Boolean](#).

Syntax: **INTERFACE.SIM()**
SIMULATOR() (deprecated)

Returns TRUE if the debugger is running on the Lauterbach Instruction Set Simulator ($PBI=SIM$).

Return Value Type: [Boolean](#).

In This Section

See also

- [IOBASE\(\)](#)
- [IOBASE.ADDRESS\(\)](#)
- [IOBASE2\(\)](#)

IOBASE()

Base address of internal I/O's

Syntax:

IOBASE()

Gets the base address of the internal I/O's without access class.

Return Value Type: [Hex value](#).

IOBASE.ADDRESS()

Base address of internal I/O's with access class

Syntax:

IOBASE.ADDRESS()

Gets the base address of the internal I/O's with access class.

Return Value Type: [Address](#).

IOBASE2()

Second base address of internal I/O's

Syntax:







IOBASE2()

Gets the second base address of the internal I/O's without access class.

Return Value Type: [Hex value](#).

IProbe Functions

These figures provide an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.



See also

- IProbe

❑ IProbe.ANALOG()

❑ IProbe.PROBE()

❑ IProbe.REF()
- ❑ IProbe()

❑ IProbe.FIRST()

❑ IProbe.RECORD.DATA()

❑ IProbe.SIZE()
- ❑ IProbe.ADC.ENABLE()

❑ IProbe.GET()

❑ IProbe.RECORD.TIME()

❑ IProbe.STATE()
- ❑ IProbe.ADC.SHUNT()

❑ IProbe.MAXSIZE()

❑ IProbe.RECORDS()

❑ IProbe.TRACK.RECORD()

IProbe()

TRUE if IPROBE

Syntax:

IProbe()

Returns TRUE if the debugger is running on a TRACE32-IPROBE hardware.

Return Value Type: [Boolean](#).

IProbe.ADC.ENABLE()

TRUE if channel is enabled

[\[Go to figure\]](#)

Syntax:

IProbe.ADC.ENABLE(<channel>)

Returns TRUE if the specified analog channel of the IProbe is enabled.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Example 1:

```
; The prefix ip stands for the IProbe of the Analog Probe.

; Returns FALSE if the V0 check box on the POD IP window is cleared.
PRINT IProbe.ADC.ENABLE(ip.V0)

; Returns TRUE if the V1 check box on the POD IP window is selected.
PRINT IProbe.ADC.ENABLE(ip.V1)
```

Example 2: To programmatically clear or select a checkbox on the **POD IP** window, use the **POD.ADC** command in a PRACTICE script file (*.cmm).

```
; Opens the POD IP window.
POD IP

; The keyword ON is used to select the V0 check box.
POD.ADC IP V0.ON
; Returns TRUE because the V0 check box is selected.
PRINT IProbe.ADC.ENABLE(ip.V0) ; The prefix ip stands for the
                                ; IProbe of the Analog Probe.

; The keyword OFF is used to clear the V0 check box.
POD.ADC IP V0.OFF
; Returns FALSE because the V0 check box is cleared.
PRINT IProbe.ADC.ENABLE(ip.V0)
```

IProbe.ADC.SHUNT()

Shunt resistor value of channel

[\[Go to figure\]](#)

Syntax: **IProbe.ADC.SHUNT(<channel>)**

Returns the shunt-resistor value of the specified current measurement <channel> of the IProbe.

Parameter Type: [String](#).

Return Value Type: [Float](#).

Example:

```
; The prefix ip stands for the IProbe of the Analog Probe.

; Returns the shunt-resistor value of the current channel I0.
PRINT IProbe.ADC.SHUNT(ip.I0)
```

Syntax:

IProbe.ANALOG()

When the PowerTrace II / PowerTrace III is powered up, this function returns if the connector of an Analog Probe is plugged.

Return Value Type: [Boolean](#).

Return Value and Description:

TRUE	The connector of an Analog Probe is plugged in at the socket labeled LOGIC ANALYZER PROBE.
FALSE	The connector of the Analog Probe is <i>not</i> plugged in at the socket labeled LOGIC ANALYZER PROBE.

Syntax:

IProbe.FIRST()

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

Syntax:

IProbe.GET(<channel_name>)

Returns the current value of the channel. This function is primarily intended for the digital channels of the Standard Probe.

Parameter Type: [String](#).

Return Value Type: [Hex value](#). If there is no current value, the function returns 0FFFFFFFFFFFFFFFFF.

Example:

```
PRINT IProbe.GET(ip.V1)      ; Returns a hexadecimal value.

PRINT IProbe.GET(ip.V1)+0.  ; Convert hex value to a decimal value.
```


Syntax:

IProbe.MAXSIZE()

Returns the maximum size of the IProbe trace buffer in records. To return a user-defined trace buffer size, use the function **IProbe.SIZE()**.

Return Value Type: [Decimal value](#).

Example: The command **IProbe.SIZE** is used to reduce the trace buffer size, e.g. to 600000 records, to speed up analysis. Using **IProbe.MAXSIZE()**, you can easily restore the maximum trace buffer size.

```
; Reduce the trace buffer size to the specified number of records.
IProbe.SIZE 600000.

; Restore the maximum trace buffer size.
IProbe.SIZE IProbe.MAXSIZE()
```

IProbe.PROBE()

[\[Go to figure\]](#)

Syntax:

IProbe.PROBE()

When the PowerTrace II / PowerTrace III is powered up, this function returns if a connector is plugged.

Return Value Type: [Boolean](#).

Return Value and Description:

TRUE	A connector is plugged in at the socket labeled LOGIC ANALYZER PROBE.
FALSE	No connector plugged in at the socket labeled LOGIC ANALYZER PROBE.

To check if the connector belongs to an Analog Probe, use the function **IProbe.ANALOG()**.

Syntax:

IProbe.RECORD.DATA(<record_number>,<channel>)

Returns the sampled data from the specified record.

Parameter and Description:

<record_number>	Parameter Type: Decimal value .
<channel>	Parameter Type: String .

Return Value Type: [Hex value](#).

Syntax:

IProbe.RECORD.TIME(<record_number>)

Returns the timestamp from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

Example: For an example, see [Analyzer.RECORD.TIME\(\)](#).

Syntax: **IProbe.RECORDS()**

Returns the number of records in the IProbe trace buffer.

Return Value Type: [Decimal value](#).

Examples:

```
; Print the number of records to the message bar below the command line.  
PRINT IProbe.RECORDS()
```

```
; Opens an IProbe.List window.  
IProbe.List /Track  
  
; Go to the first record of the analog trace data.  
IProbe.GOTO -IProbe.Records() ; Please note the minus sign.  
  
; Go to the last record of the analog trace data.  
IProbe.GOTO IProbe.RECORDS() ; No minus sign in this case.
```

Syntax: **IProbe.REF()**

Returns the record number of the reference record.

Return Value Type: [Decimal value](#).

Example 1: The **IProbe.REF()** function is used as an argument in the **IProbe.GOTO** command to jump back to the reference record.

```
IProbe.GOTO IProbe.REF() ; Jump back to the reference record.
```

Example 2: The **IProbe.View** window is opened to display more information about the reference record.

```
LOCAL &refNo  
  
; Get the number of the reference record.  
&refNo=IProbe.Ref()  
  
; Open the window with the reference record number displayed.  
IProbe.View &refNo
```

[\[Go to figure\]](#)

Syntax: **IProbe.SIZE()**

Returns the *user-defined* logical size of the TRACE32-IPROBE trace buffer in records. To return the maximum size, use the function **IProbe.MAXSIZE()**. For more information about the IProbe trace buffer size, refer to the command **IProbe.SIZE**.

Return Value Type: [Decimal value](#).

Syntax:

IProbe.STATE()

Returns the state of the IProbe.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

Syntax:

IProbe.TRACK.RECORD()

After a successful search operation, this function returns the record number. The record number returned is the number of the *first record* that matches the search criterion.

Return Value Type: [Decimal value](#).

Example:

```
; Prerequisite: Analog trace data was recorded using the IProbe.

; In the power channel p0, search for 0.17xxxx.
IProbe.Find , IProbe.p0 0.17

IF FOUND()
(
    ; Returns the first record matching the search criterion.
    AREA ; Print the record number to the AREA window.
    PRINT IProbe.TRACK.RECORD()

    ; Lists all matching records in a FindALL window.
    IProbe.FindALL , IProbe.p0 0.17 /Track
)
```

In This Section

See also

- JTAG
 - JTAG.X7EFUSE
 - ❑ JTAG.MIPI34()
 - ❑ JTAG.SEquence.EXIST()
 - ❑ JTAG.SEquence.RESULT()
 - ❑ JTAG.X7EFUSE.CNTL()
 - ❑ JTAG.X7EFUSE.KEY()
 - ❑ JTAG.X7EFUSE.USER()
 - ❑ JTAG.XUSEFUSE.DNA()
 - ❑ JTAG.XUSEFUSE.RESULT()
 - ❑ JTAG.XUSEFUSE.SEC()
 - ❑ JTAG.XUSEFUSE.USER128()
- JTAG.SEquence
 - JTAG.XUSEFUSE
 - ❑ JTAG.PIN()
 - ❑ JTAG.SEquence.LOCKED()
 - ❑ JTAG.SHIFT()
 - ❑ JTAG.X7EFUSE.DNA()
 - ❑ JTAG.X7EFUSE.RESULT()
 - ❑ JTAG.XUSEFUSE.CNTL()
 - ❑ JTAG.XUSEFUSE.KEY()
 - ❑ JTAG.XUSEFUSE.RSA()
 - ❑ JTAG.XUSEFUSE.USER()

JTAG.MIPI34()

Query special MIPI34 pins

[build 112622 - DVD 02/2020]

Syntax:

JTAG.MIPI34(<pin>)

Query special pins on MIPI34 connector. Only works in conjunction with the CombiProbe/μTrace (MicroTrace) MIPI34 whisker.

The parameter must be a valid <pin> argument of the command **JTAG.MIPI34**, e. g. **PIN12**.

Parameter Type: [String](#).

Return Value Type: [Decimal value](#).

Return Value and Description:

0	The pin was measured at a low state.
1	The pin was measured at a high state.
-1	The pin could not be read (incorrect parameter or not a MIPI-34 whisker).

Syntax: **JTAG.PIN(<signal_name>)**

Reads the level of a JTAG signal. See command **JTAG.PIN**.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

JTAG.SEquence.RESULT()

Get result of JTAG sequence

ARC, ARM, TeakLite, Xtensa

[build 97116 - DVD 09/2018]

Syntax: **JTAG.SEquence.RESULT(<global_seq_variable>)**

<global_seq_variable>: **0 | 1**

Any JTAG sequence can assign values to the global sequence variables **Result0** and **Result1**. The function **JTAG.SEquence.RESULT()** returns the value of these two global sequence variables.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Example:

```
SILENT.JTAG.SEquence.Execute PowerCheck
IF JTAG.SEquence.RESULT(0)==1
    ECHO "Power OK"
```

JTAG.SEquence.EXIST()

Check if a JTAG sequence exists

ARC, ARM, TeakLite, Xtensa

[build 93345 - DVD 09/2018]

Syntax: **JTAG.SEquence.EXIST(<seq_name>)**

Returns TRUE if the specified JTAG sequence name exists.

Parameter Type: [String](#). For a description of **<seq_name>**, see **JTAG.SEquence.ADD**.

Return Value Type: [Boolean](#).

Syntax: **JTAG.SEQUENCE.LOCKED(<seq_name>)**

Returns TRUE if the specified JTAG sequence exists but is locked. A sequence is locked if it is assigned to an event (e.g. with **SYSTEM.CONFIG.MULTITAP.JtagSEQUENCE**) or if the sequence is an internal one which was created by TRACE32 after using **SYSTEM.CPU**.

Parameter Type: [String](#). For a description of <seq_name>, see **JTAG.SEQUENCE.ADD**.

Return Value Type: [Boolean](#).

JTAG.SHIFT()

TDO output of JTAG shift

Syntax: **JTAG.SHIFT()**

Reads the TDO output of a JTAG shift. LSB first. Limited to 64 bit. See commands **JTAG.SHIFTREG** and **JTAG.SHIFTTDI**.

If you shift more than 64 bits with **JTAG.SHIFTREG** or **JTAG.SHIFTTDI** only *the first* 64-bits received by the debugger, are returned by **JTAG.SHIFT()**.

Return Value Type: [Hex value](#).

Syntax:

JTAG.X7EFUSE.RESULT()

Returns information about the success of a previous **JTAG.X7EFUSE** command.

Return Value Type: [Decimal value](#).

Return Value and Description:

0.	OK, no fuses were blown.
1.	OK, fuses were blown as requested.
2.	Error, but no fuses were blown.
3.	Error, at least one fuse was blown, but there was not yet any attempt to program sensitive data (KEY or USER).
4.	Error, programming or verifying KEY or USER failed. However, all requested CNTL flags (if any) were programmed successfully.
5.	Error while programming or verifying CNTL flags. The specified security settings may not be in effect. It could be possible to extract secret KEY or USER data that was previously programmed.

Example: See **JTAG.X7EFUSE** command.

Syntax: **JTAG.X7EFUSE.CNTL()**

Returns CNTL flags read by the previous **JTAG.X7EFUSE** command. See Xilinx application note XAPP 1239, *Using Encryption to Secure a 7 Series FPGA Bitstream*, for a description of the values.

Return Value Type: [Hex value](#).

Example:

```
JTAG.X7EFUSE /DEVICE XC7K325T

IF JTAG.X7EFUSE.RESULT() == 0 .
(
    IF (JTAG.X7EFUSE.CNTL() & 1.<<0.) != 0
        PRINT "CFG_AES_ONLY is set!"
    IF (JTAG.X7EFUSE.CNTL() & 1.<<1.) != 0
        PRINT "AES_EXCLUSIVE is set!"
    IF (JTAG.X7EFUSE.CNTL() & 1.<<2.) != 0
        PRINT "W_EN_B_KEY_USER is set!"
    IF (JTAG.X7EFUSE.CNTL() & 1.<<3.) != 0
        PRINT "R_EN_B_KEY is set!"
    IF (JTAG.X7EFUSE.CNTL() & 1.<<4.) != 0
        PRINT "R_EN_B_USER is set!"
    IF (JTAG.X7EFUSE.CNTL() & 1.<<5.) != 0
        PRINT "W_EN_B_CNTL is set!"
)
```

Syntax: **JTAG.X7EFUSE.DNA()**

Returns the unique DNA value stored in every Xilinx 7-series device, as read by the previous **JTAG.X7EFUSE** command.

Return Value Type: [Hex value](#).

Example: See **JTAG.X7EFUSE** command.

Syntax: **JTAG.X7EFUSE.KEY()**

Returns the KEY value as read by the previous **JTAG.X7EFUSE** command. If prohibited by the R_EN_B_KEY flag, return zeros instead. The returned value is encoded as a hexadecimal string with the same bit order as the one stored in the.nky file.

Return Value Type: [String](#).

Example: See **JTAG.X7EFUSE**.

Syntax: **JTAG.X7EFUSE.USER()**

Returns the USER value as read by the previous **JTAG.X7EFUSE** command. If prohibited by the R_EN_B_USER flag, return zeros instead.

Return Value Type: [Hex value](#).

Example: See **JTAG.X7EFUSE**.

Syntax:

JTAG.XUSEFUSE.RESULT()

Returns information about the success of a previous **JTAG.XUSEFUSE** command.

Return Value Type: [Decimal value](#).

Return Value and Description:

0	OK, the command was executed successfully.
1	Error, but no fuses were blown.
2	Error, fuses might be blown. Verify the current values by using the command JTAG.XUSEFUSE with the /READ option.
3	Error while verifying the AES key. The CRCs of the given key and stored key are not the same.

Example: See **JTAG.XUSEFUSE** command.

JTAG.XUSEFUSE.CNTL()

CNTL value read by JTAG.XUSEFUSE command

Syntax:

JTAG.XUSEFUSE.CNTL()

Returns the register value of the CNTL register read by a previous **JTAG.XUSEFUSE** command. See Xilinx user guide UG570, *UltraScale Architecture Configuration*, for a description of the value.

Return Value Type: [Hex value](#).

Example:

```
SYStem.JtagClock 1.0MHz

JTAG.XUSEFUSE /READ 0x0

IF ( (JTAG.XUSEFUSE.RESULT() !=1.) && (JTAG.XUSEFUSE.RESULT() !=2.) )
(
    IF (JTAG.XUSEFUSE.CNTL() &1.<<5.) !=0
        PRINT "W_DIS_CNTL is set!"
    IF (JTAG.XUSEFUSE.CNTL() &1.<<7.) !=0
        PRINT "W_DIS_KEY is set!"
)
```

Syntax: **JTAG.XUSEFUSE.DNA()**

Returns the unique DNA value stored in every Xilinx UltraScale series device, as read by the previous **JTAG.XUSEFUSE** command.

Return Value Type: [String](#).

Example:

```
SYStem.JtagClock 1.0MHz

JTAG.XUSEFUSE /READ 0x0

PRINT JTAG.XUSEFUSE.DNA()
```

Syntax: **JTAG.XUSEFUSE.KEY()**

Returns the KEY value as stated by the previous **JTAG.XUSEFUSE** command. If the key stored on the FPGA is not the same as the one provided by the user, the function **JTAG.XUSEFUSE.RESULT()** will return the value 3. The returned value is encoded as a hexadecimal string with the same bit order as the one stored in the *.nkz file.

Return Value Type: [String](#).

Example:

```
SYStem.JtagClock 1.0MHz

JTAG.XUSEFUSE /READ \
0x0123456789ABCDEF0123456789ABCDEF0123456789ABCDEF0123456789ABCDEF

IF JTAG.XUSEFUSE.RESULT()==0.
    PRINT "AES KEY matches the value: "
ELSE IF JTAG.XUSEFUSE.RESULT()==3.
    PRINT "AES KEY does not match the value: "
ELSE
    PRINT "Error while verifying the key: "

PRINT %CONTINUE JTAG.XUSEFUSE.KEY()
```

Syntax: **JTAG.XUSEFUSE.RSA()**

Returns the value of the RSA hash value as read by the previous **JTAG.XUSEFUSE** command. If prohibited by the flags in the CNTL register, the return value is 0xFFF..FF. The returned value is encoded as a hexadecimal string with the same bit order as the one stored in the *.nkz file.

Return Value Type: [String](#).

Example: See **JTAG.XUSEFUSE**

Syntax: **JTAG.XUSEFUSE.SEC()**

Returns the register value of the SEC register read by a previous **JTAG.XUSEFUSE** command. See Xilinx user guide UG570, *UltraScale Architecture Configuration*, for a description of the value.

Return Value Type: [Hex value](#).

Example:

```
SYSTem.JtagClock 1.0MHz

JTAG.XUSEFUSE /READ 0x0

IF ( (JTAG.XUSEFUSE.RESULT() != 1.) && (JTAG.XUSEFUSE.RESULT() != 2.) )
(
    IF (JTAG.XUSEFUSE.SEC() & 1.<<2.) != 0
        PRINT "RSA authentication is forced!"
    IF (JTAG.XUSEFUSE.CNTL() & 1.<<4.) != 0
        PRINT "Xilinx test access is disabled!"
)
```

Syntax: **JTAG.XUSEFUSE.USER()**

Returns the register value as read by a previous **JTAG.XUSEFUSE** command. If prohibited by the flags in the CNTL register, the return value is 0xFFFF...FF.

Return Value Type: [Hex value](#).

Example: See **JTAG.XUSEFUSE**

Syntax: **JTAG.XUSEFUSE.USER128()**

Returns the 128 bit USER value as read by a previous **JTAG.XUSEFUSE** command. If prohibited by the flags in the CNTL register, the return value is 0xFFFF...FF. The returned value is encoded as a hexadecimal string with the same bit order as the one stored in the *.nkz file.

Return Value Type: [String](#).

Example:


```
SYStem.JtagClock 1.0MHz

JTAG.XUSEFUSE /READ 0x0

IF ( (JTAG.XUSEFUSE.RESULT() != 1.) && (JTAG.XUSEFUSE.RESULT() != 2.) )
    PRINT JTAG.XUSEFUSE.USER128()
ELSE
    PRINT "Error while reading the eFUSE values!"
```

LOGGER Functions

This figure provides an overview of the return values of some of the LOGGER functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- ❑ [LOGGER.FIRST\(\)](#)
 - ❑ [LOGGER.RECORD.DATA\(\)](#)
 - ❑ [LOGGER.RECORD.TIME\(\)](#)
 - ❑ [LOGGER.REF\(\)](#)
 - ❑ [LOGGER.STATE\(\)](#)
- ❑ [LOGGER.RECORD.ADDRESS\(\)](#)
 - ❑ [LOGGER.RECORD.OFFSET\(\)](#)
 - ❑ [LOGGER.RECORDS\(\)](#)
 - ❑ [LOGGER.SIZE\(\)](#)

LOGGER.FIRST()

Get record number of first trace record

[build 71062 - DVD 09/2016]

Syntax:

LOGGER.FIRST()

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

LOGGER.RECORD.ADDRESS()

Get address recorded in trace record

[build 38764]

Syntax: **LOGGER.RECORD.ADDRESS**(<record_number>)

Returns the sampled address (access class and offset) from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

LOGGER.RECORD.DATA()

Get data recorded in trace record

[build 38764]

Syntax: **LOGGER.RECORD.DATA**(<record_number>)

Returns the sampled data of the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

LOGGER.RECORD.OFFSET()

Get address in trace record as number

[build 38764]

Syntax: **LOGGER.RECORD.OFFSET**(<record_number>)

Returns the address-offset of the sampled address from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Syntax: **LOGGER.RECORD.TIME(<record_number>)**

Returns the timestamp of the specified record. For an example, see [Analyzer.RECORD.TIME\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

LOGGER.RECORDS()

Get number of used trace records

[\[Go to figure\]](#)

Syntax: **LOGGER.RECORDS()**

Returns the number of records used for Logger trace.

Return Value Type: [Decimal value](#).

LOGGER.REF()

Get record number of reference record

Syntax: **LOGGER.REF()**

Returns the number of the selected reference record in the Logger trace.

Return Value Type: [Decimal value](#).

LOGGER.SIZE()

Get current trace buffer size in records

[build 38323 - DVD 08/2012] [\[Go to figure\]](#)

Syntax: **LOGGER.SIZE()**

Returns the size of the Logger trace buffer. The size is given by the logger buffer size of the target application.

Return Value Type: [Decimal value](#).

Syntax:

LOGGER.STATE()

Returns the state of the Logger trace.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

MACHO.LASTUUID()

Universally unique identifier of MachO file

Syntax:

MACHO.LASTUUID()

Returns the 128-bit universally unique identifier (UUID) of the file loaded with the last **Data.LOAD.MachO** command. With no MachO file was load yet or the last file did not contain an UUID the string “no UUID read” will be returned.

Return Value Type: [String](#).

In This Section

See also

- [MAP](#)
- [MAP.ROMSIZE\(\)](#)

MAP.ROMSIZE()	Size of the defined ROM
----------------------	-------------------------



Syntax:	MAP.ROMSIZE()
---------	----------------------

Returns the total size of the defined ROM.

Return Value Type: [Decimal value](#).

MCDS Functions

This figure provides an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- MCDS
- MCDS MODULE.NAME()
- MCDS MODULE.REVISON()
- MCDS.SIZE()
- MCDS.TraceBuffer.LowerGAP()
- MCDS.TraceBuffer.UpperGAP()
- MCDS.GAP()
- MCDS MODULE.NUMBER()
- MCDS MODULE.TYPE()
- MCDS.STATE()
- MCDS.TraceBuffer.SIZE()

Syntax:

MCDS.MODULE.NAME()

Returns the name of the MCDS module according to CPU selection.

Return Value Type: [String](#).

Return Value and Description:

<undefined>	Unknown or undefined MCDS module. Contact technical support.
<none>	Devices does not feature an MCDS module.
MCDS	Standard MCDS module.
MCDSlight	MCDSlight module
miniMCDS	miniMCDS module.

Syntax:

MCDS.MODULE.NUMBER()

Returns the number-part of the MCDS module ID of the attached chip.

Return Value Type: [Hex value](#).

Return Value and Description:

0xFFFF	MCDS ID register could not be read. Switch to SYStem.Mode Up if necessary.
0x0000	Devices does not feature an MCDS module.
other	MCDS_ID.NUMBER (16 bit)

Syntax:

MCDS.MODULE.REVision()

Returns the revision-part of the MCDS module ID of the attached chip.

Return Value Type: [Hex value](#).

Return Value and Description:

0xFF	MCDS ID register could not be read. Switch to SYStem.Mode Up if necessary.
0x00	Devices does not feature an MCDS module.
other	MCDS_ID.REVISION (8 bit)

MCDS.MODULE.TYPE()

Type-part of MCDS module ID

[build 70152 - DVD 09/2016]

Syntax:

MCDS.MODULE.TYPE()

Returns the type-part of the MCDS module ID of the attached chip.

Return Value Type: [Hex value](#).

Return Value and Description:

0xFF	MCDS ID register could not be read. Switch to SYStem.Mode Up if necessary.
0x00	Devices does not feature an MCDS module.
(other)	MCDS_ID.TYPE (8 bit)

MCDS.STATE()

MCDS module is switched on/off

[\[Go to figure\]](#)

Syntax:

MCDS.STATE()

Returns the state of the MCDS module.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF
1	ON

See also: Command group **MCDS**

Syntax: **MCDS.TraceBuffer.LowerGAP()**

Returns the size of the lower EMEM tiles of the currently selected memory array not used as trace buffer.

Return Value Type: [Decimal value](#).

Syntax:

MCDS.TraceBuffer.SIZE()

MCDS.SIZE() (deprecated)

Returns the size of the EMEM tiles of the currently selected memory array used as trace buffer.

Return Value Type: [Decimal value](#).

Syntax:

MCDS.TraceBuffer.UpperGAP()

MCDS.GAP() (deprecated)

Returns the size of the upper EMEM tiles of the currently selected memory array not used as trace buffer.

Return Value Type: [Decimal value](#).

MMU Functions (Memory Management Unit)

This figure provides an overview of the return values of some of the functions. For descriptions of the illustrated functions and the functions not shown here, see below.

Zone	MMU format	Default page table
H:0::	STD	H:0:::0x10000
M:0::	STD	M:0:::0xE0000
N:1::	QNX	N:1:::0x20000
I:1::	STD	I:1:::0x80000
N:2::	QNX	N:2:::0x40000
I:2::	STD	I:2:::0xC0000

MMU.FORMAT.ZONE()

MMU.DEFAULTPT.ZONE()

logical	physical	type
M:0:::F0000000--FFFFFFF	AM:78000000--87FFFFFFF	DEFAULT
NSD:1:::80000000--BFFFFFFF	I:1:::23000000--32FFFFFFF	DEFAULT
I:1:::23000000--32FFFFFFF	AH:10000000--1FFFFFFF	DEFAULT
NSD:2:::C0000000--CFFFFFFF	I:2:::35000000--44FFFFFFF	DEFAULT
I:2:::35000000--44FFFFFFF	AH:18000000--27FFFFFFF	DEFAULT
M:0:::50000000--7FFFFFFF	AM:10000000--3FFFFFFF	COMMON COMMON
N:1:::C0000000--FFFFFFF		
N:2:::C0000000--FFFFFFF		

MMU.DEFAULTTRANS.LOGRANGE.ZONE()

MMU.DEFAULTTRANS.PHYSADDR.ZONE()

In This Section

See also

- MMU
- MMU.DEFAULTPT()
- MMU.DEFAULTTRANS.LOGRANGE()
- MMU.FORMAT()
- MMU.FORMAT.ZONE()
- MMU.INTERMEDIATE.VALID()
- MMU.INTERMEDIATEEX.VALID()
- MMU.LINEAR.VALID()
- MMU.LINEAREX.VALID()
- MMU.LOGICAL.VALID()
- MMU.PHYSICAL.VALID()
- MMU.PHYSICALEX.VALID()
- MMU()
- MMU.DEFAULTPT.ZONE()
- MMU.DEFAULTTRANS.PHYSADDR()
- MMU.FORMAT.DETECTED()
- MMU.INTERMEDIATE()
- MMU.INTERMEDIATEEX()
- MMU.LINEAR()
- MMU.LINEAREX()
- MMU.LOGICAL()
- MMU.PHYSICAL()
- MMU.PHYSICALEX()

MMU()

Value of MMU register

Syntax: **MMU(<register_name>)**

Returns an MMU register value.

Parameter Type: [String](#).
Return Value Type: [Hex value](#).

MMU.DEFAULTPT()

Base address of default page table

[\[Go to figure\]](#)

Syntax 1:

MMU.DEFAULTPT()
[build 61046 - DVD 02/2015]

Syntax 2:

MMU.DEFAULTPT.ZONE(<address>)
[build 106522 - DVD 09/2019]

<address>:

<access_class>:[<machine_id>:::]0x0

Both MMU functions return the base address of the default page table that has been set with the [MMU.FORMAT](#) command.

Syntax 1: The returned base address is located in the currently active zone of the core.

Syntax 2: The returned base address is located in the [zone](#) that is selected with <address>.

Return Value Type: [Address](#). If the CPU has no MMU, a zero address is returned.


Parameter and Description:

<access_class>	Mandatory if SYStem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Mandatory if SYStem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

Example - Syntax 2:

```
;optional step: list the base addresses of the default page tables
;per zone
TRANSLation.state                                ;see column 'Default page table'

;let's return the base address of the default page table of
;machine '0:::' in the secure zone 'Z'
PRINT MMU.DEFAULTPT.ZONE(Z:0:::0x0)              ;result 'Z:0:::0x0:0x1000000'
                                                    ;see [A] below
```



Syntax 1:	MMU.DEFAULTTTRANS.<range>()
Syntax 2:	MMU.DEFAULTTTRANS.<range>.ZONE(<address>)
<range>:	LOGRANGE PHYSADDR
<address>:	<access_class>:[<machine_id>:::]0x0
Full function name only required for HELP.Index:	MMU.DEFAULTTTRANS.LOGRANGE() MMU.DEFAULTTTRANS.PHYSADDR() [build 95143 - DVD 09/2018] MMU.DEFAULTTTRANS.LOGRANGE.ZONE(<address>) MMU.DEFAULTTTRANS.PHYSADDR.ZONE(<address>) [build 106522 - DVD 09/2019]

Both MMU functions return settings that have been made with the **MMU.FORMAT** command.

Syntax 1: The returned settings are located in the currently active zone of the core.

Syntax 2: The returned settings are located in the **zone** that is selected with <address>.

Return Value and Description:

<range>	Description
LOGRANGE	Return Value Type: Address range. Use this keyword to get the logical address range of the default translation.
PHYSADDR	Return Value Type: Address. Use this keyword to get the physical base address of the default translation.

Parameter and Description:

<access_class>	Parameter Type: Address. Mandatory if SYStem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Parameter Type: Address. Mandatory if SYStem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

Examples - Syntax 1

Example 1: The function returns the logical address range of the default translation that is currently active on the core.

```
MMU.FORMAT STD      0x88000000      0x80000000--0x9FFFFFFF      0x10000000

PRINT MMU.DEFAULTTRANS.LOGRANGE()
                                ;returns C:0x80000000--0x9FFFFFFF
```

Example 2: The function returns the physical base address of the default translation that is currently active on the core.


```
MMU.FORMAT STD      0x88000000      0x80000000--0x9FFFFFFF      0x10000000
PRINT MMU.DEFAULTTRANS.PHYSADDR()
                                ;returns A:0x10000000
```

Example - Syntax 2

Example 3: Based on the zones **N:0x2::** and **H:0x0::** passed as arguments, the function **MMU.DEFAULTTRANS.LOGRANGE.ZONE()** returns the logical address ranges of these zones.

```
MMU.FORMAT STD      H:0x0:::0x10000      H:0x0:::0xA0000000--0xAFFFFFFF \
                                A:0x20000000 /MACHINE 0
PRINT MMU.DEFAULTTRANS.LOGRANGE.ZONE(H:0x0:::0x0)
                                ;returns H:0:::0xA0000000--0xAFFFFFFF

MMU.FORMAT QNX      N:0x2:::0x40000      N:0x2:::0xC0000000--0xCFFFFFFF \
                                I:0x30000000 /MACHINE 2
PRINT MMU.DEFAULTTRANS.LOGRANGE.ZONE(N:0x2:::0x0)
                                ;returns NSD:2:::0xC0000000--0xCFFFFFFF
```




- A Logical address range.
- C Physical address range.
- B Zone of the logical address range.

Syntax 1:	MMU.FORMAT() [build 53385 - DVD 08/2014]
Syntax 2:	MMU.FORMAT.ZONE(<address>) [build 106522 - DVD 09/2019]
<address>:	<access_class>:[<machine_id>:::]0x0

Both MMU functions return the MMU format of the default page table that has been set with the **MMU.FORMAT** command.

Syntax 1: The returned MMU format is the format of the currently active zone of the core.

Syntax 2: The returned MMU format is the format of the **zone** that is selected with <address>.



MMU.FORMAT()
MMU.FORMAT.ZONE()

Parameter and Description:

<access_class>	Parameter Type: Address. Mandatory if SYStem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Parameter Type: Address. Mandatory if SYStem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

Return Value Type: [String](#). If the CPU has no MMU, an empty string is returned.

Example - Syntax 2:

```
PRINT MMU.FORMAT.ZONE(N:2:::0x0) ;returns QNX
```

Syntax: **MMU.FORMAT.DETECTED()**

Auto-detects the page table format used by the kernel in the currently active zone of the core. Then the function returns the name of the page table format. The auto-detection works only if **MMU.FORMAT** is set to **STD**.

Return Value Type: [String](#).

Return Value and Description: For a list of format names, see:

- “[<format> Options for x86](#)” (general_ref_m.pdf)
- “[<format> Options for RISC-V](#)” (general_ref_m.pdf)

Example:

```
MMU.FORMAT STD
PRINT MMU.FORMAT.DETECTED() ;returns the name of the standard format
                             ;derived from the CPU state, e.g.
                             ;the format name P32
```



Syntax:

MMU.FORMAT.DETECTED.ZONE(<address>)

<address>:

<access_class>[:<machine_id>:::]0x0

Auto-detects the page table format used by the kernel and returns its name. The returned page table format refers to the **zone** that is selected with <address>. The auto-detection works only if **MMU.FORMAT** is set to **STD**.



MMU.FORMAT.DETECTED.ZONE()

Parameter Type: **Address**.

Parameter and Description:

<access_class>	Mandatory if SYSTem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Mandatory if SYSTem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

Return Value Type: **String**.

Return Value and Description: For a list of format names, see:

- “<format> Options for x86” (general_ref_m.pdf)
- “<format> Options for RISC-V” (general_ref_m.pdf)

Example:

```
SYSTem.Option.MACHINESPACES ON
MMU.FORMAT STD /MACHINE 2
PRINT MMU.FORMAT.DETECTED.ZONE (I:3:::0)
                                ;returns the name of the standard
                                ;page table format used in zone "I:3:::0"
                                ;and derived from the CPU state, e.g.
                                ;the format name "EPT4L"
```

MMX Function (MultiMedia eXtension)

MMX()	Value of MMX register
-------	-----------------------

Syntax: **MMX**(<register_name>)

Returns the content of the selected MMX register. See also **MMX** command group.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

MONITOR Function

MONITOR()	TRUE if debugger is running as monitor
-----------	--


Syntax: **MONITOR**()

Returns TRUE if the debugger is running as monitor.

Return Value Type: [Boolean](#).

NEXUS Functions

This figure provides an overview of the return values of some of the NEXUS functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- [NEXUS\(\)](#)
- [NEXUS.PortMode\(\)](#)
- [NEXUS.PortSize\(\)](#)
- [NEXUS.RTTBUILD\(\)](#)

NEXUS()

TRUE if Nexus trace is supported

Syntax:

NEXUS()

Returns TRUE if the selected CPU supports a Nexus trace.

Return Value Type: Boolean.

NEXUS.RTTBUILD()

RTT build register

ARC

[build 93248 - DVD 02/2018]

Syntax:

NEXUS.RTTBUILD(<register_index>)

<register_index>:

0

Returns the RTT build register.

Parameter Type: Decimal value.

Return Value Type: [Hex value](#). Returns 0 if the command **NEXUS.RTTBUILD** was *not* used or if there is *no* RTT trace source.

NEXUS.PortMode()

Current PortMode setting

[\[Go to figure\]](#)

Syntax: NEXUS.PortMode()

Returns the current Nexus **PortMode** setting.

Return Value Type: [String](#).

NEXUS.PortSize()

Current PortSize setting

[build 39453 - DVD 08/2012] [\[Go to figure\]](#)

Syntax: NEXUS.PortSize()

Returns the current Nexus **PortSize** setting.

Return Value Type: [String](#).

In This Section

See also

- ❑ [Onchip\(\)](#)
 - ❑ [Onchip.FLOW.ERRORS\(\)](#)
 - ❑ [Onchip.MAXSIZE\(\)](#)
 - ❑ [Onchip.RECORD.DATA\(\)](#)
 - ❑ [Onchip.RECORD.TIME\(\)](#)
 - ❑ [Onchip.REF\(\)](#)
 - ❑ [Onchip.STATE\(\)](#)
 - ❑ [Onchip.TRACK.RECORD\(\)](#)
- ❑ [Onchip.FIRST\(\)](#)
 - ❑ [Onchip.FLOW.FIFOFULL\(\)](#)
 - ❑ [Onchip.RECORD.ADDRESS\(\)](#)
 - ❑ [Onchip.RECORD.OFFSET\(\)](#)
 - ❑ [Onchip.RECORDS\(\)](#)
 - ❑ [Onchip.SIZE\(\)](#)
 - ❑ [Onchip.TraceCONNECT\(\)](#)

Onchip()

TRUE if the onchip trace is available

Syntax:

Onchip()

Returns TRUE if an onchip trace is available.

Return Value Type: [Boolean](#).

Onchip.FIRST()

Get record number of first trace record

[build 71062 - DVD 09/2016]

Syntax:

Onchip.FIRST()

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

Onchip.FLOW.ERRORS()

Get number of flow errors / hard errors

Syntax:

Onchip.FLOW.ERRORS()

Returns the number of flow errors / harderrors in the trace recording.

Return Value Type: [Decimal value](#).

Please be aware that the return value of this function is the accumulated count of events that were encountered while processing the trace recording. All opened windows showing trace data contribute to this value. The value is reset when a new trace recording is made, or when the **Trace.FLOWSTART** or **Trace.FLOWPROCESS** command is executed.

The use of this function is only recommended if you want to find out if a specified part of a trace recording is error free. The part to be analyzed can be defined using **Trace.STATistic.FIRST** and **Trace.STATistic.LAST**. If the defined part is error free (and thus this function returns zero), the analysis results are reliable as well.

Example 1: This script shows how to return only the number of flow errors and hard errors in the trace that is currently visible within the **Onchip.List** window. If you now scroll up or down in the **Onchip.List** window or increase the window size, more trace data will be decoded, and thus the number of errors returned by the function may increase.

```
Onchip.List

PRINT Onchip.FLOW.ERRORS()

; scroll up or down in the window

PRINT Onchip.FLOW.ERRORS()
```

Example 2: This script shows how to obtain the exact number of flow errors in the whole trace recording.

```
Trace.Find FLOWERROR /ALL
PRINT FOUND.COUNT()
```

Onchip.FLOW.FIFOFULL()

Get number of FIFO overflows

Syntax: **Onchip.FLOW.FIFOFULL()**

Returns the number of target FIFO overflows in the trace recording.

Return Value Type: [Decimal value](#).

Please be aware that the return value of this function is the accumulated count of events that were encountered while processing the trace recording. All opened windows showing trace data contribute to this value. The value is reset when a new trace recording is made, or when the **Trace.FLOWSTART** or **Trace.FLOWPROCESS** command is executed.

The use of this function is only recommended if you want to find out if a specified part of a trace recording is error free. The part to be analyzed can be defined using **Trace.STATistic.FIRST** and **Trace.STATistic.LAST**. If the defined part is error free (and thus this function returns zero), the analysis results are reliable as well.

Onchip.MAXSIZE()

Get max. size of trace buffer in records

[build 38323 - DVD 08/2012]

Syntax: **Onchip.MAXSIZE()**

Returns the maximum possible size of the Onchip trace buffer in records.

Return Value Type: [Decimal value](#).

Onchip.RECORD.ADDRESS()

Get address recorded in trace record

[build 38764]

Syntax: **Onchip.RECORD.ADDRESS(<record_number>)**

Returns the sampled address (access class and offset) from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

Onchip.RECORD.DATA()

Get data recorded in trace record

[build 38764]

Syntax: **Onchip.RECORD.DATA(<record_number>)**

Returns the sampled data of the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Onchip.RECORD.OFFSET()

Get address in trace record as number

[build 38764]

Syntax: **Onchip.RECORD.OFFSET(<record_number>)**

Returns the address-offset of the sampled address from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Syntax:

Onchip.RECORD.TIME(<record_number>)

Returns the timestamp of the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

Example: For an example, see [Analyzer.RECORD.TIME\(\)](#).

Onchip.RECORDS()

Get number of used trace records

Syntax:

Onchip.RECORDS()

The number of records currently stored in the on-chip trace buffer.

Return Value Type: [Decimal value](#).

Onchip.REF()

Get record number of reference record

Syntax:

Onchip.REF()

Returns the number of the selected reference record in the Onchip trace.

Return Value Type: [Decimal value](#).

Onchip.SIZE()

Get current trace buffer size in records

Syntax:

Onchip.SIZE()

Size of on-chip memory to be used as on-chip trace buffer in trace records.

Return Value Type: [Decimal value](#).

Syntax:

Onchip.STATE()

Returns the state of the on-chip trace.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

Syntax:

Onchip.TraceCONNECT()

Returns the name of the currently selected trace sink of the SoC. In case no trace-sink is selected/available, the function returns **NONE**. The trace sink is selected with the [<trace>.TraceCONNECT](#) command.

Return Value Type: [String](#).

Example: ARM Coresight system with two ETFs

```
SYStem.CONFIG ETF1 Base DAP:<address>
SYStem.CONFIG ETR2 Base DAP:<address>
Onchip.TraceCONNECT ETF1
PRINT Onchip.TraceCONNECT() ; returns "ETF1"
Onchip.TraceCONNECT ETF2
PRINT Onchip.TraceCONNECT() ; returns "ETF2"
```

Syntax: **Onchip.TRACK.RECORD()**

After a successful search operation, this function returns the record number.

Return Value Type: [Decimal value](#).

Example: For an example, see [Analyzer.TRACK.RECORD\(\)](#).

PBI()	Name of used debug back-end
-------	-----------------------------

[build 25366 - DVD 02/2011]

Syntax:	PBI()
---------	-------

Returns the name of the used debug back-end. For further information, refer to “[Section PBI](#)” in TRACE32 Installation Guide, page 42 (installation.pdf).

Return Value Type: [String](#).

In This Section

See also

- PCI
- PCI.Read.B()
- PCI.Read.L()
- PCI.Read.W()

PCI.Read.B()

Byte from PCI register

Syntax:

PCI.Read.B(<bus>,<device>,<function>,<register>)

Reads a byte from selected PCI register. For a description of the parameters, click [here](#).

Return Value Type: [Hex value](#).

PCI.Read.L()

Long from PCI register

Syntax:

PCI.Read.L(<bus>,<device>,<function>,<register>)

Reads a long from selected PCI register. For a description of the parameters, click [here](#).

Return Value Type: [Hex value](#).

PCI.Read.W()

Word from PCI register

Syntax:

PCI.Read.W(<bus>,<device>,<function>,<register>)

Reads a word from selected PCI register. For a description of the parameters, click [here](#).

Parameter and Description:

<bus>	Parameter Type: Decimal or hex or binary value . PCI bus number.
<device>	Parameter Type: Decimal or hex or binary value . PCI device number.
<function>	Parameter Type: Decimal or hex or binary value . PCI function number.
<register>	Parameter Type: Decimal or hex or binary value . PCI register number.

Return Value Type: [Hex value](#).

In This Section

See also

- PER
- ❑ PER.Buffer.Byte()

❑ PER.Buffer.Short()

❑ PER.HByte()

❑ PER.LongLong()

❑ PER.Quad()

❑ PER.SByte()

❑ PER.SLong()

❑ PER.Word()
- ❑ PER.ADDRESS()

❑ PER.Buffer.Long()

❑ PER.Buffer.Word()

❑ PER.Long()

❑ PER.LongLong.BigEndian()

❑ PER.Quad.BigEndian()

❑ PER.Short()

❑ PER.TByte()

❑ PER.Word.BigEndian()
- ❑ PER.ARG()

❑ PER.Buffer.LongLong()

❑ PER.Byte()

❑ PER.Long.BigEndian()

❑ PER.LongLong.LittleEndian()

❑ PER.Quad.LittleEndian()

❑ PER.Short.BigEndian()

❑ PER.VALUE()

❑ PER.Word.LittleEndian()
- ❑ PER.BASE()

❑ PER.Buffer.Quad()

❑ PER.EVAL()

❑ PER.Long.LittleEndian()

❑ PER.PByte()

❑ PER.SAVEINDEX()

❑ PER.Short.LittleEndian()

❑ PER.VALUE.STRING()

PER.<width>()

Memory contents in default endianness

[build 76251 - DVD 09/2016]

Syntax:	PER.<width>(<address>)
<width>:	Byte Short Word TByte Long PByte HByte SByte SLong Quad LongLong
Full function name only required for HELP.Index:	PER.Byte(<address>) PER.Short(<address>) PER.Word(<address>) PER.TByte(<address>) PER.Long(<address>) PER.PByte(<address>) PER.HByte(<address>) PER.SByte(<address>) PER.SLong(<address>) PER.Quad(<address>) PER.LongLong(<address>)

The **PER.<width>()** functions return memory contents in the default endianness of the architecture.

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

The **PER.<width>()** functions are used in PER files and are synonyms for the **Data.<width>()** functions. However, the difference between the two function groups is that the return values of the **PER.<width>()** functions are based on dualport accesses, provided the respective PER file is opened with the **DualPort** option e.g.:

```
PER.view <file>.per /DualPort
```

<width>	Description of PER.<width>()
Byte	Returns a single byte from memory.
Short	Returns a word (16-bit) from memory.
Word	Returns a word (16-bit) from memory.
TByte	Returns a 3-byte value from memory.
Long	Returns a long value (32-bit) from memory.
PByte	Returns a 5-byte value from memory.
HByte	Returns a 6-byte value from memory.
SByte	Returns a 7-byte value from memory.
SLong	Reads signed long value from memory - sign extended internally to a 64-bit value.
Quad	Returns a 64-bit value from memory.
LongLong	Returns a 64-bit value from memory.

PER.<width>.<endianness>()

Memory contents in specified endianness

[build 76251 - DVD 09/2016]

Syntax:	PER.<width>.<endianness>(<address>)
<width>:	Byte Short Word TByte Long PByte HByte SByte SLong Quad LongLong
<endianness>:	LittleEndian BigEndian
Full function name only required for HELP.Index:	PER.Short.BigEndian(<address>) PER.Short.LittleEndian(<address>) PER.Word.BigEndian(<address>) PER.Word.LittleEndian(<address>) PER.Long.BigEndian(<address>) PER.Long.LittleEndian(<address>) PER.LongLong.BigEndian(<address>) PER.LongLong.LittleEndian(<address>) PER.Quad.BigEndian(<address>) PER.Quad.LittleEndian(<address>)

The **PER.<width>.<endianness>()** functions return memory contents in the specified endianness.

Parameter Type: [Address](#).

Return Value Type: [Hex value](#).

The **PER.<width>.<endianness>()** functions are used in PER files and are synonyms for the **Data.<width>.<endianness>()** functions. However, the difference between the two function groups is that the return values of the **PER.<width>.<endianness>()** functions are based on dualport accesses, provided the respective PER file is opened with the **DualPort** option e.g.:

```
PER.view <file>.per /DualPort
```

<width>.<endianness>	Description of PER.<width>.<endianness>()
Short.BigEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to big endian.
Short.LittleEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to little endian.
Word.BigEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to big endian.
Word.LittleEndian	Returns a word (16-bit) from memory, while the byte order of the word is forced to little endian.
Long.BigEndian	Returns a long value (32-bit) from memory, while the byte order of the word is forced to big endian.
Long.LittleEndian	Returns a long value (32-bit) from memory, while the byte order of the word is forced to endian endian.
LongLong.BigEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to big endian.
LongLong.LittleEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to little endian.
Quad.BigEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to big endian.
Quad.LittleEndian	Returns a 64-bit value from memory, while the byte order of the word is forced to little endian.

PER.ADDRESS()

Address of register(field)

[build 147535 - DVD 09/2022]

Syntax:

PER.ADDRESS("<path>")

Returns the address of the register stated as <path>. Refer to **PER.Set.ByName** for a description of <path>. **PER.Set.CONDITIONs** may be used to read addresses from within **IF** conditions.

Parameter Type: **String**.

Return Value Type: **Address**.

Syntax:PER.ADDRESS.<sub_cmd>(<address>)

<width>:isNONSECURE | isNONSECUREEX | isSECURE | isSECUREEX

Full function name only required for HELP.Index:PER.ADDRESS.isNONSECURE(<address>)
PER.ADDRESS.isNONSECUREEX(<address>)
PER.ADDRESS.isSECURE(<address>)
PER.ADDRESS.isSECUREEX(<address>)

The **PER.ADDRESS.<sub_cmd>()** functions are used in PER files and are synonyms respectively for the **ADDRESS.isNONSECURE()**, **ADDRESS.isNONSECUREEX()**, **ADDRESS.isSECURE()**, and **ADDRESS.isSECUREEX()** functions. However, the difference between the two function groups is that the return values of the **PER.ADDRESS.<sub_cmd>()** functions are based on the access class provided as parameter and can be overridden using the options Secure or NonSecure, e.g.:

```
PER.view <file>.per /Secure
PER.view <file>.per /NonSecure
```

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

<sub_cmd>	Description of PER.ADDRESS.<sub_cmd>()
isNONSECURE	Checks if the address, inside a peripheral definition file (PER file), passed as parameter will force a non-secure (TrustZone) access.
isNONSECUREEX	Checks if the address, inside a peripheral definition file (PER file), passed as parameter combined with the current CPU status will cause a non-secure (TrustZone) access.
isSECURE	Checks if the address, inside a peripheral definition file (PER file), passed as a parameter will force a Secure (TrustZone) access.
isSECUREEX	Checks if the address, inside a peripheral definition file (PER file), passed as a parameter combined with the current CPU status will cause an Secure (TrustZone) access.

PER.ARG()

Argument of PER.view command

Syntax:PER.ARG()

Returns the (optional) argument of the **PER.view** command. Only useful inside peripheral definition files.

Return Value Type: [Hex value](#).

Syntax:

PER.ARG.ADDRESS()

Returns the (optional) address argument of the **PER.view** command. Only useful inside peripheral definition files.

Return Value Type: [Address](#).

Syntax:

PER.BASE()

Returns the address last passed to the **BASE** command. Only to be used within peripheral files.

Return Value Type: [Address](#).

Syntax:PER.Buffer.<width>(<index>)

<width>:Byte | Short | Word | Long | LongLong | Quad

(Full function name only required for HELP.Index):PER.Buffer.Byte(<index>)
PER.Buffer.Short(<index>)
PER.Buffer.Word(<index>)
PER.Buffer.Long(<index>)
PER.Buffer.LongLong(<index>)
PER.Buffer.Quad(<index>)

<width>	Description of PER.Buffer.<width>()
Byte	Returns a byte from the SGROUP buffer. Only useful within a SGROUP of a PER-file.
Short Word	Returns a 16-bit word from the SGROUP buffer. Only useful within a SGROUP of a PER-file.
Long	Returns a 32-bit word from the SGROUP buffer. Only useful within a SGROUP of a PER-file.
LongLong Quad	Returns a 64-bit from the SGROUP buffer. Only useful within a SGROUP of a PER-file.

Parameter and Description:

<index>	Parameter Type: Decimal or hex or binary value .
---------	--

Return Value Type: [Hex value](#).

Syntax:

PER.EVAL(<integer>)

Returns the value of a expression (defined with **BASE**) inside a peripheral definition file (PER file), which was defined after a **BASE**, **IF**, **ELIF** or **ELSE** command.

Parameter Type: **Decimal** or **hex** or **binary value**.

The parameter defines which expression is returned (0=first one).

NOTE 1:

The function returns only the last evaluated value of the expression. It will not evaluated the expression again.

Expressions after **BASE**, will be evaluated by a **GROUP** command after the **BASE** command in a PER file.

NOTE 2:

The function must only be used in the context of **IF** or **ELIF**.

Return Value Type: **Address**.

PER.FILENAME()

PER file name

Syntax:

PER.FILENAME()

Returns the file name of the active peripheral definition file (PER file).

Return Value Type: **String**.

Syntax:

PER.SAVEINDEX(<address>,<width>,<index_address>,<index_width>, | <index_value>)

Function returns memory contents at Address (<address>) while a value (<index_value>) is temporarily set in an index register (<index_address>). The access width can be set individually.

Sequence:

- Backup memory contents of memory location <index_address>
- Set value <index_value> to <index_addr>
- Read memory contents at memory location <address> using <width>
- Restore memory contents of memory location <index_address>

Parameter and Description:

<address>	Address to read. Parameter Type: Address.
<width>	Access width of <address>. Parameter Type: Decimal or hex or binary value.
<index_address>	Address of index register. Parameter Type: Address.
<index_width>	Access width of <index_address>. Parameter Type: Decimal or hex or binary value.
<index_value>	Index value. Parameter Type: Decimal or hex or binary value.

Return Value Type: Hex value.

See also: [per_prog.pdf - SAVEINDEX](#).

Syntax:

PER.VALUE("<path>")

Returns the value of the register or register field stated as <path>. Refer to [PER.Set.ByName](#) for a description of <path>. [PER.Set.CONDITIONs](#) may be used to read values from within [IF](#) conditions.

Parameter Type: String.

Return Value Type: Hex value.

Syntax: **PER.VALUE.STRING("<path>")**


Returns the <choice> value of a **BITFLD**. Refer to **PER.Set.ByName** for a description of <path>. **PER.Set.CONDItions** may be used to read choices from within **IF** conditions.

Parameter Type: [String](#).

Return Value Type: [String](#).

PERF Functions (Performance)

This figure provides an overview of the return values of some of the PERF functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- PERF
- PERF.MEMORY.SnoopAddress()
- PERF.METHOD()
- PERF.PC.HITS()
- PERF.RunTime()
- PERF.STATE()
- PERF.MEMORY.HITS()
- PERF.MEMORY.SnoopSize()
- PERF.MODE()
- PERF.RATE()
- PERF.SNOOPFAILS()
- PERF.TASK.HITS()

PERF.MEMORY.HITS()

Number of memory samples

Syntax:

PERF.MEMORY.HITS(<value>,<core>)

Number of hits for the given memory value and core number.

Parameter and Description:

<value>	Parameter Type: Decimal or hex or binary value.
<core>	Parameter Type: Decimal value. If <core> is -1, the number of hits is returned for all cores.

Return Value Type: Decimal value.

Syntax:

PERF.MEMORY.SnoopAddress()

Returns the snoop memory address.

Return Value Type: [Address](#).

Syntax:

PERF.MEMORY.SnoopSize()

Returns the snoop size in bytes (1, 2, 4, or 8).

Return Value Type: [Hex value](#).

Syntax:

PERF.METHOD()

Returns the recording method of the Performance Analyzer.

Return Value Type: [Hex value](#).

Return Value and Description:

0	HARDWARE method
1	BusSnoop method
2	StopAndGo method
3	Trace method
4	Snoop method
5	DCC method

Syntax:

PERF.MODE()

Returns the current recording mode of the Performance Analyzer.

Return Value Type: [Hex value](#).

Return Value and Description:

1	PC mode
2	FLAGs mode
8	TASK mode
9	PCTASK mode
10	MEMory mode
11	PCMEMory mode
40	LeVel mode

PERF.PC.HITS()

Number of PC samples

Syntax:

PERF.PC.HITS(<address_range>,<core>)

Number of program counter hits for the given address range and core number.

Parameter and Description:

<address_range>	Parameter Type: Address range .
<core>	Parameter Type: Decimal value . If <core> is -1, the number of hits is returned for all cores.

Return Value Type: [Decimal value](#).

PERF.RATE()

Number of snoops per second

Syntax:

PERF.RATE()

Returns the number of snoops per second.

Return Value Type: [Decimal value](#).

Syntax:

PERF.RunTime()

Percentage of time retained for the actual program run when the **StopAndGo** method is used.

Return Value Type: [String](#).

Syntax:

PERF.SNOOPFAILS()

Returns the number of snoop fails.

Return Value Type: [Decimal value](#).

[\[Go to figure\]](#)

Syntax:

PERF.STATE()

Returns the state of the Performance Analyzer.

Return Value Type: [Hex value](#).

Return Value and Description:

0	DISable state
1	OFF state
2	Arm state

Syntax:

PERF.TASK.HITS(<task_magic>,<core>)

Returns the number of hits for the given task magic number and core number.

Parameter and Description:

<task_magic>	Parameter Type: Decimal or hex or binary value .
<core>	Parameter Type: Decimal value . If <core> is -1, the number of hits is returned for all cores.

Return Value Type: [Decimal value](#).

In This Section

See also

- [PORT.GET\(\)](#)
[PORT.SIZE\(\)](#)
- [PORT.MAXSIZE\(\)](#)
[PORT.STATE\(\)](#)
- [PORT.RECORDS\(\)](#)
[PORT.TRACK.RECORD\(\)](#)
- [PORT.REF\(\)](#)

PORT.GET()

Value of channel

Syntax:

PORT.GET(<channel_name>)

Returns the current value of the given port channel.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

PORT.MAXSIZE()

Get max. size of trace buffer in records

[build 38323 - DVD 08/2012]

Syntax:

PORT.MAXSIZE()

Returns the maximum possible trace buffer size of the port analyzer in records.

Return Value Type: [Decimal value](#).

PORT.RECORDS()

Get number of used trace records

Syntax:

PORT.RECORDS()

Returns the number of records in the port analyzer.

Return Value Type: [Decimal value](#).

PORT.REF()

Get record number of reference record

Syntax:

PORT.REF()

Returns the number of the selected reference record in the Port Analyzer.

Return Value Type: [Decimal value](#).

PORT.SIZE()

Get current trace buffer size in records

[build 38323 - DVD 08/2012]

Syntax:

PORT.SIZE()

Returns the size of the Port Analyzer trace buffer to be used in trace records.

Return Value Type: [Decimal value](#).

PORT.STATE()

Get state of Port Analyzer

Syntax:

PORT.STATE()

Returns the state of the Port Analyzer.

Return Value Type: [Hex value](#).

Return Value and Description:

0	Off state
1	Arm state
2	Break state
3	Trigger state
6	Slave state

PORT.TRACK.RECORD()

Get record number matching search

Syntax:

PORT.TRACK.RECORD()

After a successful search operation, this function returns the record number. For an example, see [Analyzer.TRACK.RECORD\(\)](#).

Return Value Type: [Decimal value](#).

PORTANALYZER()

Syntax: **PORTANALYZER()**

Returns TRUE if a port analyzer hardware is plugged.

Return Value Type: [Boolean](#).

PORTSHARING Function

PORTSHARING()

Current setting of PortSHaRing

ICD-TriCore, ICD-PCP, ICD-GTM, RH850

Syntax: **PORTSHARING()**
ETK() (deprecated)

Returns the current setting of [SYSTEM.CONFIG PortSHaRing](#).

Return Value Type: [Decimal value](#).

Return Value and Description:

0	OFF
1	ON
2	AUTO

In This Section

See also

- | | |
|---|---|
| hardware.POWERDEBUG() | hardware.POWERINTEGRATOR() |
| hardware.POWERINTEGRATOR2() | hardware.POWERNEXUS() |
| hardware.POWERTRACE() | hardware.POWERTRACE2() |
| hardware.POWERTRACE2LITE() | hardware.POWERTRACE3() |
| hardware.POWERTRACEPX() | hardware.POWERTRACESERIAL() |

In This Section

See also

- [hardware.POWERPROBE\(\)](#)
- [PROBE.GET\(\)](#)
- [PROBE.MAXSIZE\(\)](#)
- [PROBE.RECORD.DATA\(\)](#)
- [PROBE.RECORD.TIME\(\)](#)
- [PROBE.RECORDS\(\)](#)
- [PROBE.REF\(\)](#)
- [PROBE.SIZE\(\)](#)
- [PROBE.STATE\(\)](#)
- [PROBE.TRACK.RECORD\(\)](#)

PROBE.COUNTER.EVENT()

Get value of trigger program event counter

Syntax:

PROBE.COUNTER.EVENT(<counter_name>)

Returns the value of an event counter of the PowerProbe CTU.

Parameter Type: [String](#).

Return Value Type: [Decimal value](#).

PROBE.COUNTER.EXTERN()

Get value of trigger program external counter

Syntax:

PROBE.COUNTER.EXTERN(<counter_name>)

Returns the value of an extern counter of the PowerProbe CTU.

Parameter Type: [String](#).

Return Value Type: [Decimal value](#).

PROBE.COUNTER.TIME()

Get value of trigger program time counter

Syntax:

PROBE.COUNTER.TIME(<counter_name>)

Returns the value of a time counter of the PowerProbe CTU.

Parameter Type: [String](#).

Return Value Type: [Time value](#).

Syntax: **Probe.FIRST()**

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

PROBE.FLAG()

Check state of trigger program FLAG

Syntax: **PROBE.FLAG(<flag_name>)**

Returns the value of a flag of the PowerProbe CTU.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

PROBE.GET()

Value of channel

Syntax: **PROBE.GET(<channel_name>)**

Returns the current value of the given channel.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

PROBE.MAXSIZE()

Get max. size of trace buffer in records

Syntax: **PROBE.MAXSIZE()**

The maximum number of records, which can be recorded by the PowerProbe (value depends on the actual selected tracing mode too).

Return Value Type: [Decimal value](#).

PROBE.RECORD.DATA()

Get data recorded in trace record

Syntax:

PROBE.RECORD.DATA(<record_number>,<channel>)

Returns the sampled data from the specified record.

Parameter and Description:

<record_number>	Parameter Type: Decimal value .
<channel>	Parameter Type: String .

Return Value Type: [Hex value](#).

PROBE.RECORD.TIME()

Get timestamp of trace record

Syntax:

PROBE.RECORD.TIME(<record_number>)

Returns the timestamp from the specified record. For an example, see [Analyzer.RECORD.TIME\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

PROBE.RECORDS()

Get number of used trace records

Syntax:

PROBE.RECORDS()

Returns the number of records recorded by the PowerProbe.

Return Value Type: [Decimal value](#).

PROBE.REF()

Get record number of reference record

Syntax:

PROBE.REF()

Returns the number of the selected reference record in the Onchip trace.

Return Value Type: [Decimal value](#).

Syntax:

PROBE.SIZE()

Returns the actual defined logical size of the PowerProbe trace buffer in records.

Return Value Type: [Decimal value](#).

Syntax:

PROBE.STATE()

Returns the state of the PowerProbe.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

Syntax:

PROBE.TRACK.RECORD()

After a successful search operation, this function returns the record number. For an example, see [Analyzer.TRACK.RECORD\(\)](#).

Return Value Type: [Decimal value](#).

Program Pointer Function

PP() Address of program pointer (access class, space ID, program counter)

Syntax: **PP()**


Returns the address of the *program pointer*, which consists of the access class + the CPU program counter (PC). See [A] and [C] in the example.

Additionally, the function **PP()** returns the space ID as a hex value if **SYStem.Option.MMUSPACES** is set to **ON**. See [B] in the example.

Return Value Type: [Address](#).

Example:

```
PRINT PP()                      ;prints to the TRACE32 message line: SR:0x0:0x464
                               ;see screenshot
```



- A [Access class](#).
- B [Space ID](#).
- C Content of CPU program counter (PC). See also [Register.view](#) window.

See also: [Register\(\)](#).


Register()

Content of register

Syntax:

Register(<register_name> | PP)

Returns the content of a register.



- A Register names.
- B Register contents.
- C Register content of the program counter (PC).

Parameter and Description:

<register_name>	Parameter Type: String. The architecture-specific register names are displayed in the Register.view window.
PP	Parameter Type: String. A TRACE32 built-in keyword that can be used to return the register content of the program counter (PC) regardless of its real <register_name>. That is, the keyword PP is an <i>architecture-independent register name</i> for the program counter.

Return Value Type: Hex value.

Example:

```
Register.view           ;opens the Register.view window

PRINT Register(R13)     ;prints the content of the register named R13 to
                        ;the TRACE32 message line

PRINT Register(PP)      ;returns the content of the program counter (PC)
                        ;- regardless of its real <register_name>
```

See also: PP().


Syntax:

Register.LIST(" " | "<register_name>")

Returns the first / next valid register name.

Parameter and Description: You can pass an empty string as a register name or a real register name.

Empty string	Parameter Type: String . Passing an empty string returns the <i>first</i> register name. For example, the register name R0 for the ARM architecture. See [A] in figure below.
<register_name>	Parameter Type: String . Passing a real register name returns the name of the <i>next</i> register. For example, if you pass PC as register name, the function returns CPSR as the next register name for the ARM architecture. See [B] in figure below.



Return Value Type: [String](#).

Example: The function **Register.LIST()** is used to loop through all register names and print them to the **AREA.view** window.

```
Register.view
AREA.view

&reg=Register.LIST(" ")           ;returns the first register name
PRINT "&reg"                       ;and prints it to the AREA window

WHILE "&reg">" "                   ;loop through all register names
(
    PRINT Register.LIST("&reg")    ;print register name
    &reg=Register.LIST("&reg")    ;get next register name
)
```

Syntax:


Register.Valid(<register_name>)

Returns TRUE if the register value is available.

Parameter and Description:

<register_name>	Parameter Type: String . The architecture-specific register names are displayed in the Register.view window.
-----------------	---


Return Value Type: [Boolean](#).



```
PRINT Register.Valid(R0)      ; returns FALSE as the R0 value is not
                              ; available
PRINT Register.Valid(R5)      ; returns TRUE
```

RTS Functions

This figure provides an overview of the return values the RTS functions. For descriptions of the illustrated functions, see below.



In This Section

See also

- RTS
- RTS.BUSY()
- RTS.ERROR()
- RTS.FIFOFULL()
- RTS.NOCODE()
- RTS.RECORD()
- RTS.RECORDS()

RTS.ERROR()

Check for flowerrors during RTS processing

[\[Go to figure\]](#)

Syntax:

RTS.ERROR()

Returns TRUE if **flowerrors** where detected during RTS processing.

Return Value Type: **Boolean**.

RTS.NOCODE()

Check for RTS NOCODE error

[build 78366 - DVD 02/2017]

Syntax:

RTS.NOCODE()

Returns TRUE if code was missing in VM for decoding.

Return Value Type: **Boolean**.

Syntax: **RTS.FIFOFULL()**

Returns TRUE if the target trace FIFO buffer overflowed during the recording.

Return Value Type: [Boolean](#).

RTS.RECORD()

Find record causing an error in RTS

[build 78366 - DVD 02/2017]]

Syntax: **RTS.RECORD()**

Returns the record number of the error that stopped RTS.

Return Value Type: [Decimal value](#).

RTS.RECORDS()

Get number of trace records transferred to RTS

[\[Go to figure\]](#) [build 47027 - DVD 08/2013]

Syntax: **RTS.RECORDS()**

Returns the number of trace records transferred to the host for RTS processing.

Return Value Type: [Decimal value](#).

RTS.BUSY()

Check if RTS is busy

[build 115124 - DVD 02/2020]]

Syntax: **RTS.BUSY()**

Returns TRUE when RTS trace is off and processing is catching up.

Return Value Type: [Boolean](#).

In This Section

See also

- [RunTime](#)
- [RunTime.ACCURACY\(\)](#)
- [RunTime.ACTUAL\(\)](#)
- [RunTime.LAST\(\)](#)
- [RunTime.LASTRUN\(\)](#)
- [RunTime.REFA\(\)](#)
- [RunTime.REFB\(\)](#)

RunTime.ACCURACY()

Accuracy of run-time counter

Syntax:

RunTime.ACCURACY()

Returns the measurement error of the RunTime counter in seconds.

Return Value Type: [Time value](#).

RunTime.ACTUAL()

Syntax:

RunTime.ACTUAL()

Returns the value displayed in the **actual** column of the [RunTime.state](#) window (as time from zero).

Return Value Type: [Time value](#).

RunTime.LAST()

Syntax:

RunTime.LAST()

Returns the value displayed in the **laststart** column of the [RunTime.state](#) window (as time from zero).

Return Value Type: [Time value](#).

RunTime.LASTRUN()

Syntax: **RunTime.LASTRUN()**

Returns the time of the last single step or the time between the last go and break of the program.

Return Value Type: [Time value](#).

RunTime.REFA()

Syntax: **RunTime.REFA() (deprecated)**

Returns the value displayed in the **ref A** column of the [RunTime.SHOW](#) window (as time from zero).

Return Value Type: [Time value](#).

RunTime.REFB()

Syntax: **RunTime.REFB() (deprecated)**

Returns the value displayed in the **ref B** column of the [RunTime.SHOW](#) window (as time from zero).

Return Value Type: [Time value](#).

SMMU.BaseADDRESS()

Base address of SMMU

ARM, ARMv8-A

[build 64463 - DVD 09/2015]

Syntax:

SMMU.BaseADDRESS("<smmu_name>")

Returns the base address of hardware system MMU (SMMU). SMMUs are created with the **SMMU.ADD** command.

Parameter Type: [String](#).

Return Value Type: [Address](#).

Example:

```
;define a new SMMU named "myGPU" for a graphics processing unit
;      <smmu_name>      <base_address>
SMMU.ADD      "myGPU"      MMU500      A:0x50000000

;returns AZSD:0x0:0x50000000 as <base_address>
PRINT SMMU.BaseADDRESS ( "myGPU")
```

SMMU.StreamID2SMRG()

Find match for stream ID

ARM, ARMv8-A

[build 64463 - DVD 09/2015] [\[Example\]](#)

Syntax:

SMMU.StreamID2SMRG("<name>",<stream_id>")

Finds a matching stream mapping register group (SMRG) for a given <stream_id> using the SMMU stream ID matching algorithm.

Parameter and Description:

<name>	Parameter Type: String . Specifies the SMMU to be searched. The SMMU <name> must be quoted.
<stream_id>	Parameter Type: Decimal or hex or binary value . Stream ID of a memory transaction stream.

Return Value and Description:

Range: 0 to (max. number of index entries-1).	Return Value Type: Decimal value . If exactly one matching SMRG was found, the function returns the index of the matching SMRG. See also column index in the SMMU.StreamMapTable window.
-1	Return Value Type: Decimal value . If no matching SMRG was found for the given <i><stream_id></i> , -1 will be returned.
-2	Return Value Type: Decimal value . If more than one matching SMRG was found for the given <i><stream_id></i> , -2 will be returned. Additionally, a warning message will be printed to the AREA window. NOTE: If more than one SMRG matches a given <i><stream_id></i> , a stream matching fault occurs in the SMMU hardware.


Example: This PRACTICE script opens the **SMMU.StreamMapTable** window, searches for the *<stream_id>* 0x3464, and highlights the matching SMRG 0x0464 in yellow.

For the SMRG 0x0464, the function **SMMU.StreamID2SMRG()** returns the index 11 (decimal).

```
;open the window and highlight the matching SMRG in yellow
SMMU.StreamMapTable myGPU /StreamID 0x3464

;return the index of the SMRG as a decimal value
&index=SMMU.StreamID2SMRG ("myGPU", 0x3464)

;print the index as hex and decimal to the AREA window
PRINT "hex: 0x" CONVERT.INTTOHEX(&index) "    decimal: &index"
AREA.view
```




NOTE: At first glance, the **StreamID** 0x**3**464 does not seem to match the SMRG 0x**0**464. However, if you take the ID mask 0x7000 (= 0y0111_0000_0000_0000) into account, the match is correct.

The row highlighted in yellow in the **SMMU.StreamMapTable** window is a correct match for the **StreamID** 0x3464 we searched for.

SNOOPer Functions

This figure provides an overview of the return values of some of the SNOOPer functions. For descriptions of the illustrated functions and the functions not shown here, see below.



In This Section

See also

- [SNOOPer.FIRST\(\)](#)
 - [SNOOPer.RECORD.ADDRESS\(\)](#)
 - [SNOOPer.RECORD.OFFSET\(\)](#)
 - [SNOOPer.RECORDS\(\)](#)
 - [SNOOPer.SIZE\(\)](#)
- [SNOOPer.MAXSIZE\(\)](#)
 - [SNOOPer.RECORD.DATA\(\)](#)
 - [SNOOPer.RECORD.TIME\(\)](#)
 - [SNOOPer.REF\(\)](#)
 - [SNOOPer.STATE\(\)](#)

SNOOPer.FIRST()

Get record number of first trace record

[build 71062 - DVD 09/2016]

Syntax:

SNOOPer.FIRST()

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

SNOOPer.MAXSIZE()

Get max. size of trace buffer in records

[build 38323 - DVD 08/2012] [[Go to figure](#)]

Syntax: **SNOOPer.MAXSIZE()**

Returns the maximum possible number of records.

Return Value Type: [Decimal value](#).

SNOOPer.RECORD.ADDRESS()

Get address recorded in trace record

[build 38764]

Syntax: **SNOOPer.RECORD.ADDRESS(<record_number>)**

Returns the sampled address (access class and offset) from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

SNOOPer.RECORD.DATA()

Get data recorded in trace record

[build 38764]

Syntax: **SNOOPer.RECORD.DATA(<record_number>)**

Returns the sampled data of the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

SNOOPer.RECORD.OFFSET()

Get address in trace record as number

[build 38764]

Syntax: **SNOOPer.RECORD.OFFSET(<record_number>)**

Returns the address-offset of the sampled address from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Syntax:

SNOOPer.RECORD.TIME(<record_number>)

Returns the timestamp of the specified record. For an example, see [Analyzer.RECORD.TIME\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

Syntax:

SNOOPer.RECORDS()

The number of records currently recorded in the SNOOPer trace buffer.

Return Value Type: [Decimal value](#).

Syntax:

SNOOPer.REF()

The number of the selected reference record in the SNOOPer trace.

Return Value Type: [Decimal value](#).

Syntax:

SNOOPer.SIZE()

Returns the currently defined size of the SNOOPer trace buffer in records.

Return Value Type: [Decimal value](#).

Syntax:

SNOOPer.STATE()

Returns the state of the SNOOPer trace.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state

In This Section

See also

- ❑ [STATE.HALT\(\)](#)
- ❑ [STATE.NOCPUACCESS\(\)](#)
- ❑ [STATE.NOCTIACCESS\(\)](#)
- ❑ [STATE.OSLK\(\)](#)
- ❑ [STATE.POWER\(\)](#)
- ❑ [STATE.PROCESSOR\(\)](#)
- ❑ [STATE.RESET\(\)](#)
- ❑ [STATE.RUN\(\)](#)
- ❑ [STATE.TARGET\(\)](#)

STATE.HALT()

Syntax: **STATE.HALT()**

Returns the state of the “halt” display (i.e. no CPU cycles).

Return Value Type: [Boolean](#).

STATE.OSLK()

32-bit and 64-bit ARM cores

[build 67684 - DVD 02/2016]

Syntax: **STATE.OSLK()**

Returns the current state of the OS-lock bit of the CPU.

Return Value Type: [Boolean](#).

Return Value and Description:

TRUE	The CPU is running and OS-lock bit is set.
FALSE	FALSE can mean either case 1 or case 2: • Case 1: The CPU is running and OS-lock bit is cleared. • Case 2: The debugger has connected to the CPU and detected that the CPU has stopped.

Syntax:

STATE.POWER()

Returns the state of the target power line.

Return Value Type: [Boolean](#).

Return Value and Description:

TRUE	Power is applied.
FALSE	Power is not applied.


NOTE:

Please check the power-off voltage if the power-off state cannot be detected.
Especially for low-power applications, the debug/trace-signal current can be enough to power the application:
Target power does not drop to GND level -> power-off cannot be detected.

Example

In the following example, the message box is displayed as long as power is applied to the target board. The message box disappears only if these conditions are met:

- You have unplugged all connectors from the target board.
- You have clicked **OK**.



```
LOCAL &msgA &msgB &msgC ; PRACTICE macros for the message texts A, B, C

&msgA="1. Power OFF PandaBoard."+CONV.CHAR(0x0d)+\
"2. Click 'OK'. "+CONV.CHAR(0x0d)+"3. Power ON PandaBoard."

&msgB="Waiting for PandaBoard to power up..."

&msgC="PandaBoard is now powered up again."

AREA.view                ; Opens the AREA.view window.

WHILE STATE.POWER()      ; While power is on...
    DIALOG.OK "&msgA" ; ...prompt the user to power off the board.

PRINT "&msgB"          ; Now prompt the user to power up the board again.

WAIT STATE.POWER()      ; Wait for the user to respond as requested.

AREA.Clear ; Clear the previous message from the AREA.view window.

PRINT "&msgC"          ; Display success message.
```

`+CONV.CHAR(0x0d)+` creates a line break on the GUI. A backslash `\` is used as a line continuation character in PRACTICE script files (*.cmm). No white space permitted after the backslash.

STATE.PROCESSOR()

Syntax: **STATE.PROCESSOR()**

Returns the name of the processor, which was selected with the command **SYSystem.CPU**. This function is an alias for **SYSystem.CPU()**.

Return Value Type: **String**.

STATE.RESET()

Syntax: **STATE.RESET()**

Returns the state of the target reset line.

Return Value Type: [Boolean](#).

STATE.RUN()

Syntax: **STATE.RUN()**
 RUN() (deprecated)

Returns the state of the run-flag (CPU running in target).

Return Value Type: [Boolean](#).

STATE.TARGET()

State of target displayed in TRACE32 state line

Syntax: **STATE.TARGET()**

Returns the message about the target state displayed in the [state line](#). For example, `system down`, `system ready`, `running`, `stopped`.

Return Value Type: [String](#).

SPE Function

SPE()

Content from SPE register

Syntax: **SPE(<register_name>)**

Returns the content of the selected SPE register. See also [SPE](#) command group.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

SSE()

Segment from SSE register

Syntax: **SSE(<register_name>.<column_number>)**

Returns a 32-bit segment of the selected 128-bit SSE register. See also **SSE** command group.

Parameter Type: **String**.



Parameter and Description:

<register_name>	The register names are listed in the SSE.view window.
<column_number>	The column numbers start at 0 and are read from right to left in the SSE.view window. See example below. A column k corresponds to the bit range $(k \cdot 32 + 31) - (k \cdot 32)$, where $0 \leq k \leq 3$

Return Value Type: **Hex value**.

Example: This demo script returns 32-bit values of the register **XMM1** from the column **0** (bits 31 to 0) and the column **2** (bits 95 to 64) of the **SSE.view** window.

```
SSE.view
SSE.Set XMM1 689 789 809 9009
PRINT "Register|Bit Range|Col.|Value"
PRINT " XMM1   | 31-0   | 0  | " SSE(XMM1.0) ;32-bit value from col. 0
PRINT " XMM1   | 95-64  | 2  | " SSE(XMM1.2) ;32-bit value from col. 2
```



A Register names.

0 - 3 Column numbers - from right to left - in the **SSE.view** window.

hardware.STG()

TRUE if Stimuli Generator hardware

Syntax:

hardware.STG()
STG() (deprecated)

Returns TRUE if Stimuli Generator hardware is available.

Return Value Type: [Boolean](#).

In This Section

See also

- sYmbol
 - ❑ sYmbol.AutoLOAD.CHECKCMD()
 - ❑ sYmbol.BEGIN()
 - ❑ sYmbol.END()
 - ❑ sYmbol.EXIST()
 - ❑ sYmbol.FUNCTION()
 - ❑ sYmbol.ISFUNCTION()
 - ❑ sYmbol.LANGUAGE()
 - ❑ sYmbol.LIST.SOURCE()
 - ❑ sYmbol.NAME()
 - ❑ sYmbol.NEXT.BEGIN()
 - ❑ sYmbol.SEARCHFILE()
 - ❑ sYmbol.SECEND()
 - ❑ sYmbol.SECNAME()
 - ❑ sYmbol.SECRANGE()
 - ❑ sYmbol.SOURCEFILE()
 - ❑ sYmbol.SOURCEPATH()
 - ❑ sYmbol.TRANSPOSE()
 - ❑ sYmbol.VARNAME()
- ❑ sYmbol.AutoLOAD.CHECK()
 - ❑ sYmbol.AutoLOAD.CONFIG()
 - ❑ sYmbol.COUNT()
 - ❑ sYmbol.EPILOG()
 - ❑ sYmbol.EXIT()
 - ❑ sYmbol.IMPORT()
 - ❑ sYmbol.ISVARIABLE()
 - ❑ sYmbol.LIST.PROGRAM()
 - ❑ sYmbol.MATCHES()
 - ❑ sYmbol.NAME.AT()
 - ❑ sYmbol.RANGE()
 - ❑ sYmbol.SECADDRESS()
 - ❑ sYmbol.SECEXIST()
 - ❑ sYmbol.SECPRANGE()
 - ❑ sYmbol.SIZEOF()
 - ❑ sYmbol.SOURCELINE()
 - ❑ sYmbol.STATE()
 - ❑ sYmbol.TYPE()

sYmbol.AutoLOAD.CHECK()

Update option for the symbol autoloader

[build 71364 - DVD 09/2016]

Syntax:

sYmbol.AutoLOAD.CHECK()

Returns the update option of the symbol autoloader that was given with **sYmbol.AutoLOAD.CHECK**.

Return Value Type: **String**. Returns an empty string if no automatic update is configured.

sYmbol.AutoLOAD.CHECKCMD()

Load command for symbol autoloader

[build 71364 - DVD 09/2016]

Syntax:

sYmbol.AutoLOAD.CHECKCMD()

Returns the command that was specified to be used to load a symbol file with the symbol autoloader (e.g. as parameter to **sYmbol.AutoLOAD.CHECKCoMmand**).

Return Value Type: **String**. Returns an empty string if the symbol autoloader is not configured.

Syntax: **sYmbol.AutoLOAD.CONFIG()**

Returns the sub-command that was used to configure the symbol autoloader. E.g. "CHECKCoMmanD" if **sYmbol.AutoLOAD.CHECKCoMmanD** was used.

Return Value Type: [String](#). Returns an empty string if the symbol autoloader is not configured.

Syntax: **sYmbol.BEGIN(<symbol>)**

Returns the first address occupied by the symbol. A symbol name used alone represent the beginning address too. Function only implemented to have a counterpart of function the **sYmbol.END()**.

Parameter Type: [Symbol](#).

Return Value Type: [Address](#).

Example:

```
Data.Print sYmbol.BEGIN(vbfield)
Data.Print vbfield                // displays the identical value
```

Syntax: **sYmbol.COUNT(<symbol>)**

Returns the number of symbols defined with the specified name. The wildcards '*' and '?' are supported.

Parameter Type: [Symbol](#).

Return Value Type: [Decimal value](#).

Examples:

```
ECHO sYmbol.COUNT(func*)  
ECHO sYmbol.COUNT(func2?)
```

Syntax: **sYmbol.ECA.BINary.GAPNUMBER()**

Returns the number of observability gaps detected by the command [sYmbol.ECA.BINary.PROCESS](#).

The function returns the error code -1, if no symbols are loaded or a numeric overflow was detected.

Return Value Type: [Decimal value](#).

Syntax: **sYmbol.END(<symbol>)**

Returns the last address occupied by the symbol.

Parameter Type: [Symbol](#).

Return Value Type: [Address](#).

Example:

```
Data.Print sYmbol.END(vbfield)
```

Syntax: **sYmbol.EPILOG(<symbol>)**

Returns the last address of the specified function where the local variables are still valid, i.e. the address of the return point. Prerequisite: The function has *exactly one* return point.

Parameter Type: [Symbol](#).

Return Value Type: [Address](#).


Example 1: The function **sYmbol.EPILOG()** is used to display the address of the return point in the [Data.Print](#) window.

```
List.auto func1                ;optional step: display the function
Go.Return                      ;optional step: go to the address of
                               ;the return point
Data.Print sYmbol.EPILOG(func1) ;get the address of the return point
                               ;and display it in the Data.Print
                               ;window
```

Example 2: The function **sYmbol.EPILOG()** is used to set a breakpoint to the return point in order to watch the local variable `__struct_result` in the [Var.Watch](#) window.

```
Break.Set sYmbol.EPILOG(func4) ;set a breakpoint to the return point
                               ;address of 'func4'
Go                               ;start the program execution
WAIT !STATE.RUN()              ;wait until program stops

Var.Watch %Open.ON __struct_result //watch local variable '__struct_re.'
```



Syntax: **sYmbol.EXIST(<symbol>)**

Returns TRUE if the symbol exists in the TRACE32 symbol database or FALSE otherwise.

Parameter Type: [Symbol](#).

Return Value Type: [Boolean](#).

Example 1:

```
PRINT sYmbol.EXIST(vbfield)
PRINT sYmbol.EXIST(qwertzuiop)
```

Example 2: The **sYmbol.EXIST()** function can be used together with the [Trace.Find](#) command in a PRACTICE script. This prevents the PRACTICE script from stopping if the searched symbol does not exist, and eliminates the need for an error handler.

```
IF sYmbol.EXIST(qwertzuiop)
(
    Trace.Find , Address qwertzuiop
    IF FOUND()
        PRINT "Record number of 'qwertzuiop' is: " Analyzer.TRACK.RECORD()
)
ELSE
(
    PRINT "The symbol 'qwertzuiop' does not exist in the symbol database."
)
```

Syntax: **sYmbol.EXIT(<symbol>)**

Returns the exit address of the specified function.

Parameter Type: [Symbol](#).

Return Value Type: [Address](#).

Example:

```
Data.Print sYmbol.EXIT(func40)
PRINT ADDRESS.OFFSET(sYmbol.EXIT(func40))
```

Syntax: **sYmbol.FUNCTION(<address>)**

Returns the path and name of the function that includes the specified address. The address has to be classified, e.g. **P:0x200**

Parameter Type: [Address](#).

Return Value Type: [String](#).

Example:

```
PRINT sYmbol.FUNCTION(P:0x40001000)
```

sYmbol.IMPORT()

Import file names

Syntax: **sYmbol.IMPORT()**

Returns the name of the next not yet processed import file name. This function can be used to walk through the list of import names (Only relevant for *.exe target programs, on Windows CE for example).

Return Value Type: [String](#).

sYmbol.ISFUNCTION()

TRUE if symbol is function

[build 135097 - DVD 09/2021]

Syntax: **sYmbol.ISFUNCTION(<symbol>)**

Returns TRUE if the selected symbol is function.

Parameter Type: [Symbol](#).

Return Value Type: [Boolean](#).

Example:

```
Print sYmbol.ISFUNCTION(func1) ; return TRUE
```

Syntax: **sYmbol.ISVARIABLE(<*symbol*>)**

Returns TRUE if the selected symbol is variable.

Parameter Type: [Symbol](#).

Return Value Type: [Boolean](#).

Syntax:

sYmbol.LANGUAGE()

Returns the currently selected language for high-level expressions.

Return Value Type: [String](#).

sYmbol.List.MAP.<x>()

Information about address ranges on the target

[build 86990 - DVD 09/2017]

Syntax:

sYmbol.List.MAP.<x>()

<x>:

COUNT | BEGIN | END | RANGE

(Full function name only required for HELP.Index):

sYmbol.List.MAP.COUNT()
sYmbol.List.MAP.BEGIN(<index>)
sYmbol.List.MAP.END(<index>)
sYmbol.List.MAP.RANGE(<index>)


<x>	Description of sYmbol.List.MAP.<x>()
COUNT	Returns the number of address ranges loaded to the target with the Data.LOAD.* <file> commands. Return Value Type: Decimal value .
BEGIN(<index>)	Returns the start address of the range <index>. Parameter Type: Decimal value . Return Value Type: Address .
END(<index>)	Returns the end address of the range <index>. Parameter Type: Decimal value . Return Value Type: Address .
RANGE(<index>)	Returns the range <index>. Parameter Type: Decimal value . Return Value Type: Address range .

Parameter and Description:

<index>	The individual <index> numbers of the ranges are listed in the load order column of the sYmbol.List.MAP window. To return the highest <index> number, use sYmbol.List.MAP.COUNT() .
---------	---

Example:

```
SYStem.Up ;connect to target
Data.LOAD.Elf sieve_flash_thumb_ii_v7m.elf ;load application to target
&i=1.
RePeaT sYmbol.List.MAP.COUNT() ;loop through number of address ranges
( ;let's use PRINTF to format the output to the AREA.view window
  PRINTF "%s%i%s" "Range " &i " starts at "
  PRINTF %CONTinue "0x%x%s" sYmbol.List.MAP.BEGIN(&i) ". "
  &i=&i+1.
)
```



sYmbol.LIST.PROGRAM()

Path and file name of binary files

[build 42354 - DVD 02/2013]

Syntax:

sYmbol.LIST.PROGRAM(1 | 0)

Returns the path and file name of a loaded target binary, e.g. an ELF file.

Parameter and Description:

1	Parameter Type: Decimal or hex value . Starts with the first target binary listed in the sYmbol.List.Program window.
0	Parameter Type: Decimal or hex value . Continues with the next target binary in the list. To return all loaded target binaries, call the function repeatedly until an empty string is returned.

Return Value Type: [String](#).

Syntax:

sYmbol.List.PROGRAM.<x>()

<x>:

COUNT | COMMAND | FORMAT | FILE | NAME | RANGE

(Full function name only required for HELP.Index):

sYmbol.List.PROGRAM.COUNT()
sYmbol.List.PROGRAM.COMMAND(<index>)
sYmbol.List.PROGRAM.FORMAT(<index>)
sYmbol.List.PROGRAM.FILE(<index>)
sYmbol.List.PROGRAM.NAME(<index>)
sYmbol.List.PROGRAM.RANGE(<index>)


<x>	Description of sYmbol.List.PROGRAM.<x>()
COUNT	Returns the number of programs loaded to the symbol table with the Data.LOAD.* <file> commands. Return Value Type: Decimal value .
COMMAND(<index>)	Returns the commandline how <index> got added to the symbol database. Parameter Type: Decimal value . Return Value Type: String .
FORMAT(<index>)	Returns the format of program <index>. Parameter Type: Decimal value . Return Value Type: String .
FILE(<index>)	Returns the path of file <index>. Parameter Type: Decimal value . Return Value Type: String .
NAME(<index>)	Returns the symbol database name of <index>. Parameter Type: Decimal value . Return Value Type: String .
RANGE(<index>)	Returns the range <index>. Parameter Type: Decimal value . Return Value Type: Address range .

Parameter and Description:

<index>	The individual <index> numbers address the lines in the sYmbol.List.Program window. To return the highest <index> number, use sYmbol.List.PROGRAM.COUNT() .
---------	--

Example:

```
; load file to symbol database
Data.LOAD.Elf ~/demo/arm/compiler/gnu-pic/sieve_arm.elf /NoCODE
Data.LOAD.Elf ~/demo/arm/compiler/gnu-pic/sieve_thumb_v4.elf \
                                0x80000000 /NoCODE /NoClear
&i=1.
RePeaT sYmbol.List.PROGRAM.COUNT() ; loop through number of programs
( ; lets use PRINTF to format output to AREA.view window
  PRINTF "Program %i Name: %s" &i sYmbol.List.PROGRAM.NAME(&i)
  PRINTF " Format: %s" sYmbol.List.PROGRAM.FORMAT(&i)
  PRINTF " File: %s" sYmbol.List.PROGRAM.FILE(&i)
  PRINTF " Range: %#!R" sYmbol.List.Program.RANGE(&i)
  &i=&i+1.
)
```



sYmbol.List.SECTION.<x>()

Information about section ranges

[build 141685 - DVD 02/2022]

Syntax:	sYmbol.List.SECTION.<x>()
<x>:	COUNT PATH RANGE
(Full function name only required for HELP.Index):	sYmbol.List.SECTION.COUNT() sYmbol.List.SECTION.PATH(<index>) sYmbol.List.SECTION.RANGE(<index>)

<x>	Description of sYmbol.List.PROGRAM.<x>()
COUNT	Returns the number of sections loaded to the symbol table with the Data.LOAD.* <file> commands. Return Value Type: Decimal value.
PATH(<index>)	Returns the symbol path <index>. Parameter Type: Decimal value. Return Value Type: String.
RANGE(<index>)	Returns the range <index>. Parameter Type: Decimal value. Return Value Type: Address range.


Parameter and Description:

<index>	The individual <index> numbers address the lines in the sYmbol.List.SECTION window. To return the highest <index> number, use sYmbol.List.SECTION.COUNT() .
---------	--

Example:

```

; load file to symbol database
Data.LOAD.Elf ~/demo/arm/compiler/gnu-pic/sieve_arm.elf /NoCODE
&i=1.
RePeaT sYmbol.List.SECTION.COUNT() ; loop through number of sections
( ; lets use PRINTF to format output to AREA.view window
  PRINTF "Range %i Path: %-24s Range: %#!R" &i \
        sYmbol.List.SECTION.PATH(&i) sYmbol.List.SECTION.RANGE(&i)
  &i=&i+1.
)
```



Syntax:

sYmbol.LIST.SOURCE(<start_over>,<filter>,<refresh_source_list>)

Via the TRACE32 Remote API, 3rd-party tools can use the **sYmbol.LIST.SOURCE()** together with the **T32Cmd()** interface function to request the file location of all source files, e.g. *.c files, used to build the currently loaded target binary, e.g. an ELF file.

Because a target binary consists of more than one source file, it is necessary to call the **sYmbol.LIST.SOURCE()** function repeatedly until an empty string is returned.

Parameter and Description:

<start_over>	Parameter Type: Decimal or hex value. 1: Starts with the first source file listed in the sYmbol.List.SOURCE window, e.g. a *.c. file. 0: Continue with the next source file in the list.
<filter>	Parameter Type: Decimal or hex value. 0: Returns the file path of all files referenced in the symbol file, regardless if found on the local machine or not. 1: Returns the file location of all files that are currently loaded by TRACE32 PowerView. This implies that the files are found on the local machine. 2: Returns the file path of files that are not found by TRACE32 PowerView. 4: Returns the file path of files referenced in the symbol file, but do not contain any sourcecode with debug information. Such files will never show up in the List window.
<refresh_source_list>	Parameter Type: Decimal or hex value. 1: Tells TRACE32 PowerView to refresh the internal source file list before returning file locations. 0: Does not refresh the internal source file list, i.e. files not opened in a Data.List window will be unknown / missing.

Return Value Type: [String](#).

sYmbol.MATCHES()

Number of occurrences

Syntax:

sYmbol.MATCHES()

Returns the number of hits of a preceding command like [sYmbol.Browse](#) or [sYmbol.ForEach](#).

Return Value Type: [Decimal value](#).

Example:

```
sYmbol.Browse func*0
PRINT sYmbol.MATCHES ( )
ENDDO
```

sYmbol.NAME()

Symbol path and name based on address

Syntax: **sYmbol.NAME(<address>)**

Returns the symbol path and name of a specific address. The address has to be classified, e.g. **D:0x200**. If the address is within the body of a function, the result is the same as returned by **sYmbol.FUNCTION()**.

Parameter Type: [Address](#).

Return Value Type: [String](#).

Example:

```
PRINT sYmbol.NAME (D:0x40005EB8)
```

sYmbol.NAME.AT()

Resolve ambiguous symbols based on address

[build 54072 - DVD 09/2014]

Syntax: **sYmbol.NAME.AT(<address>,<context_address>)**

Returns the symbol path and name of an *<address>*.

The function tries to find the symbol in the symbol database which fits best to the specified context address. Address, space ID, and access class of the specific context address are used as filter criteria to find the best match.

The function is useful if the same symbol name exists more than once in the symbol database. The function allows to find the symbol which belongs to a specific program address range or a specific task (space ID). In addition in ARM architectures, the function finds the symbol which belongs to a specific ARM Zone (non-secure, secure, hypervisor, see **SYStem.Option.ZoneSPACES**).

Parameter and Description:

<i><address></i>	Parameter Type: String .
<i><context_address></i>	Parameter Type: Address .

Return Value Type: [String](#). Returns an empty string if no matching symbol is found.

Examples:

```
PRINT sYmbol.NAME.AT(sieve,D:0x00209860)
PRINT sYmbol.NAME.AT(main,D:0x02A3:0x0)
PRINT sYmbol.NAME.AT(__per_cpu_offset,H:0x0)
PRINT sYmbol.NAME.AT(__per_cpu_offset,N:0x0)
```

sYmbol.NEXT.BEGIN()

Start address of next symbol

[build 33011 - DVD 02/2012]

Syntax: **sYmbol.NEXT.BEGIN(<symbol>)**

Returns the start address of the next symbol.

Parameter Type: [Symbol](#).

Return Value Type: [Address](#).

sYmbol.RANGE()

Address range of symbol

Syntax: **sYmbol.RANGE(<symbol>)**

Returns the address range occupied by the symbol (e.g. function or variable).

Parameter Type: [Symbol](#).

Return Value Type: [Address range](#).

Example:

```
Data.Print sYmbol.RANGE(flags)
```

sYmbol.SEARCHFILE()

Absolute path of source file

Syntax: **sYmbol.SEARCHFILE(<file>)**



Walks through the search path for source files and returns the absolute path of the first found file.

Parameter Type: [String](#).

Return Value Type: [String](#). If no file is found the function returns an empty string.

Example:

```
PRINT symbol.SEARCHFILE(demo.c)
PRINT symbol.SEARCHFILE(.src\sieve.c)
```



Syntax:

sYmbol.SECADDRESS(<section>)

Returns the logical start address of the named section.

Parameter Type: [String](#).

Return Value Type: [Address](#).

Syntax:

sYmbol.SECEND(<section>)

Returns the logical end address of the named section.

Parameter Type: [String](#).

Return Value Type: [Address](#).

[build 115086 - DVD 02/2020]

Syntax:

sYmbol.SECEXIST(<section>)

Returns TRUE if the named section exists.

Parameter Type: [String](#)

Return Value Type: [Boolean](#).

Syntax:

sYmbol.SECNAME(<address>)

Returns the name of the section at the specified address.

Parameter Type: [Address](#).

Return Value Type: [String](#).

See also: [sYmbol.List.Section](#) window.

sYmbol.SECPRANGE()

Physical address range of section

Syntax:

sYmbol.SECPRANGE(<section>)

Returns the physical address range occupied by the named section.

Parameter Type: [String](#).

Return Value Type: [Address range](#).

sYmbol.SECRANGE()

Logical address range of section

Syntax:

sYmbol.SECRANGE(<section>)

Returns the logical address range occupied by the named section.

Parameter Type: [String](#).

Return Value Type: [Address range](#).

Syntax:

sYmbol.SIZEOF(<symbol>)

Returns the size occupied by the specified debug symbol in memory (e.g. function, variable, module).

Parameter Type: [Symbol](#).

Return Value Type: [Hex value](#).

Example:

```
Data.Print flags++sYmbol.SIZEOF(flags)

Data.Find flags++sYmbol.SIZEOF(flags) 0x00
IF FOUND()
(
    Data.Set TRACK.ADDRESS() 0xEE
    Data.Print TRACK.ADDRESS()
)
ENDDO
```

Syntax:

sYmbol.SOURCEFILE(<address> | <symbol>[,<want_load_path>])

Returns the name of the source file for the specified program address or symbol. The address has to be classified, e.g. **P**:0x200. In this example, **P**: stands for the memory class *Program Memory*.

This function can only be used with program addresses/symbols. It returns an empty string for data addresses / variables.

Parameter and Description:

<address>	Parameter Type: Address .
<symbol>	Parameter Type: Symbol .
<want_load_path>	Parameter Type: Boolean . Returns the file loading path, if parameter is true or omitted. Otherwise the compilation file path, generated at build time, is returned.

Return Value Type: [String](#).

Example:

```
PRINT sYmbol.SOURCEFILE(main)
PRINT sYmbol.SOURCEFILE(main,FALSE())
```

sYmbol.SOURCELINE()

HLL-line number of address

Syntax: **sYmbol.SOURCELINE(<address>)**

Returns the HLL-line number of the specified address. The address has to be classified, e.g. **P:0x200**. In this example, **P** stands for the memory class *Program Memory*.

Parameter Type: [Address](#).

Return Value Type: [Decimal value](#).

Example 1:

```
PRINT sYmbol.SOURCELINE(P:0x40005EB8)
```

Example 2: A user-defined command with the name **EDT** is created. When you execute it, TRACE32 opens the source file in your external editor (here: TextPad) and positions the cursor in the line where the program counter (PC) is located in TRACE32.

```
; command extension to call external editor
; adapt path and parameter syntax to your own editor, e.g.:
; - uedit32.exe filename/line
; - textpad.exe filename(line)

ON CMD EDT GOSUB
(
  LOCAL &file &line &cmdline
  ENTRY &file
  IF "&file"==" "
  (
    &file=sYmbol.SOURCEFILE(P:Register(pc))
    &line=sYmbol.SOURCELINE(P:Register(pc))
    &line=STRING.CUT("&line",-1.)
  )
  &cmdline="OS.Command start textpad.exe &file(&line)"
  &cmdline
  RETURN
)
STOP
ENDDO
```

Syntax: **sYmbol.SOURCEPATH(<directory_path>)**

Returns TRUE if the given directory name is already defined as directory search path (by **sYmbol.SourcePATH** or loader option **/PATH**).

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Example:

```
&my_path=sYmbol.SOURCEFILE(main)
&my_path=OS.FILE.PATH(&my_path)
PRINT "&my_path"
sYmbol.SourcePATH.Set &my_path
PRINT sYmbol.SOURCEPATH(&my_path)
sYmbol.SourcePATH.List
ENDDO
```

[build 53267 - DVD 08/2014]

Syntax: **sYmbol.STATE(<name>)**

Returns a value from the window **sYmbol.STATE** specified by its name.

Parameter Type: [String](#).

Return Value Type: [String](#).

Example:

```
&functions=sYmbol.STATE(functions)
PRINT %Decimal &functions " known functions in your target program(s) "
```

[build 122118 - DVD 09/2020]

Syntax: **sYmbol.TRANSPOSE(<name>)**

Allows to transpose program and module names following this rule:

- 1. A ‘_’ is added as first characcter, if the name begins with 0--9 or ‘\$’.
- 2. Any character expect 0--9, A--Z, a--z is replaced by a ‘_’.

This transposing can be switched off by adding the option **/NoTranspose** to any **Data.LOAD** comman.

Parameter Type: [String](#).

Return Value Type: [String](#).

Example:

```
PRINT sYmbol.TRANSPOSE("1_test-12@test-bay")
; prints "_1_test_12_test_bay" to AREA
```

sYmbol.TYPE()

Type of symbol

Syntax:

sYmbol.TYPE(<symbol>)

Returns the basic type of a symbol.

Parameter Type: [Symbol](#).

Return Value Type: [Hex value](#).

Return Value and Description:

0	Symbol does not exist.
1	Plain label without type information.
2	HLL function.
3	HLL variable.
(-)	Other values may be defined in the future.

Examples:

```
PRINT sYmbol.TYPE(qwertzuiop)
PRINT sYmbol.TYPE(_main)
PRINT sYmbol.TYPE(sieve)
PRINT sYmbol.TYPE(flags)
```

Syntax: **sYmbol.VARNAME(<address>)**



Returns the name of the variable or structure element at the specified address.

Parameter Type: [Address](#).

Return Value Type: [String](#).

SYStem Functions

This figure provides an overview of the return values of some of the SYStem functions. For descriptions of the illustrated SYStem functions and other SYStem functions, see below.



In This Section

See also

- SYStem
- ❑ SYStem.AMBA()
- ❑ SYStem.CADIconfig.RemoteServer()
- ❑ SYStem.CONFIG.DEBUGPORT()
- ❑ SYStem.CONFIG.DRPOST()
- ❑ SYStem.CONFIG.IRPOST()
- ❑ SYStem.CONFIG.JTAGTAP()
- ❑ SYStem.CONFIG.ListSIM()
- ❑ SYStem.CONFIG.TAPState()
- ❑ SYStem.DCI.Bridge()
- ❑ SYStem.DCI.TIMEOUT()
- ❑ SYStem.GTL.CONNECTED()
- ❑ SYStem.GTL.LIBName()
- ❑ SYStem.GTL.VENDORID()
- ❑ SYStem.HOOK()
- ❑ SYStem.IMASKHLL()
- ❑ SYStem.INSTANCECOUNT()
- ❑ SYStem.JtagClock()
- ❑ SYStem.MCDCommand.ResultString()
- ❑ SYStem.Mode()
- ❑ SYStem.Option.DUALPORT()
- ❑ SYStem.Option.HRCWOVerRide()
- ❑ SYStem.Option.MMUSPACES()
- ❑ SYStem.Option.SPILLLOcation()
- ❑ SYStem.RESetBehavior()
- ❑ SYStem.USECORE()
- ❑ SYStem.ACCESS.DENIED()
- ❑ SYStem.BigEndian()
- ❑ SYStem.CADIconfig.Traceconfig()
- ❑ SYStem.CONFIG.DEBUGPORTTYPE()
- ❑ SYStem.CONFIG.DRPRE()
- ❑ SYStem.CONFIG.IRPRE()
- ❑ SYStem.CONFIG.ListCORE()
- ❑ SYStem.CONFIG.Slave()
- ❑ SYStem.CPU()
- ❑ SYStem.DCI.BssbClock()
- ❑ SYStem.GTL.CALLCOUNTER()
- ❑ SYStem.GTL.CYCLECOUNTER()
- ❑ SYStem.GTL.PLUGINVERSION()
- ❑ SYStem.GTL.VERSION()
- ❑ SYStem.IMASKASM()
- ❑ SYStem.INSTANCE()
- ❑ SYStem.IRISconfig.RemoteServer()
- ❑ SYStem.LittleEndian()
- ❑ SYStem.MCDconfig.LIBrary()
- ❑ SYStem.NOTRAP()
- ❑ SYStem.Option.EnReset()
- ❑ SYStem.Option.MACHINESPACES()
- ❑ SYStem.Option.ResBreak()
- ❑ SYStem.Option.ZoneSPACES()
- ❑ SYStem.Up()
- ❑ SYStem.USEMASK()

SYStem.ACCESS.DENIED()

TRUE if memory access is denied

Syntax: **SYStem.ACCESS.DENIED()**

Returns whether memory accesses are allowed during real-time emulation.

Return Value Type: [Boolean](#).

Example:

```
SYStem.MemAccess Denied
PRINT SYStem.ACCESS.DENIED() ;returns TRUE
```

SYStem.AMBA()

TRUE if AMBA bus mode is selected

Syntax: **SYStem.AMBA()**

Returns TRUE if **SYStem.Option.AMBA** is active.

Refer to “[Arm Debugger](#)” (debugger_arm.pdf) for more information.

Return Value Type: [Boolean](#).

SYStem.BigEndian()

TRUE if target core runs in big endian mode

[build 05147 - DVD 12/2009]

Syntax: **SYStem.BigEndian()**

Returns TRUE if target core runs in big endian mode.

Return Value Type: [Boolean](#).

Syntax:	SYStem.CADIconfig.RemoteServer(<key>)
<key>:	1 2 3

Returns the information about the connection to the CADI server. The connection is configured with the command **SYStem.CADIconfig.RemoteServer**.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Parameter and Description:

1	Returns the IP address or host name of the remote computer where the virtual target including the CADI server is running.
2	Returns the TCP/IP port of the CADI server.
3	Returns the IP address or host name and the port as follows: <ip>:<port>

Return Value Type: [String](#).

Return Value and Description:

- IP address or host name or port depend on the parameter passed to the function.
- For local settings, localhost without any port is returned.

Examples:

```
SYStem.CADIconfig.RemoteServer
PRINT SYStem.CADIconfig.RemoteServer(3)      ;returns localhost

SYStem.CADIconfig.RemoteServer 192.168.178.2 7002.
PRINT SYStem.CADIconfig.RemoteServer(1)      ;returns 192.168.178.2
PRINT SYStem.CADIconfig.RemoteServer(3)      ;returns 192.168.178.2:7002

SYStem.CADIconfig.RemoteServer RmtPC 7000.
PRINT SYStem.CADIconfig.RemoteServer(2)      ;returns RmtPC
```

Syntax: SYStem.CADIconfig.Traceconfig(1 | 2 | 3)

Returns information about the connection to the CADI trace plug-in. The connection is configured with the command [SYStem.CADIconfig.Traceconfig](#).

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Parameter and Description:

1	Returns the IP address of the host machine where the virtual target is running.
2	Returns the TCP/IP port of the trace plug-in.
3	Returns the IP address and the port as follows: <ip>:<port>

Return Value Type: [String](#).

SYStem.CONFIG.<tap_position>()

[build 45294 - DVD 08/2013] [\[Go to figure\]](#)

Syntax:	SYStem.CONFIG.<tap_position>(<core_index>)
<tap_position>:	DRPOST DRPRE IRPOST IRPRE
Full function name only	SYStem.CONFIG.DRPOST(<core_index>)
required for	SYStem.CONFIG.DRPRE(<core_index>)
HELP.Index:	SYStem.CONFIG.IRPOST(<core_index>)
	SYStem.CONFIG.IRPRE(<core_index>)

Returns the effective JTAG PRE and POST settings of the core to be debugged. See also command **SYStem.CONFIG.DRPRE**.

Parameter and Description:

<core_index>	Parameter Type: Decimal or hex or binary value. - The index number of the core is 0 if you are debugging only one core. - If you are debugging multiple cores in an SMP debug session and if the cores use different TAP controller in the JTAG scan chain, then <core_index> refers to the core of interest.
--------------	--

Return Value Type: [Decimal value](#).

SYStem.CONFIG.DEBUGPORT()

[build 53511 - DVD 08/2014] [\[Go to figure\]](#)

Syntax:	SYStem.CONFIG.DEBUGPORT()
---------	---------------------------

Returns the selected debug port.

Details about the meaning of the return value can be found in the description of the [SYStem.CONFIG.DEBUGPORT](#) command.

Return Value Type: [String](#).

SYStem.CONFIG.DEBUGPORTTYPE()

[build 53511 - DVD 08/2014] [\[Go to figure\]](#)

Syntax:	SYStem.CONFIG.DEBUGPORTTYPE() DEBUGPORT.TYPE() (deprecated)
---------	--

Returns the selected debug port type, e.g. JTAG, CJTAG.

SYStem.CONFIG.JTAGTAP()

Return the JTAG PRE and POST settings

[build 103442 - DVD 02/2019] [\[Examples\]](#)

Syntax:	SYStem.CONFIG.JTAGTAP (<i><item></i> , <i><config_index></i>)
<i><item></i> :	[<i><component></i>] IRPRE [. <i><subitem></i>] [<i><component></i>] DRPRE [. <i><subitem></i>] [<i><component></i>] IRPOST [. <i><subitem></i>] [<i><component></i>] DRPOST [. <i><subitem></i>]
<i><component></i> :	DAP DAP2 ETB ... (depending on the CPU architecture)
<i><subitem></i> :	ABSOLUTE FIXED



Returns the JTAG PRE and POST settings of the core TAP, DAP TAP, ETB TAP and others used for debugging. See also commands **SYStem.CONFIG.IRPRE**, **SYStem.CONFIG DAPIRPRE**, etc. in the [Processor Architecture Manuals](#).

Parameter and Description:

<i><item></i>	Parameter Type: String. Name of the JTAG TAP coordinate which reflects a setting in the SYStem.CONFIG.state /Jtag window, e.g. the setting for DAPIRPOST. Per default, the value entered by the user is returned.
<i><subitem></i>	Parameter Type: String. Per default, the value entered by the user is returned. FIXED returns the preconfigured value in TRACE32 relative to the SoC. ABSOLUTE returns the preconfigured value + the value entered by the user.
<i><config_index></i>	Parameter Type: Decimal value. Index of the physical core TAP; in case of DAP or ETB the value must be 0. 1 ≤ x ≤ CONFIGNUMBER(). 0 is an alias for the first physical core or items that are shared among multiple cores.

Return Value Type: [Decimal value](#).

Example 1: For the ARM architecture



```

;[A] returns the value entered by the user for DAPIRPOST
PRINT "A: " SYSTEM.CONFIG.JTAGTAP(DAPIRPOST,0) ;returns 0

;[B] returns the preconfigured value for DAPIRPOST relative
;to the SoC
PRINT "B: " SYSTEM.CONFIG.JTAGTAP(DAPIRPOST.FIXED,0) ;returns 4

;[A]+[B] returns the value entered by the user + the
;preconfigured value. In this case the result is again 4
PRINT "A+B = " SYSTEM.CONFIG.JTAGTAP(DAPIRPOST.ABSOLUTE,0) ;returns 4


;now the SoC is daisy-chained with another SoC which has
;the IR-length 8 and the DR-length 1
SYSTEM.CONFIG DAPIRPOST 8.
SYSTEM.CONFIG DAPDRPOST 1.

;[C] returns the value entered by the user for DAPIRPOST
PRINT "C: " SYSTEM.CONFIG.JTAGTAP(DAPIRPOST,0) ;returns 8



;[D] returns the preconfigured value for DAPIRPOST relative
;to the SoC
PRINT "D: " SYSTEM.CONFIG.JTAGTAP(DAPIRPOST.FIXED,0) ;returns 4

;[C]+[D] returns the value entered by the user + the
;preconfigured value. Now the result is 12
PRINT "C+D = " SYSTEM.CONFIG.JTAGTAP(DAPIRPOST.ABSOLUTE,0) ;returns 12

```



Example 2: For the MIPS architecture



```

PRINT CONFIGNUMBER() ;returns the upper bound of <config_index>, here 2

;[A] returns the value entered by the user for IRPOST
PRINT "A: " SYSTEM.CONFIG.JTAGTAP (IRPOST,2) ;returns 0

;[B] returns the preconfigured value for IRPOST relative
;to the SoC
PRINT "B: " SYSTEM.CONFIG.JTAGTAP (IRPOST.FIXED,2) ;returns 5

;[A]+[B] returns the value entered by the user + the
;preconfigured value. in this case the result is again 5
PRINT "A+B = " SYSTEM.CONFIG.JTAGTAP (IRPOST.ABSOLUTE,2) ;returns 5


;now the SoC is daisy-chained with another SoC which has the
;IR-length 8 and the DR-length 1
SYSTEM.CONFIG IRPOST 8.
SYSTEM.CONFIG DRPOST 1.

;[C] returns the value entered by the user for IRPOST
PRINT "C: " SYSTEM.CONFIG.JTAGTAP (IRPOST,2) ;returns 8

;[D] returns the preconfigured value for DAPIRPOST relative
;to the SoC
PRINT "D: " SYSTEM.CONFIG.JTAGTAP (IRPOST.FIXED,2) ;returns 5

;[C]+[D] returns the value entered by the user + the
;preconfigured value. now the result is 13
PRINT "C+D = " SYSTEM.CONFIG.JTAGTAP (IRPOST.ABSOLUTE,2) ;returns 13

```



Syntax: **SYStem.CONFIG.ListCORE**(<line_number>,"<column_string>")

Returns the core list from the virtual target platform only once with first call of the function **SYStem.CONFIG.ListCORE()** or the command **SYStem.CONFIG.ListCORE**. This will require a **SYStem.Mode Down** state. All later function calls return the core list from a table stored locally.

Parameter and Description:

<line_number>	Parameter Type: Decimal or hex value . A numerical input indicating the line number for the search; <line_number> equals the core # number. Range: • 0x0 or 0. returns the number of available lines, i.e. cores. • -1 re-reads the core information for the virtual target platform.
<column_string>	Parameter Type: String . A case sensitive search string that must match the searched column name. An empty string "" is allowed.

Return Value Type: [String](#).

Return Value and Description:

String	If the search string <column_string> is found, the complete element is returned as a string.
Empty string	If the search string <column_string> does not match a column name and/or the <line_number> was out of its currently valid range, an empty string is returned.

Examples for SYStem.CONFIG.ListCORE():

```
;returns the number of cores
PRINT SYStem.CONFIG.ListCORE(0,"")

;returns the value at the intersection of the 2nd row and the column
;labeled "simulation".
PRINT SYStem.CONFIG.ListCORE(2,"simulation")

;returns an empty string because the column labeled "SimulationN" does not
;exist. Remember that the "<column_string>" is case-sensitive.
PRINT SYStem.CONFIG.ListCORE(2,"SimulationN")

PRINT SYStem.CONFIG.ListCORE(200., "device")

PRINT SYStem.CONFIG.ListCORE(2, "core")
```

```
;re-reads the core information for the virtual target platform
PRINT SYStem.CONFIG.ListCORE(-1, "")

;returns the updated value at the intersection of the 2nd row and the
column labeled "core"
PRINT SYStem.CONFIG.ListCORE(2, "core")
```

SYStem.CONFIG.ListSIM()

Syntax: **SYStem.CONFIG.ListSIM(<line_number>,"<column_string>")**

The function returns a string, and both parameters are mandatory. The content of the simulation list is read from the virtual target platform only once with first call of the function **SYStem.CONFIG.ListSIM()** or the command **SYStem.CONFIG.ListSIMulation**. This will require a **SYStem.Mode Down** state. All later function calls return strings from a table stored locally.

Parameter and Description:

<line_number>	Parameter Type: Decimal or hex value . A numerical input, indicating the line number for the search; <line_number> equals the core # number. Range: 0x0 or 0. returns the number of available lines, i.e. cores. -1 re-reads the core information for the virtual target platform.
<column_string>	Parameter Type: String . A case-sensitive search string that must match the searched column name. An empty string "" is allowed.

Return Value Type: [String](#).

Return Value and Description:

String	If the search string <column_string> was found, the complete element is returned as a string.
Empty string	If the search string <column_string> does not match a column name and/or the <line_number> was out of its currently valid range, an empty string is returned.

SYStem.CONFIG.Slave()

[build 45263 - DVD 08/2013] [[Go to figure](#)]

Syntax: **SYStem.CONFIG.Slave()**

Returns TRUE if setting **SYStem.CONFIG Slave** is set to **ON**.

Return Value Type: [Boolean](#).

Syntax: SYStem.CONFIG.TAPState()

Returns the default JTAG TAP state configured with the command **SYStem.CONFIG TAPState**.

Return Value Type: [Decimal value](#).

Return Value and Description:

0	Exit2-DR
1	Exit1-DR
2	Shift-DR
3	Pause-DR
4	Select-IR-Scan
5	Update-DR
6	Capture-DR
7	Select-DR-Scan
8	Exit2-IR
9	Exit1-IR
10	Shift-IR
11	Pause-IR
12	Run-Test/Idle
13	Update-IR
14	Capture-IR
15	Test-Logic Reset

SYStem.CPU()

Name of processor

Syntax: **SYStem.CPU()**
 CPU() (deprecated)

Returns the name of the processor, which was selected with the command **SYStem.CPU**. This function is an alias for **STATE.PROCESSOR()**.

Return Value Type: [String](#).

Syntax: **SYStem.GTL.CALLCOUNTER()**

Retrieves the number of calls to the GTL library to measure performance.

Return Value Type: [Decimal value](#).

Syntax: **SYStem.GTL.CONNECTED()**

Returns TRUE if all configured transactors are connected to the simulation or emulation.

Return Value Type: [Boolean](#).

Syntax: **SYStem.GTL.CYCLECOUNTER()**

Retrieves the number of clock cycles of the executed protocol since the last call. In case of JTAG, **SYStem.GTL.CYCLECOUNTER()** counts the JTAG clock cycles.

Return Value Type: [Decimal value](#).

Syntax: **SYStem.GTL.LIBname()**

Returns the name of the GTL library that was passed by the command [SYStem.GTL.LIBname](#).

Return Value Type: [String](#).

Syntax:

SYStem.GTL.ModelINFO(<n>)

Returns the info string of the n^{th} model enumerated from GTL API. The info string can be used to pass information about the model.

If n equals -1, the function returns the info string of the current model. The index for iteration start by 0. The returned values are valid for all values n where [SYStem.GTL.ModelNAME\(n\)](#) returns a valid name.

Parameter Type: [Decimal value](#).

Return Value Type: [String](#).

Example:

```
LOCAL &n
&n=0.
while SYStem.GTL.ModelNAME (&n) != " "
(
    PRINT "Model: " SYStem.GTL.ModelNAME (&n) " Info: "
    SYStem.GTL.ModelINFO (&n)
    &n=&n+1.
)
ENDDO
```

SYStem.GTL.ModelNAME()

Model Name

Syntax:

SYStem.GTL.ModelNAME(<index>)

Returns the name of a certain model.

Parameter Type: [Decimal value](#).

Return Value Type: [String](#).

SYStem.GTL.PLUGINVERSION()

Version number

Syntax:

SYStem.GTL.PLUGINVERSION()

Returns the version number of the GTL API retrieved from the GTL library/plugin-in.

Return Value Type: [Decimal value](#).

SYStem.GTL.TransactorNAME()

Transactor name

Syntax:

SYStem.GTL.TransactorNAME(<index>)

Returns the name of a transactor.

Parameter Type: [Decimal value](#).

Return Value Type: [String](#).

SYStem.GTL.TransactorTYPE()

Transactor type

Syntax:

SYStem.GTL.TransactorTYPE(<index>)

Returns the type of a transactor.

Parameter Type: [Decimal value](#).

Return Value Type: [String](#).

Return Value and Description: Types can be JTAGPROBE, GPIO, TRACE, BUSMASTER,...

SYStem.GTL.VENDORID()

Vendor ID

Syntax:

SYStem.GTL.VENDORID()

Returns the vendor ID retrieved from the GTL library.

Return Value Type: [String](#).

Syntax: **SYStem.GTL.VERSION()**

Returns the version number of the GTL API of TRACE32.

Return Value Type: [Decimal value](#).

SYStem.HOOK()

Syntax: **SYStem.HOOK()**

Returns address of the hook function defined with **SYStem.Option.HOOK**.

Return Value Type: [Hex value](#).

SYStem.IMASKASM()

Syntax: **SYStem.IMASKASM()**

Returns the TRUE if interrupts are disabled during assembler stepping due to the setting **SYStem.Option.IMASKASM ON**.

Return Value Type: [Boolean](#).

SYStem.IMASKHLL()

Syntax: **SYStem.IMASKHLL()**

Returns the TRUE if interrupts are disabled during HLL stepping due to the setting **SYStem.Option.IMASKHLL ON**.

Return Value Type: [Boolean](#).

Syntax:

SYStem.INSTANCE()

If a TRACE32 PowerView instance belongs to an AMP debug session, then this function returns the index of the TRACE32 PowerView instance.

Return Value Type: [Hex value](#).

Return Value and Description:

0x1...	If the PowerView instances have been started via the T32Start utility, then the return values correspond to the values that T32Start has assigned to the PowerView instances. Without the use of T32Start, the return value corresponds to the <i><index></i> value <i>you</i> have specified for <code>INSTANCE=<index></code> in the config file.
0x0	The index of a PowerView instance is 0x0 (a) if the configuration file contains the setting <code>CORE=0</code> or (b) if TRACE32 was started as TRACE32 Instruction Set Simulator (<code>PBI=SIM</code> in the config file).

For information about `CORE=` and `INSTANCE=`, refer to:

- [“Section PBI”](#) (installation.pdf)

Example:

```
;the instance indexes of all PowerView GUIs participating in an
;AMP debug session are printed to their respective message lines
InterCom.execute ALL ECHO SYStem.INSTANCE()
```

Syntax:

SYStem.INSTANCECOUNT()

This function returns the number of TRACE32 PowerView GUIs connected to the same PowerDebug box.

Return Value Type: [Decimal value](#).

SYStem.IRISconfig.RemoteServer()

[build 109127 - DVD 09/2019]

Syntax:	SYStem.IRISconfig.RemoteServer(<key>)
<key>:	1 2 3

Returns the details about the connection to the IRIS server. The connection is configured with the command **SYStem.IRISconfig.RemoteServer**.

Parameter Type: [Decimal](#) or [hex](#) or [binary value](#).

Parameter and Description:

1	Returns the IP address or host name of the remote computer where the virtual target including the IRIS server is running.
2	Returns the TCP/IP port of the IRIS server.
3	Returns the IP address and the port as follows: <ip>: <port>.

Return Value Type: [String](#).

SYStem.JtagClock()

Syntax:	SYStem.JtagClock()
---------	---------------------------

Returns the JTAG clock set with the command **SYStem.JtagClock**.

Return Value Type: [Decimal value](#).

SYStem.LittleEndian()

[build 05147 - DVD 12/2009]

Syntax:	SYStem.LittleEndian()
---------	------------------------------

Returns TRUE if target core runs in little endian mode.

Return Value Type: [Boolean](#).

SYStem.MCDCommand.ResultString()

[build 136589 - DVD 09/2021]

Syntax: SYStem.MCDCommand.ResultString()

Returns the answer-string of the MCD server given by the last call of **SYStem.MCDCommand**. The maximum length of this string is 100 characters. It returns an empty string if no answer is available.

Return Value Type: [String](#).

SYStem.MCDconfig.LIBrary()

[build 76420 - DVD 09/2016]

Syntax: SYStem.MCDconfig.LIBrary(<key>)
<key>: 1 | 2 | 3

Returns the path and/or file name of the used MCD library.

Parameter and Description:

1	Parameter Type: Decimal or hex or binary value . Returns the file name of the library, e.g. mcddrv.dll
2	Parameter Type: Decimal or hex or binary value . Returns the path of the library, e.g. c:\virtual_target\mcd\
3	Parameter Type: Decimal or hex or binary value . Returns the path and the file name of the library, e.g. c:\virtual_target\mcd\mcddrv.dll

Return Value Type: [String](#).

SYStem.Mode()

Syntax: SYStem.Mode()

Returns the actual debugger mode.

Return Value Type: [Hex value](#).

Return Value and Description:

0	Down
1	StandBy
2	NoDebug
4	Prepare
11	Up
12	Up (StandBy)
13	Prepare (StandBy)

SYStem.NOTRAP()

1 if the option NOTRAP is active

Syntax:SYStem.NOTRAP()

Returns 1 if the command **SYStem.Option.NOTRAP** is active.

Return Value Type: [Hex value](#).

SYStem.Option.DUALPORT()

State of like-named command

Only available for architectures having the like-named command

[build 108886 - DVD 09/2019]

Syntax:SYStem.Option.DUALPORT()

Returns TRUE if the command **SYStem.Option.DUALPORT** is set to **ON**, else the function returns FALSE.

Return Value Type: [Boolean](#).

SYStem.Option.MACHINESPACES()

State of like-named command

ARM, PowerPC, Intel® x86

[build 104967 - DVD 02/2019]

Syntax:SYStem.Option.MACHINESPACES()

Returns TRUE if the command **SYStem.Option.MACHINESPACES** is set to **ON**, else the function returns FALSE.

Return Value Type: [Boolean](#).

Example:

```
IF SYSTEM.Option.MACHINESPACES()==FALSE()  
    SYSTEM.Option.MACHINESPACES ON
```

SYStem.Option.MMUSPACES()

State of like-named command

ARM, PowerPC, Intel® x86

[build 104967 - DVD 02/2019]

Syntax: **SYStem.Option.MMUSPACES()**

Returns TRUE if the command **SYStem.Option.MMUSPACES** is set to **ON**, else the function returns FALSE.

Return Value Type: Boolean.

Example

```
IF SYSTEM.Option.MMUSPACES()==FALSE()  
    SYSTEM.Option.MMUSPACES ON
```

SYStem.Option.EnReset()

State of like-named command

ARM

[build 135725 - DVD 09/2021]

Syntax: **SYStem.Option.EnReset()**

Returns the current state of **SYStem.Option.EnReset** as TRUE or FALSE.

Return Value Type: Boolean.

SYStem.Option.ResBreak()

State of like-named command

ARM

[build 134096 - DVD 09/2021]

Syntax: **SYStem.Option.ResBreak()**

Returns the current state of **SYStem.Option.ResBreak** as TRUE or FALSE.

Return Value Type: Boolean.

Syntax:

SYStem.Option.SPILLLOCation()

Returns the current state of **SYStem.Option.SPILLLOCation** as TRUE or FALSE.

Return Value Type: [Hex value](#).

Syntax:

SYStem.Option.ZoneSPACES()

Returns TRUE if the command **SYStem.Option.ZoneSPACES** is set to **ON**, else the function returns FALSE.

Return Value Type: [Boolean](#).

Example

```
IF SYStem.Option.ZoneSPACES()==FALSE()  
  SYStem.Option.ZoneSPACES ON
```

Syntax:

SYStem.RESetBehavior()

Returns the current setting of [SYStem.Option.RESetBehavior](#).

Return Value Type: [String](#).

HALT RestoreGo RunRestore	For a description of the return values, see SYStem.Option.RESetBehavior in “ TriCore Debugger and Trace ” (debugger_tricore.pdf).
--	---

Example:

```
SYStem.Option.RESetBehavior Halt
PRINT SYStem.RESetBehvior()      ;returns the string HALT
```

SYStem.Up()

TRUE if debugger has access to debug resources

Syntax:

SYStem.Up()

Returns whether the actual mode of the probe is up (see also [SYStem.Mode\(\)](#) function).

Return Value Type: [Boolean](#).

Example 1:

```
IF !SYStem.Up()      ;alternatively: IF SYStem.Up()==FALSE()
(
    ;your code
)
ELSE
(
    ;your code
)
```

Example 2: This script shows how to access a peripheral register on the AHB bus prior to **SYStem.Mode Up** or **Attach**, e.g. to disable a watchdog.

```
SYStem.Mode Prepare

IF SYStem.Up()==TRUE()      ; if Prepare was successful
(
    ; configure peripheral register before SYStem.Mode Up or Attach
    Data.Set EAHB:<peripheral_address> %Long 0x1
)
```

SYStem.USECORE()

Syntax: **SYStem.USECORE()**

Returns the value of CORE= from the PBI= section in the config file.

If CORE= or INSTANCE= or both are missing in the config file, then **SYStem.USECORE()** returns 1 by default. That is, in this case the return value is equivalent to the explicit setting CORE=1 in the config file.

For information about CORE= and INSTANCE=, refer to:

- [“Section PBI”](#) (installation.pdf)

Return Value Type: [Hex value](#).

Example: In this script, a second instance is started, and then **SYStem.USECORE()** is used to return the value of CORE=.

```
;returns 1
PRINT SYStem.USECORE()

;starts a 2nd TRACE32 PowerView instance with the user-defined name
;'secondInst', clones and extends the current config file for the 2nd
;instance
TargetSystem.NewInstance secondInst /ChipIndex 10. /ONCE

;the CONVERT.HEXTOIN() function is used to convert the hex return value
;of SYStem.USECORE() to the decimal value 10
InterCom.execute secondInst PRINT CONVERT.HEXTOINT(SYStem.USECORE())
```

SYStem.USEMASK()

Syntax:

SYStem.USEMASK()

Returns the USEMASK of this TRACE32 PowerView GUI.

Return Value Type: [Hex value](#).

The USEMASK selects the Lauterbach device, when several devices are connected to each other via PODBUS IN/OUT. The bitmask defines which devices (PowerDebug, PowerTrace, PowerProbe, ...) are controlled by the host application program. A '1' means control the device, a '0' means skip the device. The left most bit controls the first device on the bus i.e. the device with the host connection (USB, ETH). Normally a use mask will contain a single set bit e.g. "1000", indicating that only one of the devices in the PODBUS is used by the respective program. When using PowerView to control two devices the use mask will contain two '1' bits. An example for this is a PowerDebug device and a PowerProbe device which are used to record signals corresponding to a debug session of PowerDebug. Using this mechanism it is possible to combine a debugger and a PowerProbe device, independently of their position in the PODBUS chain.

The USEMASK is set in the TRACE32 configuration file (config.t32) with option `USE=<bits>` in the section `PBI=`

However the function **SYStem.USEMASK()** returns the value set in `USE=` *in an inverse bit-order*. The same value is also shown in the [VERSION.HARDWARE](#) window.

The function returns 0xFFFFFFFFFFFFFFFF for a single debugger (where `USE=` was not set).

device	USE=	PRINT %BINary SYStem.USEMASK()	VERSION.HARDWARE
1st	100	00000001	0x0001
2nd	010	00000010	0x0002
3rd	001	00000100	0x0003


TASK Functions

The TASK functions can be used after [OS-aware debugging](#) has been configured, as described in the **Configuration** chapters of the [“OS Awareness Manuals”](#) (rtos_<os>.pdf).

In the following, we list the TASK functions that work with all OS-aware configurations.

For the TASK functions that work only with specific OS-aware configurations, refer to the [“OS Awareness Manuals”](#) (rtos_<os>.pdf).

This figure provides an overview of the return values of some of the TASK functions. For descriptions of the illustrated TASK functions and other TASK functions, see below.



In This Section

See also

- TASK
 - ❑ TASK.ACCESS()
 - ❑ TASK.BACK()
 - ❑ TASK.CONFIGFILE()
 - ❑ TASK.CURRENT.MACHINEID()
 - ❑ TASK.CURRENT.TASK()
 - ❑ TASK.FIRST()
 - ❑ TASK.ID()
 - ❑ TASK.MACHINE.ID()
 - ❑ TASK.MACHINE.VTTB()
 - ❑ TASK.MAGIC()
 - ❑ TASK.MAGICRANGE()
 - ❑ TASK.NAME()
 - ❑ TASK.ORTIFILE()
 - ❑ TASK.SPACEID()
- ❑ TASK()
 - ❑ TASK.ACCESS.ZONE()
 - ❑ TASK.CONFIG()
 - ❑ TASK.COUNT()
 - ❑ TASK.CURRENT.SPACEID()
 - ❑ TASK.CURRENT.TASKNAME()
 - ❑ TASK.FORE()
 - ❑ TASK.MACHINE.ACCESS()
 - ❑ TASK.MACHINE.NAME()
 - ❑ TASK.MACHINEID()
 - ❑ TASK.MAGICADDRESS()
 - ❑ TASK.MAGICSIZE()
 - ❑ TASK.NEXT()
 - ❑ TASK.SPACE.COUNT()

Syntax:

TASK()

Returns the name of the current task.
Short for TASK.CURRENT.TASKNAME()

Return Value Type: [String](#).

TASK.ACCESS()

Access class

[\[build 69123\]](#)

Syntax:

TASK.ACCESS()

Returns the access class set by the command [TASK.ACCESS](#).

Return Value Type: [String](#).

TASK.ACCESS.ZONE()

Access class zone

[\[build 68412\]](#)

Syntax:

TASK.ACCESS.ZONE()

Returns the access class zone set by the command [TASK.ACCESS](#).

Return Value Type: [String](#).

TASK.BACK()

Background task number

Syntax:

TASK.BACK()

Returns the background task number.

Return Value Type: [Hex value](#).

Syntax:

TASK.CONFIG(magic | magicsize)

Parameter and Description:

magic	Parameter Type: String (<i>without</i> quotation marks). Returns the magic address, which is the location that contains the currently running task (i.e. its task magic number). The task is identified by a unique value called <i>task magic number</i>. The magic numbers of the tasks are displayed in the magic column of the TASK.List.tasks window.
magicsize	Parameter Type: String (<i>without</i> quotation marks). Returns the size of the task magic number (1, 2 or 4).

Return Value Type: [Hex value](#).

Example 1:

```
PRINT TASK.CONFIG(magic)
```

Example 2:

```
PRINT TASK.CONFIG(magicsize)
```

[build 78972]

Syntax:

TASK.CONFIGFILE()

Returns the file (with path) used to load an OS Awareness with [TASK.CONFIG](#).

Return Value Type: [String](#).

[build 123903]

Syntax:

TASK.COUNT()

Returns the number of tasks in the task list.

Return Value Type: [Hex value](#).

Syntax:

TASK.CURRENT.MACHINEID()

Returns the ID of the current machine. Only valid if SYStem.Option MACHINESPACES is set.

Return Value Type: [Hex value](#).

Syntax:

TASK.CURRENT.SPACEID()

Returns the ID of the current MMU space. Only valid if SYStem.Option MMUSPACES is set.

Return Value Type: [Hex value](#).

Syntax:

TASK.CURRENT.TASK()

Returns the “magic value” of the current task.

Return Value Type: [Hex value](#).

Syntax:

TASK.CURRENT.TASKNAME()

Returns the name of the current task.

Return Value Type: [String](#).

Syntax:

TASK.FIRST()

Returns the task magic number of the first task in the task list.

Return Value Type: [Hex value](#).

TASK.FORE()

Foreground task number

Syntax:

TASK.FORE()

Returns the foreground task number.

Return Value Type: [Hex value](#).

TASK.ID()

ID of task

[\[Go to figure\]](#)

Syntax:

TASK.ID("<task_name>")

Returns the ID of the specified task name.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

TASK.MACHINE.ACCESS()

Default access class

[build 92265 - DVD 01/2018]

Syntax:

TASK.MACHINE.ACCESS(<machine_id>)

Returns the default access class of the machine specified by <machine_id>.

This function is useful on systems with a hypervisor after [SYSTEM.Option.MACHINESPACES](#) has been set to **ON**. For some hypervisors it is difficult to determine whether a given guest machine runs in the guest mode (hardware virtualized machines) or in the host/hypervisor mode (pseudo virtualized machines). The **TASK.MACHINE.ACCESS()** function can be used to find out with which access class a logical addresses of a given machine must be prefixed.

Examples:

- On Intel systems the default access class may be based on **H**: (machines running in VMX host mode) or **G**: (machines running in VMX guest mode).
- On ARM systems, the default access class may be based on **H**: (machines running in hypervisor mode) or **N**: (machines running in non-secure/guest mode).

Parameter Type: [Decimal value](#).

Return Value Type: [String](#).

TASK.MACHINE.ID()

ID of machine

[build 123903]

Syntax:

TASK.MACHINE.ID("<machine_name>")
TASK.MACHINEID("<machine_name>") (deprecated)

Returns the ID of the given machine name if the machine exists.
Returns "1F" if the machine does not exist.

The machine name is set by a Hypervisor Awareness or by an extension name (see also the command [EXTension.LOAD](#)).

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

TASK.MACHINE.NAME()

Name of machine

[build 92273 - DVD 02/2018]

Syntax:

TASK.MACHINE.NAME(<machine_id> | <machine_magic>)

Returns the name of the given machine ID if the machine exists.
Returns the machine ID if the machine exists but does not have a name.
Returns "(unknown)" if the machine does not exist.

The machine name is set by a Hypervisor Awareness or by an extension name (see also the command [EXTension.LOAD](#)).

Parameter and Description:

<machine_id>	Parameter Type: Decimal or hex or binary value . For information about the parameter, see machine ID .
<machine_magic>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [String](#).

Example 1: This script lists all functions of the machine with ID 1 in the [sYmbol.Browse.Function](#) window, provided the symbol program name is identical to the machine name.

```
LOCAL &machinename
&machinename=TASK.MACHINE.NAME(1)
sYmbol.Browse.Function \\&machinename\*\*
```

Example 2: Based on the specified address, the [ADDRESS.MACHINEID\(\)](#) function extracts the machine ID. The machine ID is then passed to the [TASK.MACHINE.NAME\(\)](#) function, which returns the machine name belonging to the machine ID.

```
PRINT TASK.MACHINE.NAME(ADDRESS.MACHINEID(P:0x1:::0x3000))
```

TASK.MACHINE.VTTB()

VTTB of machine

Syntax: **TASK.MACHINE.VTTB(<machine_id> | <machine_magic>)**

Returns the virtualization translation table base address of the given machine if the machine exists.
Returns -1 if the machine does not exist.

Parameter and Description:	
<machine_id>	Parameter Type: Decimal or hex or binary value . For information about the parameter, see machine ID .
<machine_magic>	Parameter Type: Decimal or hex or binary value .

Return Value Type: [Hex value](#).

TASK.MAGIC()

Task magic number

Syntax: **TASK.MAGIC("<task_name>")**

Returns the task magic number of the specified task name.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Syntax:

TASK.MAGICADDRESS([<core>[,<machine_id>]])

Returns the address of the memory location holding the running task of the specified core and machine (aka "magic_address").

Parameter and Description:

<core>	Parameter Type: Hex value .
<machine_id>	Parameter Type: Hex value .
NONE	If no parameter is given the function returns the address holding the running task of the core and machine currently in use.

Return Value Type: [Address](#).

Syntax:

TASK.MAGICRANGE([<core>[,<machine_id>]])

Returns the range of the memory location holding the running task of the specified core and machine (aka "magic_address").

Parameter and Description:

<core>	Parameter Type: Hex value .
<machine_id>	Parameter Type: Hex value .
NONE	If no parameter is given the function returns the range of the memory location holding the running task of the core and machine currently in use.

Return Value Type: [Address](#).

Syntax:

TASK.MAGICSIZE([<core>[,<machine_id>]])

Returns the size of the memory location holding the running task of the specified core and machine (aka "magic_address").

Parameter and Description:

<core>	Parameter Type: Hex value .
<machine_id>	Parameter Type: Hex value .
NONE	If no parameter is given the function returns the size of the memory location holding the running task of the core and machine currently in use.

Return Value Type: [Address](#).

TASK.NAME()

Name of task

[\[Go to figure\]](#)

Syntax:

TASK.NAME(<task_magic>)

Returns a task name based on the specified task magic number.

Parameter Type: [Hex value](#).

Return Value Type: [String](#).

Example:

```
PRINT TASK.NAME ( 0xEBF2F9C0 )
```

TASK.NEXT()

Next task in list

[\[build 123903\]](#)

Syntax:

TASK.NEXT(<task_magic>)

Returns the task magic number of the task following the specified task in the task list.

Parameter Type: [Hex value](#).

Return Value Type: [Hex value](#).

Syntax:

TASK.ORTIFILE([<machine_id>])

Returns the file (with path) used to load an ORTI file with **TASK.ORTI/EXT.ORTI.LOAD**. The optional parameter <machine_id> can be used in hypervisor and iAMP setups to specify the machine ID the ORTI file was loaded to.

Parameter and Description:

<machine_id>	Optional: Machine ID the ORTI file was loaded to. Useful for hypervisor/iAMP setups. Parameter Type: Decimal or hex or binary value.
--------------	--

Return Value Type: String.

Example:

```
; Single OS case
CD C:\Projects\os1
TASK.ORTI deploy/os.orti
PRINT TASK.ORTIFILE()
; Result: "C:\Projects\os1\deploy\os.orti"

; Hypervisor/iAMP scenario
CD C:\Projects
EXT.ORTI.LOAD os1/deploy/os.orti /MACHINE 1.
EXT.ORTI.LOAD os2/deploy/os.orti /MACHINE 2.
PRINT TASK.ORTIFILE(2.)
; Result: "C:\Projects\os2\deploy\os.orti"
PRINT TASK.ORTIFILE(1.)
; Result: "C:\Projects\os1\deploy\os.orti"
PRINT TASK.ORTIFILE(3.)
; Result: ""
```

Syntax:

TASK.SPACE.COUNT()

Returns the number of address spaces in the list of spaces.

Return Value Type: Hex value.

Syntax: **TASK.SPACEID("<task_name>")**

Returns the space ID of the specified task name.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

In This Section

See also

- [TERM](#)
□ [TERM.RETURNCODE\(\)](#)
- [TERM.LINE\(\)](#)
□ [TERM.TRIGGERED\(\)](#)
- [TERM.NEWHANDLE\(\)](#)
- [TERM.READBUSY\(\)](#)

TERM.LINE()

Get line from terminal window

Syntax:

TERM.LINE(<channel>,<line_number>)
TERM.LINE(<address>,<line_number>) (deprecated)

<channel>:

#<number>

Returns the content of the specified line from the active terminal window.

Parameter and Description:

<channel>	Parameter Type: String . Handle to refer to a terminal. A new handle can be created with TERM.METHOD .
<address>	Parameter Type: Address . <address> is the communication port of the virtual terminal.
<line_number>	Parameter Type: Decimal value .

Return Value Type: [String](#).

TERM.NEWHANDLE()

Get next free terminal handle

[build 168780 - DVD 09/2024]

Syntax:

TERM.NEWHANDLE()

Returns the next free handle for terminal operations.

Return Value Type: [String](#).

Example:

```
PRIVATE &th
&th=TERM.NEWHANDLE()
TERM.METHOD #&th COM COM1
TERM.view #&th
```

TERM.READBUSY()

TRUE as long as TERM.READ is in progress

[build 143560 - DVD 02/2022]

Syntax:

TERM.READBUSY()

Returns TRUE as long as a **TERM.READ** command is in progress.

Return Value Type: Boolean.

Example:

```
TERM.READ #1 <file_name>      ; start upload
SCREEN.ALWAYS                 ; to make upload as fast as possible

;PRACTICE will loop through this while loop until the read is done
WHILE TERM.READBUSY(#1)
(
    //Some PRACTICE commands
)

SCREEN.ON
```

TERM.RETURNCODE()

Get returncode from terminal routine

[build 58677 - DVD 02/2015]

Syntax:

TERM.RETURNCODE(<channel>)
TERM.RETURNCODE(<address>) (deprecated)

<channel>:

#<number>

Returns the return value of the semihosting function from the active terminal window.

Parameter and Description:

<channel>	Parameter Type: String. Handle to refer to a terminal. A new handle can be created with TERM.METHOD .
<address>	Parameter Type: Address. <address> is the communication port of the virtual terminal.

TERM.TRIGGERED()

Get trigger state of terminal window

[build 95013 - DVD 09/2018]

Syntax:

TERM.TRIGGERED(<channel>)

TERM.TRIGGERED(<address_out>) (deprecated)

<channel>:

#<number>

Returns TRUE once the message string to be searched for in the active terminal window has been printed to the active terminal window. Use the [TERM.TRIGGER](#) command to specify the message string you want.

Parameter and Description:

<channel>	Parameter Type: String . Handle to refer to a terminal. A new handle can be created with TERM.METHOD .
<address_out>	Parameter Type: Address . The address parameter is only required for memory-based data exchange (SingleE, BufferE, SingleS, BufferS). Pass an arbitrary address for all non-memory-based methods e.g. Serial Console/COM.

Return Value Type: [Boolean](#).


Example 1:

```
TERM.TRIGGER #3 "Hit any key"
SCREEN.WAIT TERM.TRIGGERED (#3)
```

Example 2: Refer to the [TERM.TRIGGER](#) command.

TPIU Functions

This figure provides an overview of the return values of the functions. For descriptions of the illustrated functions, see below.



In This Section

See also

- TPIU
- TPIU.PortMode()
- TPIU.PortSize()
- TPIU.SWVPrescaler()

TPIU.PortMode()

Port mode setting

[build 65602 - DVD 09/2015] [\[Go to figure\]](#)

Syntax: **TPIU.PortMode()**

Returns current **PortMode** setting of the TPIU made with the command **TPIU.PortMode**. For example, **Bypass**, **Wrapper**, **Continuous**, **NRZ**.

Return Value Type: [String](#).

TPIU.PortSize()

Port size setting

[build 65602 - DVD 09/2015] [\[Go to figure\]](#)

Syntax: **TPIU.PortSize()**

Returns the current **PortSize** setting of the TPIU made with the command **TPIU.PortSize**.

Return Value Type: [String](#).

Return Value and Description:

1, 2, 3, 4, ...	Port size setting for parallel trace.
1Lane, 2Lane, 3Lane, 4Lane	Port size setting for serial trace.
SWV	Port size setting for SerialWireViewer.

TPIU.SWVPrescaler()

SWVPrescaler value

[build 65602 - DVD 09/2015] [\[Go to figure\]](#)

Syntax:

TPIU.SWVPrescaler()

Returns the current **SWVPrescaler** value set with the command **TPIU.SWVPrescaler**.

Return Value Type: [Decimal value](#).

TPUBASE Function

TPUBASE.ADDRESS()

Address of TPU

Syntax:

TPUBASE.ADDRESS()

Returns the address where the TPU is located.

Return Value Type: [Address](#).

Trace Functions

This figure provides an overview of the return values of some of the Trace functions. For descriptions of the illustrated functions and the functions not shown here, see below.

Trace.STATE()

Trace.RECORDS()

Trace.METHOD()
Trace.METHOD.ANALYZER()
Trace.METHOD.ART()
Trace.METHOD....()

Trace.MAXSIZE()
Trace.SIZE()

In This Section

See also

- Trace

□ Trace.FLOW.FIFOFULL()

□ Trace.METHOD.ART()

□ Trace.METHOD.Integrator()

□ Trace.METHOD.ONCHIP()

□ Trace.RECORD.DATA()

□ Trace.SIZE()

□ Trace.STATistic.FIRST()

□ Trace.STATistic.LAST()

□ Trace.TraceCONNECT()

□ Trace.FIRST()

□ Trace.MAXSIZE()

□ Trace.METHOD.CAnalyzer()

□ Trace.METHOD.IProbe()

□ Trace.METHOD.Probe()

□ Trace.RECORD.OFFSET()

□ Trace.STATE()

□ Trace.STATistic.IMAX()

□ Trace.STATistic.MAX()

□ Trace.FLOW()

□ Trace.METHOD()

□ Trace.METHOD.FDX()

□ Trace.METHOD.LA()

□ Trace.METHOD.SNOOPer()

□ Trace.RECORD.TIME()

□ Trace.STATistic.COUNT()

□ Trace.STATistic.IMIN()

□ Trace.STATistic.MIN()

□ Trace.FLOW.ERRORS()

□ Trace.METHOD.Analyzer()

□ Trace.METHOD.HAnalyzer()

□ Trace.METHOD.LOGGER()

□ Trace.RECORD.ADDRESS()

□ Trace.RECORDS()

□ Trace.STATistic.EXIST()

□ Trace.STATistic.Internal()

□ Trace.STATistic.Total()

Trace.FIRST()

Get record number of first trace record

[build 71062 - DVD 09/2016]

Syntax:

Trace.FIRST()

Returns the record number of the first record. The first record is the record with the lowest record number.

Return Value Type: [Decimal value](#).

Trace.FLOW()

TRUE if trace method is flow trace

[build 70748 - DVD 09/2016]

Syntax: **Trace.FLOW()**

Returns TRUE if the selected trace method is a flow trace.

Return Value Type: [Boolean](#).

Trace.FLOW.ERRORS()

Get number of flow errors / hard errors

Syntax: **Trace.FLOW.ERRORS()**

Returns the number of flow errors and hard errors found while processing the trace recording.

Return Value Type: [Decimal value](#).

Please be aware that the return value of this function is the accumulated count of events that were encountered while processing the trace recording. All opened windows showing trace data contribute to this value. The value is reset when a new trace recording is made, or when the [Trace.FLOWSTART](#) or [Trace.FLOWPROCESS](#) command is executed.

The use of this function is only recommended if you want to find out if a specified part of a trace recording is error free. The part to be analyzed can be defined using [Trace.STATistic.FIRST](#) and [Trace.STATistic.LAST](#). If the defined part is error free (and thus this function returns zero), the analysis results are reliable as well.

Example 1: This script shows how to return only the number of flow errors and hard errors in the trace that is currently visible within the [Trace.List](#) window. If you now start scrolling up or down in the [Trace.List](#) window or increase the window size, more trace data will be decoded, and thus the number of errors returned by the function may increase.

```
Trace.List

PRINT Trace.FLOW.ERRORS()

; scroll up or down in the window

PRINT Trace.FLOW.ERRORS()
```

Example 2: This script shows how to obtain the exact number of flow errors in the whole trace recording.

```
Trace.Find FLOWERROR /ALL  
PRINT FOUND.COUNT()
```

Trace.FLOW.FIFOFULL()

Get number of FIFO overflows

Syntax: **Trace.FLOW.FIFOFULL()**

Returns the number of **FIFO overflows** found while processing the trace recording.

Return Value Type: [Decimal value](#).

Please be aware that the return value of this function is the accumulated count of events that were encountered while processing the trace recording. All opened windows showing trace data contribute to this value. The value is reset when a new trace recording is made, or when the [Trace.FLOWSTART](#) or [Trace.FLOWPROCESS](#) command is executed.

The use of this function is only recommended if you want to find out if a specified part of a trace recording is error free. The part to be analyzed can be defined using [Trace.STATistic.FIRST](#) and [Trace.STATistic.LAST](#). If the defined part is error free (and thus this function returns zero), the analysis results are reliable as well.

The example below shows how to obtain the exact number of flow errors in the whole trace recording.

```
Trace.Find FIFOFULL /ALL  
PRINT FOUND.COUNT()
```

Trace.MAXSIZE()

Get max. size of trace buffer in records

[build 38323 - DVD 08/2012] [[Go to figure](#)]

Syntax: **Trace.MAXSIZE()**

Returns the maximum possible number of records.

Return Value Type: [Decimal value](#).

Syntax: **Trace.METHOD()**

Returns the long form of the currently configured trace method.

Return Value Type: [String](#).

Trace.METHOD.Analyzer()

TRUE if the trace method is Analyzer

[\[Go to figure\]](#)

Syntax: **Trace.METHOD.Analyzer()**

Returns TRUE if the trace method is Analyzer.

The trace method is set with the command [Trace.METHOD.Analyzer](#).

Return Value Type: [Boolean](#).

Trace.METHOD.ART()

TRUE if the trace method is ART

[\[Go to figure\]](#)

Syntax: **Trace.METHOD.ART()**

Returns TRUE if the trace method is ART.

The trace method is set with the command [Trace.METHOD.ART](#).

Return Value Type: [Boolean](#).

Trace.METHOD.CAnalyzer()

TRUE if the trace method is CAnalyzer

[\[Go to figure\]](#)

Syntax: **Trace.METHOD.CAnalyzer()**

Returns TRUE if the trace method is CAnalyzer (CombiProbe).

The trace method is set with the command [Trace.METHOD.CAnalyzer](#).

Return Value Type: [Boolean](#).

Trace.METHOD.FDX()

TRUE if the trace method is FDX

[\[Go to figure\]](#)

Syntax: **Trace.METHOD.FDX()**

Returns TRUE if the trace method is FDX.

The trace method is set with the command [Trace.METHOD.FDX](#).

Return Value Type: [Boolean](#).

Trace.METHOD.HAnalyzer()

TRUE if the trace method is HAnalyzer

Syntax: **Trace.METHOD.HAnalyzer()**

Returns TRUE if the trace method is HAnalyzer (Trace-over-USB).

The trace method is set with the command [Trace.METHOD.HAnalyzer](#).

Return Value Type: [Boolean](#).

Trace.METHOD.Integrator()

TRUE if the trace method uses the Integrator

[\[Go to figure\]](#)

Syntax: **Trace.METHOD.Integrator()**

Returns TRUE if the trace method uses the Integrator hardware analyzer.

The trace method is set with the command [Trace.METHOD.Integrator](#).

Return Value Type: [Boolean](#).

Trace.METHOD.IProbe()

TRUE if the trace method uses the IProbe

[build 60615 - DVD 02/2015] [\[Go to figure\]](#)

Syntax: **Trace.METHOD.IProbe()**

Returns TRUE if the trace method uses the IProbe of PowerTrace II / PowerTrace III hardware analyzer.

The trace method is set with the command [Trace.METHOD.IProbe](#).

Return Value Type: [Boolean](#).

Syntax:Trace.METHOD.LA()

Returns TRUE if the trace method is LA.

The trace method is set with the command **Trace.METHOD.LA**.

Return Value Type: [Boolean](#).

Syntax:Trace.METHOD.LOGGER()

Returns TRUE if the trace method is LOGGER.

The trace method is set with the command **Trace.METHOD.LOGGER**.

Return Value Type: [Boolean](#).

Syntax:Trace.METHOD.ONCHIP()

Returns TRUE if the trace method is ONCHIP.

The trace method is set with the command **Trace.METHOD.Onchip**.

Return Value Type: [Boolean](#).

Syntax:Trace.METHOD.Probe()

Returns TRUE if the trace method uses the PowerProbe hardware analyzer.

Return Value Type: [Boolean](#).

Syntax: **Trace.METHOD.SNOOPer()**

Returns TRUE if the trace method is SNOOPer.

The trace method is set with the command **Trace.METHOD.SNOOPer**.

Return Value Type: [Boolean](#).

Syntax: **Trace.RECORD.ADDRESS(<record_number>)**

Returns the sampled address (access class and offset) from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Address](#).

Syntax: **Trace.RECORD.DATA(<record_number>)**

Returns the sampled data of the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Syntax: **Trace.RECORD.OFFSET(<record_number>)**

Returns the address-offset of the sampled address from the specified record.

Parameter Type: [Decimal value](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT Trace.RECORD.OFFSET(-000009.)
```

Syntax: **Trace.RECORD.TIME(<record_number>)**

Returns the timestamp of the specified record. For an example, see [Analyzer.RECORD.TIME\(\)](#).

Parameter Type: [Decimal value](#).

Return Value Type: [Time value](#).

Syntax: **Trace.RECORDS()**

Returns the number of records currently recorded in the trace buffer.

If the state is **OFF** and the current mode is **STREAM**, this function will block until all buffered data has been received.

Return Value Type: [Decimal value](#).

Syntax:

Trace.SIZE()

Returns the currently defined size of the trace buffer to be used for recording in records.

Return Value Type: [Decimal value](#).

Syntax:

Trace.STATE()

Returns the state of the PowerTrace hardware.

If the state is **OFF** and the current mode is **STREAM**, this function will block until all buffered data has been received.

Return Value Type: [Hex value](#).

Return Value and Description:

0	OFF state
1	Arm state
2	break state
3	trigger state
4	DISable state
8	SPY state
9	OFF state, but data is still being processed (PIPE and RTS modes only)

Syntax: **Trace.STATistic.COUNT(<address>)**

Returns the number of occurrences of the selected function in the trace statistic results.

Return Value Type: [Decimal value](#).

Syntax: **Trace.STATistic.EXIST(<address>)**

Returns TRUE if the selected function exists in the trace statistic results.

Return Value Type: [Boolean](#).

Syntax: **Trace.STATistic.FIRST()**

Returns the number of the record set by [Trace.STATistic.FIRST](#) command. If this is not the case, it returns the first record number in the trace.

Return Value Type: [Decimal value](#).

Syntax: **Trace.STATistic.IMAX(<address>)**

Returns the longest time between function entry and exit without called sub-functions.

Return Value Type: [Time value](#).

Syntax: **Trace.STATistic.IMIN(<address>)**

Returns the shortest time between function entry and exit without called sub-functions.

Return Value Type: [Time value](#).

Trace.STATistic.Internal()

Time spent within the selected function

[build 121928 - DVD 09/2020]

Syntax: **Trace.STATistic.Internal(<address>)**

Returns the time spent within the selected function in the trace statistic results.

Return Value Type: [Time value](#).

Trace.STATistic.LAST()

Record number of end point for statistic analysis

[build 169552 - DVD 09/2024]

Syntax: **Trace.STATistic.LAST()**

Returns the number of the record set by [Trace.STATistic.LAST](#) command. If this is not the case, it returns the last record number in the trace.

Return Value Type: [Decimal value](#).

Trace.STATistic.MAX()

Maximum time of selected function

[build 121928 - DVD 09/2020]

Syntax: **Trace.STATistic.MAX(<address>)**

Returns the longest measured time it took to execute the function.

Return Value Type: [Time value](#).

Syntax: **Trace.STATistic.MIN(<address>)**

Returns the shortest measured time it took to execute the function.

Return Value Type: [Time value](#).

Syntax: **Trace.STATistic.Total(<address>)**

Returns the total time within the selected function in the trace statistic results.

Return Value Type: [Time value](#).

Syntax: **Trace.TraceCONNECT()**

Returns the name of the currently selected trace sink of the SoC. In case no trace-sink is selected/available, the function returns **NONE**. The trace sink is selected with the [<trace>.TraceCONNECT](#) command.

Return Value Type: [String](#).

Example: See [Onchip.TraceCONNECT\(\)](#).

In This Section

See also

- [TRACEPORT](#)
- [TRACEPORT.LaneCount\(\)](#)

TRACEPORT.LaneCount()

Number of serial lanes

[build 104159 - DVD 02/2019]

Syntax:

TRACEPORT.LaneCount(<index>)

<index>:

1. ... <n>


Returns the number of serial lanes for the specified traceport <index>.

Parameter Type: [Decimal value](#).

Return Value Type: [Decimal value](#).

Example 1:

```
TRACEPORT.state                                ;optional step: open window for
                                                ;traceport 1. (= <index>)
ECHO TRACEPORT.LaneCount (1.)                 ;returns 3., see screenshot below
```



Example 2:

```
TRACEPORT2.state                              ;optional step: open window for
                                                ;traceport 2. (= <index>)
ECHO TRACEPORT.LaneCount (2.)
```

In This Section

See also

- ▢ [TRACK.ADDRESS\(\)](#)
- ▢ [TRACK.COLUMN\(\)](#)
- ▢ [TRACK.LINE\(\)](#)
- ▢ [TRACK.RECORD\(\)](#)
- ▢ [TRACK.STRING\(\)](#)
- ▢ [TRACK.TIME\(\)](#)

TRACK.ADDRESS()

Get tracking address

Syntax:

TRACK.ADDRESS()

Returns the tracking address e.g. after search or memory test commands, such as [Data.Find](#) or [Data.Test](#).

Return Value Type: [Address](#).

Example:

```
Data.Find flags++0xFF 0x01
IF FOUND()==TRUE()
(
    Data.Set    TRACK.ADDRESS() 0xAA
    Data.Print TRACK.ADDRESS()
)
```

TRACK.COLUMN()

Number of column where the found item starts

Syntax:

TRACK.COLUMN()

After a successful search operation, this function returns the column number.

Return Value Type: [Decimal value](#).

TRACK.LINE()

Number of line containing the found item

Syntax:

TRACK.LINE()

After a successful search operation, this function returns the line number.

Return Value Type: [Decimal value](#).

Example: The function **TRACK.LINE()** is used to automatically scroll to the required line number in the **TYPE** window, where the search string was found.

```
LOCAL &file &line
&file="~/demo/arm/compiler/gnu/src/sieve.c"

FIND &file , "main("      ;search for the string "main(" in whole file
&line=TRACK.LINE()      ;return the line number of the first occurrence

IF FOUND()==TRUE()        ;if found, open file in TYPE window and
(                          ;scroll to the &line where the string was found
    TYPE &file &line /LineNumbers
)
```

See also: [FIND](#) and [ComPare](#).

Syntax: **TRACK.RECORD()**

After a successful search operation, this function returns the record number. For an example, see [Analyzer.TRACK.RECORD\(\)](#).

Return Value Type: [Decimal value](#).

Syntax: **TRACK.STRING()**
SELECTION.STRING() (deprecated)


Returns a single-line or multi-line selection made by a user in a TRACE32 window. For information about how to return values and selections from user-defined dialogs, see [DIALOG Functions](#).

Return Value Type: [String](#).

Syntax:

TRACK.TIME()

Returns the timestamp of the current tracking record in relation to the zero-time reference point.



Return Value Type: Time value.


Example:

```
;set the zero-time reference point to record no. -12000.
ZERO.offset Trace.RECORD.TIME(-12000.)

;set the tracking record to the record -10000.
Trace.TRACK -10000.

PRINT "TRACK.TIME() result: " %COLOR.MAROON TRACK.TIME() ;see [A] below

;display the result in the trace listing with the ti.zero column as the
;first column followed by all DEfault columns
Trace.List %TimeFixed Time.Zero DEfault /Track
```



In This Section

See also

- [TRANSlation](#)
 - ❑ [TRANS.INTERMEDIATE\(\)](#)
 - ❑ [TRANS.INTERMEDIATEEX\(\)](#)
 - ❑ [TRANS.LINEAR\(\)](#)
 - ❑ [TRANS.LINEAREX\(\)](#)
 - ❑ [TRANS.LIST.LOGRANGE\(\)](#)
 - ❑ [TRANS.LIST.PHYSADDR\(\)](#)
 - ❑ [TRANS.LOGICAL\(\)](#)
 - ❑ [TRANS.PHYSICAL\(\)](#)
 - ❑ [TRANS.PHYSICALEX\(\)](#)
 - ❑ [TRANS.TABLEWALK\(\)](#)
- ❑ [TRANS.ENABLE\(\)](#)
 - ❑ [TRANS.INTERMEDIATE.VALID\(\)](#)
 - ❑ [TRANS.INTERMEDIATEEX.VALID\(\)](#)
 - ❑ [TRANS.LINEAR.VALID\(\)](#)
 - ❑ [TRANS.LINEAREX.VALID\(\)](#)
 - ❑ [TRANS.LIST.NUMBER\(\)](#)
 - ❑ [TRANS.LIST.TYPE\(\)](#)
 - ❑ [TRANS.LOGICAL.VALID\(\)](#)
 - ❑ [TRANS.PHYSICAL.VALID\(\)](#)
 - ❑ [TRANS.PHYSICALEX.VALID\(\)](#)

TRANS.LIST.NUMBER()

Number of TRANS.List entries

Syntax 1:	TRANS.LIST.NUMBER()
Syntax 2:	TRANS.LIST.NUMBER.ZONE(<address>)
<address>:	<access_class>:[<machine_id>:::]0x0

Both functions return the number of entries in the [TRANSlation.List](#) window.

- Syntax 1:** The queried entry is located in the currently active zone of the core.
- Syntax 2:** The queried entry is located in the [zone](#) that is selected with <address>.

Return Value Type: [Decimal value](#).

The type of entries in the **TRANSlation.List** window which can be queried are

- static translations created with command [TRANSlation.Create](#) or [MMU.Scan](#)
- protected address ranges created with command [TRANSlation.Protect](#)
- transparent entries created with command [TRANSlation.TRANSPARENT](#)
- common ranges created with command [TRANSlation.COMMON](#) or [TRANSlation.COMMON.ADD](#)

Note that default translations created with command [MMU.FORMAT](#) and displayed in the first lines of the **TRANSlation.List** window can not be queried with this set of functions. Use function [MMU.DEFAULTTRANS.<range>](#) to query default translations.

Parameter and Description:

<access_class>	Mandatory if SYStem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Mandatory if SYStem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

TRANS.LIST.LOGRANGE()

Query TRANS.List entry

Syntax 1:	TRANS.LIST.LOGRANGE (<entry_index>)
Syntax 2:	TRANS.LIST.LOGRANGE.ZONE (<entry_index>, <address>)
<address>:	<access_class>:[<machine_id>:::]0x0

Both functions return the logical address range of entry <entry_index> in the in the **TRANSlation.List** window.

- Syntax 1:** The queried entry is located in the currently active zone of the core.
- Syntax 2:** The queried entry is located in the **zone** that is selected with <address>.

Return Value Type: [Address.range](#)

Note: an address offset of 0xFFFFFFFF (for 32-bit architectures) or 0xFFFFFFFFFFFFFFFF (for 64-bit architectures) is returned if <entry_index> does not select any existing entry.

Parameter and Description:

<entry_index>	the index of the queried entry. Positive numbers query the entries in the TRANSlation.List window, starting with 0 for the first entry in the window. Negative numbers query entries in a reverse sequence, starting with the last entry.
<access_class>	Mandatory if SYStem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Mandatory if SYStem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

Example - Syntax 2:

```
;optional step: list all translation entries
TRANSlation.list

; display the logical address range of the first entry in the
TRANSlation.List window
PRINT TRANS.LIST.LOGRANGE(0)

; display the logical address range of the second entry in the
TRANSlation.List window for machine '2:::' in the nonsecure zone 'N'
PRINT TRANS.LIST.LOGRANGE.ZONE(1, N:2:::0)

; display the logical address range of the last entry in the
TRANSlation.List window
PRINT TRANS.LIST.LOGRANGE(-1)

; display the logical address range of the second last entry in the
TRANSlation.List window
PRINT TRANS.LIST.LOGRANGE(-2)
```

TRANS.LIST.PHYSADDR()

Query TRANS.List entry

Syntax 1:	TRANS.LIST.PHYSADDR(<entry_index>)
Syntax 2:	TRANS.LIST.PHYSADDR.ZONE(<entry_index>, <address>)
<address>:	<access_class>:[<machine_id>:::]0x0

Both functions return the physical base address of entry <entry_index> in the in the **TRANSlation.List** window.

- Syntax 1:** The queried entry is located in the currently active zone of the core.
- Syntax 2:** The queried entry is located in the **zone** that is selected with <address>.

Return Value Type: **Address**.

Note: an address offset of 0xFFFFFFFF (for 32-bit architectures) or 0xFFFFFFFFFFFFFFFF (for 64-bit architectures) is returned if <entry_index> does not select any existing entry.

Parameter and Description:

<entry_index>	the index of the queried entry. Positive numbers query the entries in the TRANSLation.List window, starting with 0 for the first entry in the window. Negative numbers query entries in a reverse sequence, starting with the last entry.
<access_class>	Mandatory if SYStem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Mandatory if SYStem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

TRANS.LIST.TYPE()

Query TRANS.List entry

Syntax 1:	TRANS.LIST.TYPE (<entry_index>)
Syntax 2:	TRANS.LIST.TYPE.ZONE (<entry_index>, <address>)
<address>:	<access_class>[:<machine_id>:::]0x0

Both functions return one of the follow strings, indicating the type of entry <entry_index> in the in the **TRANSLation.List** window:

TRANSLATION	the queried entry is a translation entry created with command TRANSLation.Create or MMU.Scan
TRANSPARENT	the queried entry is a transparent entry created with command TRANSLation.TRANSPARENT
PROTECTED	the queried entry is a protected entry created with command TRANSLation.Protect
COMMON	the queried entry is a common address range created with command TRANSLation.COMMON or TRANSLation.COMMON.ADD
empty string	<entry_index> does not select a valid entry

Syntax 1: The queried entry is located in the currently active zone of the core.
Syntax 2: The queried entry is located in the **zone** that is selected with <address>.

Return Value Type: **String**.

Parameter and Description:

<entry_index>	the index of the queried entry. Positive numbers query the entries in the TRANSLation.List window, starting with 0 for the first entry in the window. Negative numbers query entries in a reverse sequence, starting with the last entry.
<access_class>	Mandatory if SYStem.Option.ZoneSPACES is ON . See access class in the glossary.pdf.
<machine_id>	Mandatory if SYStem.Option.MACHINESPACES is ON . See machine ID in the glossary.pdf.
0x0	Fixed <address> suffix.

TRANS.ENABLE()

TRUE if address translation is enabled

Syntax:

TRANS.ENABLE()

Returns TRUE if the address translation of the debugger is enabled with the command **TRANSLation.ON**.

Return Value Type: **Boolean**.

TRANS.INTERMEDIATE()

Convert a guest logical address

ARM and Intel®

Syntax 1:

TRANS.INTERMEDIATE(<address>)
MMU.INTERMEDIATE(<address>) (alias)

Syntax 2:

TRANS.INTERMEDIATEEX(<address>)
MMU.INTERMEDIATEEX(<address>) (alias)

Converts a guest logical address to an intermediate address if the stage 2 address translation (for ARM targets) or Extended Physical Translation (for Intel® targets) is enabled.

TRANS.INTERMEDIATE() behaves like **TRANS.PHYSICAL()** and converts <address> to a physical address if:

- <address> is not a *guest* logical address
- or the stage 2 translation / Extended Physical Translation in the target MMU is not available or disabled.

Syntax 1: No access class expansion of `<address>` is done prior to the translation. Tries to translate `<address>` as it is. Use this syntax to do a translation only. The result is independent of the current CPU mode.

Syntax 2: The access class of `<address>` is expanded prior to the translation, missing information is added from the current PC's access class. Use this syntax to get the same translation result as a standard access to the target. The translation result may depend on the current CPU mode.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

TRANS.INTERMEDIATE.VALID()

TRUE if address translation is valid

ARM and Intel®

Syntax 1:	TRANS.INTERMEDIATE.VALID(<address>) MMU.INTERMEDIATE.VALID(<address>) (alias)
Syntax 2:	TRANS.INTERMEDIATEEX.VALID(<address>) MMU.INTERMEDIATEEX.VALID(<address>) (alias)

Checks whether a valid guest logical-to-intermediate address translation exists for the specified address.

Syntax 1: No access class expansion of `<address>` is done prior to the translation.

Syntax 2: The access class of `<address>` is expanded prior to the translation, missing information is added from the current PC's access class.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

TRANS.LINEAR()

Convert logical to linear address

Intel®

Syntax 1:	TRANS.LINEAR(<address>) MMU.LINEAR(<address>) (alias)
Syntax 2:	TRANS.LINEAREX(<address>) MMU.LINEAREX(<address>) (alias)

Converts a logical address to a linear address.

Syntax 1: No access class expansion of `<address>` is done prior to the translation. Tries to translate `<address>` as it is. Use this syntax to do a translation only. The result is independent of the current CPU mode.

Syntax 2: The access class of *<address>* is expanded prior to the translation, missing information is added from the current PC's access class. Use this syntax to get the same translation result as a standard access to the target. The translation result may depend on the current CPU mode.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

TRANS.LINEAR.VALID()

TRUE if address translation is valid

Intel®

Syntax 1:	TRANS.LINEAR.VALID (<i><address></i>) MMU.LINEAR.VALID (<i><address></i>) (alias)
Syntax 2:	TRANS.LINEAREX.VALID (<i><address></i>) MMU.LINEAREX.VALID (<i><address></i>) (alias)

Checks whether a valid logical-to-linear address translation exists for the specified address.

Syntax 1: No access class expansion of *<address>* is done prior to the translation.

Syntax 2: The access class of *<address>* is expanded prior to the translation, missing information is added from the current PC's access class.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

TRANS.LOGICAL()

Convert physical to logical address

Syntax:	TRANS.LOGICAL (<i><physical_address></i>) MMU.LOGICAL (<i><physical_address></i>) (alias)
---------	--

Converts a physical address to a logical address using the TRACE32 static translation table. No access class expansion is done prior to the translation. This function tries to translate *<address>* as it is. The result is independent of the current CPU mode.

Use the command **TRANSLation.List** to view the static translation table.
If the static translation table contains more than one valid entry matching the specified *<physical_address>*, then the first entry will be used for the address conversion.

NOTE:

- **TRANS.LOGICAL**(*<physical_address>*) does not search in page tables.
- If you want to search through the entries of a page table, you must first use the command **MMU.SCAN** to read the contents of the page table into the static translation table.
- If you want to search through the entries of a page table, you can also use the command **MMU.INFO** *<physical_address>* to search the system page tables for entries that yield *<physical_address>*.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

TRANS.LOGICAL.VALID()

TRUE if address translation is valid

Syntax:

TRANS.LOGICAL.VALID(*<physical_address>*)
MMU.LOGICAL.VALID(*<physical_address>*) (alias)

Checks whether a valid physical-to-logical address translation exists for the specified physical address. Only the static translation table will be searched, no page tables. No access class expansion of *<address>* is done prior to the translation.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

TRANS.PHYSICAL()

Convert logical to physical address

Syntax 1:

TRANS.PHYSICAL(*<address>*)
MMU.PHYSICAL(*<address>*) (alias)

Syntax 2:

TRANS.PHYSICALEX(*<address>*)
MMU.PHYSICALEX(*<address>*) (alias)

Converts a logical address to a physical address.

Syntax 1: No access class expansion of *<address>* is done prior to the translation. Tries to translate *<address>* as it is. Use this syntax to do a translation only. The result is independent of the current CPU mode.

Syntax 2: The access class of `<address>` is expanded prior to the translation, missing information is added from the current PC's access class. Use this syntax to get the same translation result as a standard access to the target. The translation result may depend on the current CPU mode.

Parameter Type: [Address](#).

Return Value Type: [Address](#).

Use [ADDRESS.PHYSICAL\(\)](#) to check whether the translation was successful and the result is really a physical address.

If the translation failed, `ADDRESS.PHYSICAL(TRANS.PHYSICAL(<address>))` will return FALSE.

Example:

```
; This is an example for the ARM simulator
; It demonstrates the difference between functions
; TRANS.PHYSICAL() and TRANS.PHYSICALEX()

; Select a CPU with trust zone (nonsecure/secure mode)
SYStem.CPU CORTEXA5
AREA.View

; Let's make the static address translation zone specific so that it is
; easier to demonstrate the difference between TRANS.PHYSICAL()
; and TRANS.PHYSICALEX()
SYStem.Option.ZoneSPACES ON

SYStem.UP

Register.Set M 0x13      ; set CPU to supervisor mode
Register.Set NS 1        ; set CPU to nonsecure mode
; Now the PC's access class is NSD:

; Define a static translation for a nonsecure address range
TRANSLation.Create N:0xA0000000--0xAFFFFFFF A:0x30000000

TRANSLation.List          ; show the static translation list
TRANSLation.ON            ; enable the debugger address translation

; 1. Try to translate an address with unspecific access class
PRINT TRANS.PHYSICAL(D:0xA0005000)
;   the result is D:0xA0005000 because there is no translation
;   for D:0xA0005000 with SYStem.Option.ZoneSPACES ON
;   There is a translation for nonsecure addresses only.

; 2. Try to translate an address with unspecific access class,
;   now with access class expansion using the PC's access class
PRINT TRANS.PHYSICALEX(D:0xA0005000)
;   the result is ANSD:0x0:0x30005000 because D:0xA0005000 becomes
;   NSD:0xA0005000 after the access class is expanded

; 3. Now do the same like TRANS.PHYSICALEX(), but in two distinct steps
PRINT TRANS.PHYSICAL(ADDRESS.EXPANDACCESS(D:0xA0005000))
;   the result is A:0x30005000 again, the same as in 2.
```

TRANS.PHYSICAL.VALID()

TRUE if address translation is valid

Syntax 1:	TRANS.PHYSICAL.VALID(<address>) MMU.PHYSICAL.VALID() (alias)
Syntax 2:	TRANS.PHYSICALEX.VALID(<address>) MMU.PHYSICALEX.VALID() (alias)

Checks whether a valid logical-to-physical address translation exists for the specified address.

Syntax 1: No access class expansion of <address> is done prior to the translation.

Syntax 2: The access class of <address> is expanded prior to the translation, missing information is added from the current PC's access class.

Parameter Type: [Address](#).

Return Value Type: [Boolean](#).

TRANS.TABLEWALK()

TRUE if address translation table walk is ON

Syntax:	TRANS.TABLEWALK()
---------	-------------------

Returns TRUE if the table walk for address translation is enabled in the debugger with the command [TRANSlation.TableWalk ON](#).

Return Value Type: [Boolean](#).

TSS Function

TSS()

TSS base address

Syntax:

TSS()

Returns the TSS base address of the last loaded object file (only 80386).

Return Value Type: [Hex value](#).

In This Section

See also

- Var

❑ Var.END()

❑ Var.RANGE()

❑ Var.VALUE()
- ❑ Var.ADDRESS()

❑ Var.EXIST()

❑ Var.SIZEOF()
- ❑ Var.BITPOS()

❑ Var.FVALUE()

❑ Var.STRING()
- ❑ Var.BITSIZE()

❑ Var.ISBIT()

❑ Var.TYPEOF()

Var.ADDRESS()

Address of HLL expression

Syntax:

Var.ADDRESS(<hll_expression>)

Returns the address of the HLL expression.

Parameter Type: [String](#).

Return Value Type: [Address](#).

Example:

```
Data.Print Var.ADDRESS(flags)
Data.Print Var.ADDRESS(flags[3])
```

Var.BITPOS()

Bit position inside a C bit field

Syntax:

Var.BITPOS(<hll_expression>)

Returns the start bit position of an element inside a bit field.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT Var.BITPOS(vbfield.d)
```

Syntax: **Var.BITSIZE(<hll_expression>)**

Returns the size in bits of a bit field element.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT %Decimal Var.BITSIZE(vbfield.f)
```

Syntax: **Var.END(<hll_expression>)**

Returns the last address occupied by the HLL expression.

Parameter Type: [String](#).

Return Value Type: [Address](#).

Example:

```
Data.Print Var.END(vbfield)
```

Syntax: **Var.EXIST(<hll_expression>)**

Returns TRUE if an HLL expression is syntactically valid or if an HLL variable exists.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Example 1:

```
;your code
Data.LOAD.Elf "armle.axf" /StripPATH /LowerPATH
;your code

PRINT Var.EXIST(sieve)           ;returns TRUE
PRINT Var.EXIST(flags)          ;returns TRUE
```

Example 2: Remember that inline comments for **Var.*** commands must start with **//**.

```
PRINT Var.EXIST(\val1)           ;returns FALSE

Var.NEWLOCAL int \val1           //let's now create the TRACE32-internal
                                  ;variable \val1
PRINT Var.EXIST(\val1)           ;returns TRUE because now it exists

Var.set \val1=0x42                //initialize the TRACE32-internal variable

PRINT Var.EXIST(\val1==0x5)       ;returns TRUE because syntactically
                                  ;\val1==0x5 is a valid HLL expression
```


Syntax: **Var.FVALUE(<hll_expression>)**

Returns the contents of the HLL expression.

Parameter Type: [String](#).

Return Value Type: [Float](#).

Example:

```
PRINT Var.FVALUE(ast.float)
PRINT Var.FVALUE(i)
PRINT Var.FVALUE(ast.left->x)
```

Syntax: **Var.ISBIT(<hll_expression>)**

Returns whether the HLL expression is a bit field element or not.

Parameter Type: [String](#).

Return Value Type: [Boolean](#).

Example:

```
PRINT Var.ISBIT(vbfield.f)
PRINT Var.ISBIT(vbfield)
```

Syntax: **Var.RANGE(<hll_expression>)**

Returns the address range occupied by the HLL expression in memory.

Parameter Type: [String](#).

Return Value Type: [Address range](#).

Example:

```
PRINT Var.RANGE(flags)           ;returns the address range D:0x6EA4--0x6EB6

Data.Print Var.RANGE(flags)

Data.Find Var.RANGE(flags) 0x00
IF FOUND()
(
    Data.Set TRACK.ADDRESS() 0xBB
    Data.Print TRACK.ADDRESS()
)
ENDDO
```

Syntax: **Var.SIZEOF(<hll_expression>)**

Returns the size occupied by the HLL expression in memory.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example:

```
Data.Print flags++Var.SIZEOF(flags)

Data.Find flags++Var.SIZEOF(flags) 0x00
IF FOUND()
(
    Data.Set TRACK.ADDRESS() 0xDD
    Data.Print TRACK.ADDRESS()
)
ENDDO
```

Syntax: **Var.STRING(<hll_expression>)**

Returns a zero-terminated string, if <hll_expression> is a pointer to character or an array of characters.
Returns a string that represents the variable contents otherwise.

Parameter Type: [String](#).

Return Value Type: [String](#).

Example:

```
&enumvalue=Var.STRING(ptr->member)
PRINT "&enumvalue"
```

Var.TYPEOF()

Type of HLL expression

[build 28656 - DVD 06/2011] [\[Example\]](#)

Syntax: **Var.TYPEOF(<hll_expression>)**

Returns the type of the HLL expression. The expressions can also be TRACE32-internal variables, which are created with the commands [Var.NEWLOCAL](#) and [Var.NEWGLOBAL](#).

Parameter Type: [String](#).

Return Value Type: [String](#).

Example:

```
;Create some TRACE32-internal variables, integer \val1 and
;character array \myStr, on the local PRACTICE stack frame
;Use the backslash for TRACE32-internal variables: '\val1', '\myStr'
Var.NEWLOCAL int \val1
Var.NEWLOCAL char[6][20] \myStr

//see Var.NEWLOCAL command for information about the local PRACTICE
//stack frame and on how to initialize TRACE32-internal variables

;Returns the type of the TRACE32-internal variables as a string
PRINT Var.TYPEOF(\val1) ;Returns in this case: "int"
PRINT Var.TYPEOF(\myStr) ;Returns in this case: "char [6][20]"

;Returns the type of the HLL expression as a string
;Omit the backslash for HLL expressions, here for 'flags'
PRINT Var.TYPEOF(flags) ;Returns in this case: "unsigned char [19]"
```

Syntax: **Var.VALUE(<hll_expression>)**

Returns the contents of the HLL expression.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT Var.VALUE(ast.field1)
PRINT Var.VALUE(i)
PRINT Var.VALUE(ast.left->count)
PRINT %Decimal Var.VALUE(func5(7,8,9))
```

VCO Function

VCO()	Frequency of VCO generator
-------	----------------------------


Syntax:	VCO()
---------	-------

Returns the set frequency of the VCO generator.

Return Value Type: [Decimal value](#).

VERSION Functions

This figure provides an overview of the return values of some of the **VERSION** functions. For descriptions of the illustrated functions and the functions not shown here, see below.



For more information, see also:

- [“Appendix - About the TRACE32 Software Version Numbers”](#) (ide_user.pdf)
- [“LICENSE Functions”](#) (ide_func.pdf)

In This Section

See also

- | | |
|---|--|
| ■ VERSION | □ VERSION.BUILD() |
| □ VERSION.BUILD.BASE() | □ VERSION.CABLE() |
| □ VERSION.DATE() | □ VERSION.ENVironment() |
| □ VERSION.FirmWare.DEBUG() | □ VERSION.SERIAL() |
| □ VERSION.SERIAL.CABLE() | □ VERSION.SERIAL.DEBUG() |
| □ VERSION.SERIAL.Integrator() | □ VERSION.SERIAL.NEXUSadapter() |
| □ VERSION.SERIAL.POWERPROBE() | □ VERSION.SERIAL.POWERTRACEAUXPORT() |
| □ VERSION.SERIAL.PREPROCESSOR() | □ VERSION.SERIAL.SerialPort1() |
| □ VERSION.SERIAL.TRACE() | □ VERSION.SERIAL.WHISKER() |
| □ VERSION.SOFTWARE() | □ VERSION.SOFTWARE.TYPE() |

Syntax: **VERSION.BUILD()**

Returns the upper build number of TRACE32, e.g. **28724**. Alias for **SOFTWARE.BUILD()**.
The same version information is displayed in the **VERSION.SOFTWARE** window.

The **VERSION.BUILD()** number is greater than the **VERSION.BUILD.BASE()** number if the TRACE32 executable is a build from a branch with some changes (e.g. in the case of a release branch after a feature freeze with included bug-fixes).

The **VERSION.BUILD()** number equals the **VERSION.BUILD.BASE()** number if the TRACE32 executable is a snapshot build *from the development branch*. A snapshot build is also referred to as an interim build.

Return Value Type: [Decimal value](#).

Syntax: **VERSION.BUILD.BASE()**

Returns the lower build number of TRACE32, e.g. **26464**. Alias for **SOFTWARE.BUILD.BASE()**.

Return Value Type: [Decimal value](#).

Syntax:

VERSION.CABLE()

Returns the hardware version of the debug cable.

Return Value Type: [Decimal value](#).

Syntax:

VERSION.DATE()

Returns the date of the main software in the form YYYY/MM. e.g. "2016/07"

Return Value Type: [String](#).

Syntax:

VERSION.ENVironment(<name>)

Returns a single TRACE32 environment setting as shown in the [VERSION.ENVironment](#) window.

Parameter and Description:

<name>	Parameter Type: String . Specify the environment setting by name.
--------	---

Return Value Type: [String](#).

Example:


```
;returns the path of the used TRACE32 config file
PRINT VERSION.ENVironment(CONFIG)

;returns the version number of the used QT-Library
PRINT VERSION.ENVironment(QT)
```


Syntax:

VERSION.FirmWare.DEBUG()

Returns the version number of the firmware of a PowerDebug or PowerTrace module - if the module is the first Podbus device. Otherwise it returns zero.



Return Value Type: [Float](#).

Syntax:

VERSION.SERIAL()

Returns the serial number of the system.

Return Value Type: [String](#).

Syntax:

VERSION.SERIAL.CABLE()

Returns the first serial number of the plugged debug cable. It is the same value that is also shown in the [VERSION.HARDWARE](#) window. To return all serial numbers, use [LICENSE.SERIAL\(\)](#).

Return Value Type: [String](#).

Syntax:VERSION.SERIAL.DEBUG()

Returns the serial number of the debug module. It is the same value that is also shown in the [VERSION.HARDWARE](#) window.

Return Value Type: [String](#).

Syntax:VERSION.SERIAL.Integrator()

Returns the serial number of the PowerIntegrator or PowerIntegrator-II. It is the same value that is also shown in the [VERSION.HARDWARE](#) window.

Return Value Type: [String](#).

Syntax:VERSION.SERIAL.NEXUSadapter()

Returns the serial number of the nexus adapter or preprocessor. It is the same value that is also shown in the [VERSION.HARDWARE](#) window.

Return Value Type: [String](#).

Syntax:VERSION.SERIAL.PREPROcessor()

Returns the serial number of the preprocessor. It is the same value that is also shown in the [VERSION.HARDWARE](#) window.

Return Value Type: [String](#).

Syntax: **VERSION.SERIAL.POWERPROBE()**

Returns the serial number of the PowerProbe. It is the same value that is also shown in the **VERSION.HARDWARE** window.

Return Value Type: [String](#).

VERSION.SERIAL.POWERTRACEAUXPORT() S/N of device at PT aux port

[build 133662 - DVD 02/2021]

Syntax: **VERSION.SERIAL.POWERTRACEAUXPORT()**

Returns the serial number of the Lauterbach device plugged to the AUX PORT of a PowerTrace. It is the same value that is also shown in the **VERSION.HARDWARE** window.

Return Value Type: [String](#).

VERSION.SERIAL.SerialPort1() S/N of device at Serial Port 1 of PT Serial

[build 156822 - DVD 02/2023]

Syntax: **VERSION.SERIAL.SerialPort1()**

Returns the serial number of the Lauterbach device (adapter or preprocessor) plugged to the Serial Port 1 of a PowerTrace Serial.

Return Value Type: [String](#).

VERSION.SERIAL.WHISKER() S/N of whiskers at CombiProbe or µTrace

[build 133662 - DVD 02/2021]

Syntax: **VERSION.SERIAL.WHISKER(<int>)**

Returns the serial number of the whisker cable connected to the connector specified by <int> plugged to a CombiProbe, µTrace (MicroTrace), or QuadProbe or.

It is the same value that is also shown in the **VERSION.HARDWARE** window.

For the meaning of the <int> Parameter see command **ID.WHISKER()**.

Note, that only some whisker actually contain a serial number. For all the others, the function returns an empty string.

Return Value Type: [String](#).

Syntax: **VERSION.SERIAL.TRACE()**

Returns the serial number of the trace module. It is the same value that is also shown in the **VERSION.HARDWARE** window.

Return Value Type: [String](#).

Syntax: **VERSION.SOFTWARE()**

Returns the version of the main software. Alias for **SOFTWARE.VERSION()**.

Return Value Type: [String](#).

Return Value Format: *<type>.<year>.<month>.<build_number>* where the building block *<type>* can be one of the following:

- **R:** release build
- **P:** pre-release build
- **N:** nightly build
- **S:** interim build ("snapshot")
- **F:** feature build

For more information about the *<type>* building blocks, see [“Appendix - About the TRACE32 Software Version Numbers”](#) in PowerView User’s Guide, page 129 (ide_user.pdf).

Examples:

```
PRINT VERSION.SOFTWARE() ;print the software version
```

```
;check whether the TRACE32 software being used matches a certain release
IF VERSION.SOFTWARE() != "R.2010.07.000024615"
    PRINT "wrong TRACE32 SW started"
```

Syntax: **VERSION.SOFTWARE.TYPE()**

Returns the version type of the main software.

Return Value Type: [String](#).

Return Value Format: *<type>* :

- **R:** release build
- **P:** pre-release build
- **N:** nightly build
- **S:** interim build ("snapshot")
- **F:** feature build

For more information about the *<type>* building blocks, see [“Appendix - About the TRACE32 Software Version Numbers”](#) in PowerView User’s Guide, page 129 (ide_user.pdf).

Examples:

```
PRINT VERSION.SOFTWARE.TYPE()           ;print the software version type
```

```
;check whether the TRACE32 software being used is not a release version
IF VERSION.SOFTWARE.TYPE() != "R"
    PRINT "wrong TRACE32 SW started"
```

In This Section

See also

- [VPU](#)
- [VPU\(\)](#)
- [VPUCR\(\)](#)

VPU()

Value of VPU register

Syntax: **VPU(<register_name>.W0 .. .W3)**

Returns the content of the selected VPU register.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT VPU (VR2.W3)      ;returns word 3 of register VR2
```

VPUCR()

Value of VRSAVE or VSCR register

Syntax: **VPUCR(<register>)**

<register>: **VRSAVE | VSCR**

Returns the content of the registers **VRSAVE** or **VSCR**.

Parameter Type: [String](#).

Return Value Type: [Hex value](#).

Example:

```
PRINT VPUCR (VRSAVE)    ;returns the content of register VRSAVE
```