

OS Awareness Manual QXK

MANUAL

OS Awareness Manual QXK


[TRACE32 Online Help](#)

[TRACE32 Directory](#)

[TRACE32 Index](#)

TRACE32 Documents	
OS Awareness Manuals	
OS Awareness Manual QXK	1
 Overview	3
Brief Overview of Documents for New Users	3
Supported Versions	4
 Configuration	5
Quick Configuration Guide	6
Hooks & Internals in QXK	6
 Features	7
Display of Kernel Resources	7
Task Stack Coverage	7
Task-Related Breakpoints	8
Task Context Display	9
Dynamic Task Performance Measurement	10
Task Runtime Statistics	10
Function Runtime Statistics	11
QXK specific Menu	13
 QXK Commands	14
TASK.ActiveObj	Display active objects
TASK.EXITTHRRead	Display extended threads
TASK.MuTeX	Display mutexes
TASK.SEMaphore	Display semaphores
TASK.MEMPool	Display memory pools
 QXK PRACTICE Functions	17
TASK.CONFIG()	OS Awareness configuration information

Overview



The OS Awareness for QXK contains special extensions to the TRACE32 Debugger. This manual describes the additional features, such as additional commands and statistic evaluations.

Brief Overview of Documents for New Users

Architecture-independent information:

- “[Training Basic Debugging](#)” (training_debugger.pdf): Get familiar with the basic features of a TRACE32 debugger.
- “[T32Start](#)” (app_t32start.pdf): T32Start assists you in starting TRACE32 PowerView instances for different configurations of the debugger. T32Start is only available for Windows.
- “[General Commands](#)” (general_ref_<x>.pdf): Alphabetic list of debug commands.

Architecture-specific information:

- “**Processor Architecture Manuals**”: These manuals describe commands that are specific for the processor architecture supported by your Debug Cable. To access the manual for your processor architecture, proceed as follows:
 - Choose **Help** menu > **Processor Architecture Manual**.
- “**OS Awareness Manuals**” (rtos_<os>.pdf): TRACE32 PowerView can be extended for operating system-aware debugging. The appropriate OS Awareness manual informs you how to enable the OS-aware debugging.

Supported Versions

Currently QXK is supported for the following versions:

- v5.7.2 to v6.0.2 on ARM Cortex-M.

Configuration

The **TASK.CONFIG** command loads a definition file called “qzk.t32” (directory “`~/demo/arm/kernel/qzk`”) which contains all necessary extensions.

Automatic configuration tries to locate the QXK internals automatically. For this purpose all symbol tables must be loaded and accessible at any time the OS Awareness is used.

For system resource display and trace functionality, you can do an automatic configuration of the OS Awareness. For this purpose it is necessary that all system internal symbols are loaded and accessible at any time the OS Awareness is used. Each of the **TASK.CONFIG** arguments can be substituted by '0', which means that this argument will be searched and configured automatically. For a fully automatic configuration omit all arguments:

TASK.CONFIG qzk.t32

To get a quick access to the features of the OS Awareness for QXK with your application, follow these steps:

1. Start the TRACE32.
2. Load your application as usual.
3. Load the QXK awareness:

```
TASK.CONFIG ~~/demo/arm/kernel/qxk/qxk.t32
```

4. Load the QXK menu:

```
MENU.ReProgram ~~/demo/arm/kernel/qxk/qxk.men
```

See “[QXK Specific Menu](#)”.

Now you can access the QXK extensions through the menu.

Hooks & Internals in QXK

No hooks are used in the kernel.

For retrieving the kernel data structures, the OS Awareness uses the global kernel symbols and structure definitions. Ensure that access to those structures is possible every time when features of the OS Awareness are used.

The OS Awareness for QXK supports the following features.

Display of Kernel Resources

The extension defines new commands to display various kernel resources. Information on the following QXK components can be displayed:

TASK.ActiveObj	Active objects
TASK.EXTTHRead	Extended threads
TASK.MuTeX	Mutexes
TASK.SEMaphore	Semaphores
TASK.MEMPool	Memory pools

For a detailed description of each command, refer to chapter “[QXK Commands](#)”.

When working with emulation memory or shadow memory, these resources can be displayed “On The Fly”, i.e. while the target application is running, without any intrusion to the application. If using this dual port memory feature, be sure that emulation memory is mapped to all places where QXK holds its tables.

When working only with target memory, the information will only be displayed if the target application is stopped.

Task Stack Coverage

For stack usage coverage of tasks, you can use the **TASK.STack** command. Without any parameter, this command will open a window displaying with all active tasks. If you specify only a task magic number as parameter, the stack area of this task will be automatically calculated.

To use the calculation of the maximum stack usage, a stack pattern must be defined with the command **TASK.STack.PATtern** (default value is zero).

To add/remove one task to/from the task stack coverage, you can either call the **TASK.STack.ADD** or **TASK.STack.ReMove** commands with the task magic number as the parameter, or omit the parameter and select the task from the **TASK.STack.*** window.

It is recommended to display only the tasks you are interested in because the evaluation of the used stack space is very time consuming and slows down the debugger display.

The stack start address and stack size are passed as parameters when starting the extended threads. They are not saved in QXK kernel symbols, so you have to manually specify the stack size and the stack start address in the configuration of the OS Awareness. You can use a small script to do so.

Example: This script sets the stack size of the "IDLE" task to 1024 bytes:

```
; Adapt stack characteristics of a task
; Specify the task name, e.g. the IDLE task:
&task="IDLE"

; Specify the new task size in bytes for this task, e.g. 1024 bytes:
&stacksize=0x400

; Open standard stack view and ensure a display update
TASK.STack.view
SCREEN

; Calculate task magic number and stack start address
&magic=task.magic("IDLE")
&stackstart=<value> eg. 0x200003F4

; Remove the standard stack calculation for this task
TASK.STack.ReMove &magic

; And add the custom one:
TASK.STack.ADD &magic &stackstart++(&stacksize-1)
```

Task-Related Breakpoints

Any breakpoint set in the debugger can be restricted to fire only if a specific task hits that breakpoint. This is especially useful when debugging code which is shared between several tasks. To set a task-related breakpoint, use the command:

Break.Set <address>|<range> [/<option>] /TASK <task> Set task-related breakpoint.

- Use a magic number, task ID, or task name for <task>. For information about the parameters, see ["What to know about the Task Parameters"](#) (general_ref_t.pdf).
- For a general description of the **Break.Set** command, please see its documentation.

By default, the task-related breakpoint will be implemented by a conditional breakpoint inside the debugger. This means that the target will *always* halt at that breakpoint, but the debugger immediately resumes execution if the current running task is not equal to the specified task.

NOTE:	Task-related breakpoints impact the real-time behavior of the application.
--------------	--

On some architectures, however, it is possible to set a task-related breakpoint with *on-chip* debug logic that is less intrusive. To do this, include the option **/Onchip** in the **Break.Set** command. The debugger then uses the on-chip resources to reduce the number of breaks to the minimum by pre-filtering the tasks.

For example, on ARM architectures: *If* the RTOS serves the Context ID register at task switches, and *if* the debug logic provides the Context ID comparison, you may use Context ID register for less intrusive task-related breakpoints:

Break.CONFIG.UseContextID ON	Enables the comparison to the whole Context ID register.
Break.CONFIG.MatchASID ON	Enables the comparison to the ASID part only.
TASK.List.tasks	If TASK.List.tasks provides a trace ID (traceid column), the debugger will use this ID for comparison. Without the trace ID, it uses the magic number (magic column) for comparison.

When single stepping, the debugger halts at the next instruction, regardless of which task hits this breakpoint. When debugging shared code, stepping over an OS function may cause a task switch and coming back to the same place - but with a different task. If you want to restrict debugging to the current task, you can set up the debugger with **SETUP.StepWithinTask ON** to use task-related breakpoints for single stepping. In this case, single stepping will always stay within the current task. Other tasks using the same code will not be halted on these breakpoints.

If you want to halt program execution as soon as a specific task is scheduled to run by the OS, you can use the **Break.SetTask** command.

Task Context Display

You can switch the whole viewing context to a task that is currently not being executed. This means that all register and stack-related information displayed, e.g. in **Register**, **Data.List**, **Frame** etc. windows, will refer to this task. Be aware that this is only for displaying information. When you continue debugging the application (**Step** or **Go**), the debugger will switch back to the current context.

To display a specific task context, use the command:

Frame.TASK [<task>] Display task context.

- Use a magic number, task ID, or task name for **<task>**. For information about the parameters, see **“What to know about the Task Parameters”** (general_ref_t.pdf).
- To switch back to the current context, omit all parameters.

To display the call stack of a specific task, use the following command:

Frame /Task <task> Display call stack of a task.

If you'd like to see the application code where the task was preempted, then take these steps:

1. Open the **Frame /Caller /Task** <task> window.
2. Double-click the line showing the OS service call.

Dynamic Task Performance Measurement

The debugger can execute a dynamic performance measurement by evaluating the current running task in changing time intervals. Start the measurement with the commands **PERF.Mode TASK** and **PERF.Arm**, and view the contents with **PERF.ListTASK**. The evaluation is done by reading the 'magic' location (= current running task) in memory. This memory read may be non-intrusive or intrusive, depending on the **PERF.METHOD** used.

If **PERF** collects the PC for function profiling of processes in MMU-based operating systems (**SYStem.Option.MMUSPACES ON**), then you need to set **PERF.MMUSPACES**, too.

For a general description of the **PERF** command group, refer to "**General Commands Reference Guide P**" (general_ref_p.pdf).

Task Runtime Statistics

NOTE: This feature is *only* available, if your debug environment is able to trace task switches (program flow trace is not sufficient). It requires either an on-chip trace logic that is able to generate task information (e.g. data trace), or a software instrumentation feeding one of TRACE32 software based traces (e.g. **FDX** or **Logger**). For details, refer to "**OS-aware Tracing**" (glossary.pdf).

Based on the recordings made by the **Trace** (if available), the debugger is able to evaluate the time spent in a task and display it statistically and graphically.

To evaluate the contents of the trace buffer, use these commands:

Trace.List List.TASK DEFault	Display trace buffer and task switches
Trace.STATistic.TASK	Display task runtime statistic evaluation
Trace.Chart.TASK	Display task runtime timechart
Trace.PROfileSTATistic.TASK	Display task runtime within fixed time intervals statistically

Trace.PROfileChart.TASK	Display task runtime within fixed time intervals as colored graph
Trace.FindAll Address TASK.CONFIG(magic)	Display all data access records to the “magic” location
Trace.FindAll CYcle owner OR CYcle context	Display all context ID records

The start of the recording time, when the calculation doesn't know which task is running, is calculated as “(unknown)”.

All kernel activities up to the task switch are added to the calling task.

Function Runtime Statistics

NOTE:

This feature is *only* available, if your debug environment is able to trace task switches (program flow trace is not sufficient). It requires either an on-chip trace logic that is able to generate task information (e.g. data trace), or a software instrumentation feeding one of TRACE32 software based traces (e.g. **FDX** or **Logger**). For details, refer to “[OS-aware Tracing](#)” (glossary.pdf).

All function-related statistic and time chart evaluations can be used with task-specific information. The function timings will be calculated dependent on the task that called this function. To do this, in addition to the function entries and exits, the task switches must be recorded.

To do a selective recording on task-related function runtimes based on the data accesses, use the following command:

```
; Enable flow trace and accesses to the magic location
Break.Set TASK.CONFIG(magic) /TraceData
```

To do a selective recording on task-related function runtimes, based on the Arm Context ID, use the following command:

```
; Enable flow trace with Arm Context ID (e.g. 32bit)
ETM.ContextID 32
```

To evaluate the contents of the trace buffer, use these commands:

Trace.ListNesting	Display function nesting
Trace.STATistic.Func	Display function runtime statistic
Trace.STATistic.TREE	Display functions as call tree

Trace.STATistic.sYmbol /SplitTASK	Display flat runtime analysis
Trace.Chart.Func	Display function timechart
Trace.Chart.sYmbol /SplitTASK	Display flat runtime timechart

The start of the recording time, when the calculation doesn't know which task is running, is calculated as "(unknown)".

All kernel activities up to the task switch are added to the calling task.

The menu file “qzk.men” contains a menu with QXK specific menu items. Load this menu with the **MENU.ReProgram** command.

You will find a new menu called **QXK**.


- The **Display** menu items launch the kernel resource display windows.
- The **Stack Coverage** submenu starts and resets the QXK specific stack coverage and provides an easy way to add or remove tasks from the stack coverage window.
- The **Trace** menu is extended. In the **List** submenu, you can choose if you want a trace list window to show only task switches (if any) or task switches together with default display.
- The **Perf** menu contains additional submenus for task runtime statistics, task-related function runtime statistics or statistics on task states.

TASK.ActiveObj

Display active objects

Format: **TASK.ActiveObj**

Displays a list of active objects.




“magic” is a unique ID, used by the OS Awareness to identify the active object.

TASK.EXtTHRead

Display extended threads

Format: **TASK.EXtTHRead**


Displays a list of extended threads.



“magic” is a unique ID, used by the OS Awareness to identify the extended thread.

Format: **TASK.Mutex <mutex>**

Displays detailed information about a mutex. Specify a variable or address that contains the mutex.




“magic” is a unique ID, used by the OS Awareness to identify the mutex.

TASK.SEMaphore

Display semaphores

Format: **TASK.SEMaphore <semaphore>**


Displays detailed information about a semaphore. Specify a variable or address that contains the semaphore.



“magic” is a unique ID, used by the OS Awareness to identify the semaphore.

Format: **TASK.MEMPool**

Displays detailed information about memory pools.



The screenshot shows a Windows application window titled "B::TASK.MEMPool". The window contains a table with the following data:

magic	start	end	size	blocksize	nTot	nFree	nMin
20000BFC	20000710	20000758	00000048	0008	10.	10.	8.

“magic” is a unique ID, used by the OS Awareness to identify the memory pool.

QXK PRACTICE Functions

There is a QXK specific PRACTICE function.

TASK.CONFIG()

OS Awareness configuration information

Syntax: **TASK.CONFIG(magic | magicsize)**

Parameter and Description:

magic	Parameter Type: String (<i>without</i> quotation marks). Returns the magic address, which is the location that contains the currently running task (i.e. its task magic number).
magicsize	Parameter Type: String (<i>without</i> quotation marks). Returns the size of the task magic number (1, 2 or 4).

Return Value Type: Hex value.